

SECTION 6A

POWER STEERING SYSTEM

TABLE OF CONTENTS

Specifications	6A-1	On-Vehicle Service	6A-3
Fastener Tightening Specifications	6A-1	Bleeding the Power Steering System	6A-3
Special Tools	6A-1	Checking and Adding Fluid	6A-3
Special Tools Table	6A-1	Fluid Reservoir	6A-4
Diagnosis	6A-2	Hoses and Pipes	6A-5
Power Steering System Pressure Test	6A-2	General Description and System	
Power Steering System Leak Test	6A-2	Operation	6A-10
Maintenance and Repair	6A-3	Power Steering System	6A-10


SPECIFICATIONS

FASTENER TIGHTENING SPECIFICATIONS

Application	N•m	Lb-Ft	Lb-In
Air Cleaner Housing Bolts	12	-	106
Power Steering Fluid Reservoir Attaching Bolts	7	-	62
Power Steering Line Fittings-Cylinder End	27	20	-
Power Steering Line Fittings-Valve End	18	13	-
Power Steering Pump Pressure Line Union Nut	27	20	-
Steering Gear Inlet and Outlet Pipe Fittings	27	20	-

SPECIAL TOOLS

SPECIAL TOOLS TABLE

 A105A009	KM-354-B Pressure Test Gauge Kit
---	---

DIAGNOSIS

POWER STEERING SYSTEM PRESSURE TEST

Tools Required

KM-354-B Pressure Test Gauge Kit

Check the fluid pressure as follows to determine whether the trouble is in the pump or the gear unit.

Test Procedure

1. Check the power steering fluid level and the power steering pump belt tension. Refer to "Checking and Adding Fluid" in this section and Section 6B, Power Steering Pump.
2. Disconnect the high pressure line at the pump. Use a small container to catch any fluid.
3. Connect the hose of the pressure test gauge kit KM-354-B to the power steering pressure hose from the power steering pump.
4. Place the gear selector lever in PARK (automatic transaxle-equipped vehicles) or NEUTRAL (manual transaxle-equipped vehicles). Set the parking brake.
5. Open the gauge valve fully.
6. Start the engine and let it idle.
7. Turn the steering wheel from lock-to-lock several times to warm the fluid to operating temperature.
8. Increase the engine speed to 1,500 rpm.

Notice: The power steering pump could be damaged if the valve is fully closed for more than five seconds.

9. Close the gauge valve fully, and read the pressure. The pump pressure with the valve closed should be between 7 088 kPa to 8 619 kPa (1,028 psi to 1,250 psi).
10. Immediately open the gauge valve fully.
11. Turn the steering wheel all the way to the left and the right. If the pressure is within the specified limits, the problem is not in the pump. Check the power steering gear for leaks.

POWER STEERING SYSTEM LEAK TEST

General Procedure

Inspect the following:

- The fluid reservoir for overfill.
- Fluid for aeration and overflow.
- The hoses for loose connections.
- The torsion bar, stub shaft and adjuster seals for leaks.
- The component sealing surfaces for damage.

Important: Verify the exact point of the leak. The point from which the fluid is dripping is not necessarily the point at which the system is leaking. When service is required, clean the leak area upon disassembly, replace the leaking seal, check the component sealing surfaces for damage and reset the torque bolt to specifications, where required.

External Leak Check

The purpose of this procedure is to pinpoint the location of the leak. In some cases, the leak can be easily located, but seepage-type leaks may be harder to find. To locate seepage leaks, use the following method:

1. With the engine off, wipe dry the complete power steering system.
2. Check the power steering fluid level in the pump's reservoir. Adjust the fluid level as necessary. Refer to "Checking and Adding Fluid" in this section.

Notice: Do not hold the steering wheel at a stop for any length of time as this can damage the power steering pump.

3. Start the engine. Turn the steering wheel counter-clockwise and clockwise from stop to stop several times.
4. Find the exact area of the leak and repair it.

MAINTENANCE AND REPAIR

ON-VEHICLE SERVICE

BLEEDING THE POWER STEERING SYSTEM

If the power steering hydraulic system has been serviced, an accurate fluid level reading cannot be obtained until the air is bled from the system. Follow these steps to bleed the air from the system.

1. Turn the wheels all the way to the left and add the power steering fluid to the MIN mark on the fluid level indicator.


Notice: When adding fluid or making a complete fluid change, always use DEXRON® III power steering fluid. Failure to use the proper fluid will cause hose and seal damage and fluid leaks.

2. Start the engine. With the engine running at fast idle, recheck the fluid level. If necessary, add fluid to bring the level up to the MIN mark.
3. Bleed the system by turning the wheels from side to side without reaching the stop at either end. Keep the fluid level at the MIN mark. The air must be eliminated from the fluid before normal steering action can be obtained.
4. Return the wheels to the center position. Continue running the engine for two to three minutes.
5. Road test the car to be sure the steering functions normally and is free from noise.
6. Recheck the fluid level as described in steps 1 and 2. Make sure the fluid level is at the MAX mark after the system has stabilized at its normal operating temperature. Add fluid as needed.

CHECKING AND ADDING FLUID

Notice: When adding fluid or making a complete fluid change, always use DEXRON® III power steering fluid. Failure to use the proper fluid will cause hose and seal damage and fluid leaks.

1. The power steering fluid level is indicated either by marks on a see-through fluid reservoir or by marks on a fluid level indicator on the fluid reservoir cap.
2. If the fluid is warmed up to 66°C (150°F), the fluid level should be between the MAX and MIN marks. Add fluid as needed.
3. If the fluid is cool, 21°C (70°F), the fluid level should be at the MIN mark. Add fluid as needed.




FLUID RESERVOIR


(Left-Hand Drive Shown, Right-Hand Drive Similar)

Removal Procedure

1. Siphon the power steering fluid from the fluid reservoir.
2. Loosen the hose clamps and remove both hoses.



3. Remove the fluid reservoir attaching bolts and remove the fluid reservoir from the power steering fluid reservoir bracket.




Installation Procedure

1. Attach the fluid reservoir to the power steering fluid reservoir bracket with the power steering fluid reservoir attaching bolts.

Tighten

Tighten the power steering fluid reservoir attaching bolts to 7 N•m (62 lb-in).




2. Connect both hoses and secure the hose clamps.

Notice: When adding fluid or making a complete fluid change, always use DEXRON® III power steering fluid. Failure to use the proper fluid will cause hose and seal damage and fluid leaks.

3. Fill the fluid reservoir with power steering fluid.

4. Inspect for leaks. If there are leaks, correct the cause of the leaks and bleed the system. Refer to "Bleeding the Power Steering System" in this section.




HOSES AND PIPES

Steering Gear Cylinder Pipes

Removal Procedure

1. Siphon the power steering fluid from the fluid reservoir.
2. Disconnect and remove the steering gear cylinder pipes at the rack and pinion housing. Remove the O-ring seals from the housing.



Installation Procedure

1. Install new O-rings onto the cylinder pipes. Install the steering gear cylinder pipes into the rack and pinion housing.


Tighten

Tighten the power steering line fittings at the cylinder end to 27 N•m (20 lb-ft).

Tighten

Tighten the power steering line fittings at the valve end to 18 N•m (13 lb-ft).


2. Fill the fluid reservoir with power steering fluid.
3. Inspect for leaks. If there are leaks, correct the cause of the leaks and bleed the system. Refer to "Bleeding the Power Steering System" in this section.




Power Steering Pump Hoses and Pipes (Left-Hand Drive Shown, Right-Hand Drive Similar)

Removal Procedure


1. Remove the battery and battery tray. Refer to Section 1E, Engine Electrical.
2. Siphon the power steering fluid from the fluid reservoir.
3. On SOHC engines, disconnect the pressure line pipe and the supply line hose from the inlet and outlet connections on the power steering pump.




4. On DOHC engines, remove the air cleaner housing and disconnect the pressure line pipe and the supply line hose from the inlet and outlet connections on the power steering pump.



5. Disconnect the pressure line and return line hoses from the retaining clips at the bottom and the side of the radiator.
6. Disconnect the pressure line inlet pipe from the steering gear.




7. Disconnect the supply line hose from the power steering fluid reservoir.
8. Remove the power steering pump pressure line and return line.



Installation Procedure

1. Install the power steering pump pressure line and return line.
2. Connect the supply line hose to the power steering fluid reservoir.




3. Connect the pressure line inlet pipe to the steering gear.


Tighten

Tighten the steering gear inlet pipe fitting to 27 N•m (20 lb-ft).

6A - 8 POWER STEERING SYSTEM



4. Connect the pressure line and return line hoses to the retaining clips at the bottom and the side of the radiator.
5. On SOHC engines, connect the pressure line pipe and the supply line hose to the inlet and outlet connections on the power steering pump.



6. On DOHC engines, install the air cleaner housing.

Tighten


Tighten the air cleaner housing bolts to 12 N•m (106 lb-in).

7. On DOHC engines, connect the pressure line pipe and the supply line hose to the inlet and outlet connections on the power steering pump.

Tighten

Tighten the power steering pump pressure line union nut to 27 N•m (20 lb-ft).


8. Install the battery and battery tray. Refer to Section 1E, Engine Electrical.
9. Fill the fluid reservoir with power steering fluid.
10. Inspect for leaks. If there are leaks, correct the cause of the leaks and bleed the system. Refer to 'Bleeding the Power Steering System' in this section.




Power Steering Fluid Reservoir Hose (Left-Hand Drive Shown, Right-Hand Drive Similar)

Removal Procedure

1. Siphon the power steering fluid from the fluid reservoir.
2. Disconnect the return line pipe from the outlet connection at the steering gear.



3. Disconnect the fluid reservoir hose from the fluid reservoir.
4. Remove the fluid reservoir hose.



Installation Procedure

1. Connect the fluid reservoir hose at the fluid reservoir.
2. Connect the fluid reservoir pipe to the outlet connection at the steering gear.

Tighten

Tighten the steering gear outlet pipe fittings to 27 N•m (20 lb-ft).

Notice: When adding fluid or making a complete fluid change, always use DEXRON® III power steering fluid. Failure to use the proper fluid will cause hose and seal damage and fluid leaks.

3. Fill the fluid reservoir with power steering fluid.
4. Inspect for leaks. If there are leaks, correct the cause of the leaks and bleed the system. Refer to "Bleeding the Power Steering System" in this section.

GENERAL DESCRIPTION AND SYSTEM OPERATION

POWER STEERING SYSTEM

General Description

The power steering system consists of three components: the power steering pump, the power steering fluid reservoir and the power steering rack and pinion gear. The power steering pump is a vane-type pump providing hydraulic pressure for the system and is pow-

ered by the engine. It draws on the power steering fluid reservoir, which in turn is connected to the power steering gear. A pressure-relief valve inside the flow control valve limits the pump pressure. The power steering rack and pinion gear has a rotary control valve which directs hydraulic fluid coming from the power steering pump to one side or the other side of the rack piston. The integral rack piston is attached to the rack. The rack piston converts hydraulic pressure to a linear force which moves the rack to the left or the right. The force is then transmitted through the inner and the outer tie rods to the steering knuckles, which turn the wheels.