

---

# INDEX

## A

- A-Pillar Trim Panel, Interior Trim,  
On-Vehicle Service ..... 9G-23
- A/C Compressor Relay,  
Manual Control Heating, Ventilation,  
and Air Conditioning System ..... 7B-32
- A/C Diagram, 1.3L/1.5L SOHC (IEFI-6 ECM),  
Schematic and Routing Diagrams ..... 7B-9
- A/C Diagram, Non-, Heating and  
Ventilation System, Schematic  
and Routing Diagrams ..... 7A-2
- A/C Expansion Valve,  
Manual Control Heating, Ventilation,  
and Air Conditioning System ..... 7B-33
- A/C High-Pressure Pipe Line, Manual  
Control Heating, Ventilation,  
and Air Conditioning System ..... 7B-38
- A/C Hose Assembly,  
Manual Control Heating, Ventilation,  
and Air Conditioning System ..... 7B-44
- A/C Performance Test,  
Manual Control Heating, Ventilation,  
and Air Conditioning System ..... 7B-12
- A/C Pressure Transducer,  
Manual Control Heating, Ventilation,  
and Air Conditioning System ..... 7B-32
- A/C System (Typical), Schematic  
and Routing Diagrams ..... 7B-7
- A/C System Charging Capacity,  
Specifications ..... 7B-2
- A/C System Components - Control,  
Manual Control Heating, Ventilation,  
and Air Conditioning System ..... 7B-69
- A/C System Components - Functional,  
Manual Control Heating, Ventilation,  
and Air Conditioning System ..... 7B-69
- A/C System Service Procedures, General ..... 7B-22
- A/C System, Discharging,  
Adding Oil, Evacuating, and  
Charging Procedures for ..... 7B-23
- A/C System, The V5 ..... 7B-69
- A/C/Defogger Switch Assembly,  
Manual Control Heating, Ventilation,  
and Air Conditioning System ..... 7B-31
- Abbreviations, Transaxle Definitions and,  
4T40-E Automatic Transaxle ..... 5A-265
- ABS (Amber) Indicator Off Constantly,  
No DTCs Stored ..... 4F-14
- ABS (Amber) Indicator On Constantly,  
No DTCs Stored ..... 4F-10
- ABS (Amber) Indicator On Intermittently,  
No DTCs Stored ..... 4F-12
- ABS and Brake Indicator Control,  
Antilock Brake System ..... 4F-188
- ABS Circuit (1 of 3), Schematic and  
Routing Diagrams ..... 4F-5
- ABS Circuit (2 of 3), Schematic and  
Routing Diagrams ..... 4F-6
- ABS Circuit (3 of 3), Schematic and  
Routing Diagrams ..... 4F-7
- ABS Component Locator ..... 4F-4
- ABS Enable Relay ..... 4F-213
- ABS Enable Relay Test ..... 4F-187
- ABS Enable Relay, On-Vehicle Service ..... 4F-202
- ABS Indicators ..... 4F-213
- ABS Indicators, On-Vehicle Service ..... 4F-204
- ABS Solenoid ..... 4F-193
- ABS Solenoid Fuse, On-Vehicle Service ..... 4F-203
- ABS Sytem Components ..... 4F-212
- ABS, Tires and, Antilock Brake System ..... 4F-212
- Absolute Pressure Check  
(1.3L and 1.5L SOHC IEFI-6),  
Manifold, Engine Controls, Diagnosis ..... 1F-64
- Absolute Pressure Check  
(1.3L SOHC and 1.6L DOHC ITMS-6F),  
Manifold, Engine Controls, Diagnosis ..... 1F-66
- Absolute Pressure Sensor (Typical),  
Manifold, Engine Controls,  
On-Vehicle Service ..... 1F-305
- Absolute Pressure Sensor, Manifold,  
Engine Controls ..... 1F-316
- Accumulator Spring Removal,  
4T40-E Automatic Transaxle,  
Unit Repair ..... 5A-187
- Accumulator Springs Install,  
4T40-E Automatic Transaxle,  
Unit Repair ..... 5A-241
- Actuator Assembly, Manual Shaft,  
Parking Panel and, 4T40-E Automatic  
Transaxle, Component Locator ..... 5A-31
- Actuator Guide Replacement,  
4T40-E Automatic Transaxle,  
Unit Repair ..... 5A-196
- Air Bleeding, Clutch, On-Vehicle Service ..... 5C-16
- Air Conditioning Compressor Overhaul,  
V5, Manual Control Heating, Ventilation,  
and Air Conditioning System ..... 7B-52

Air Conditioning System .....	7B-21	Ashtray Lamp, Lighting Systems, On-Vehicle Service .....	9B-50
Air Control System Check (1.3L and 1.5L SOHC IEFI-6), Idle, Engine Controls, Diagnosis .....	1F-72	Ashtray, Instrumentation/Driver Information ....	9E-48
Air Control System Check (1.3L SOHC and 1.6L DOHC ITMS-6F), Idle, Engine Controls, Diagnosis .....	1F-76	Ashtray, Instrumentation/Driver Information, Diagnosis .....	9E-6
Air Control Valve (Typical), Idle, Engine Controls, On-Vehicle Service .....	1F-304	Ashtray, Instrumentation/Driver Information, On-Vehicle Service .....	9E-27
Air Control Valve, Idle, Engine Controls .....	1F-316	Assist Handles, Passenger, On-Vehicle Service .....	9Q-14
Air Distribution Case Assembly, Heater/, Manual Control Heating, Ventilation, and Air Conditioning System .....	7B-35	Assist Handles, Passenger, Roof .....	9Q-16
Air System Operation, Idle, Engine Controls .....	1F-313	At Each Fuel Fill, Owner Inspections and Services .....	0B-13
Air Temperature Sensor (Typical), Manifold, Engine Controls, On-Vehicle Service .....	1F-303	At Least Annually, Owner Inspections and Services .....	0B-14
Air Temperature Sensor, Manifold, Engine Controls .....	1F-316	At Least Monthly, Owner Inspections and Services .....	0B-13
Airbag Module Deployment (In Vehicle), On-Vehicle Service .....	8B-46	At Least Twice a Year, Owner Inspections and Services .....	0B-13
Airbag Module Deployment (Outside of Vehicle), On-Vehicle Service .....	8B-49	Audio Security System .....	9F-14
Airbag Module Disposal Procedure, Deployed, On-Vehicle Service .....	8B-49	Audio System Circuit, Schematic and Routing Diagrams .....	9F-2
Airbag Module, Driver, On-Vehicle Service .....	8B-40	Audio System, On-Vehicle Service .....	9F-8
Airbag Module, Passenger, Supplemental Inflatable Restraints (SIR), On-Vehicle Service .....	8B-43	Automated Modulator Test Antilock Brake System, Diagnosis .....	4F-186
Airbag Modules .....	8B-51	Automated Motor Pack Diagnosis Test, Antilock Brake System, Diagnosis .....	4F-186
Airflow (Typical), Manual Control Heating, Ventilation, and Air Conditioning System, Schematic and Routing Diagrams .....	7B-8	Automatic Transmission Fluid Pressure Manual Valve Position Switch Resistance Check, 4T40-E Automatic Transaxle, Diagnosis .....	5A-64
Airflow Through Vents with Rear Heating Duct, Heating and Ventilation System, Schematic and Routing Diagrams .....	7A-3	Automatic Transmission Fluid Pressure Manual Valve Position Switch (TFP Val. Position Sw.), 4T40-E Automatic Transaxle .....	5A-271
Alignment Checking, Frame and Underbody .....	9N-3	Automatic Transmission Input (Shaft) Speed Sensor (A/T OSS), 4T40-E Automatic Transaxle .....	5A-269
Alignment Specifications, Wheel .....	2B-1	Automatic Transmission Output (Shaft) Speed Sensor (A/T OSS), 4T40-E Automatic Transaxle .....	5A-269
Alignment, Four Wheel .....	2B-8	Automatic Transmission Output Speed Sensor (A/T OSS), 4T40-E Automatic Transaxle, On-Vehicle Service .....	5A-158
AM/FM Radio, Stereo Cassette .....	9F-14	Automatic Transmission Output Speed Sensor Removal, 4T40-E Automatic Transaxle, Unit Repair .....	5A-182
Amperage, Cold Cranking, Engine Electrical .....	1E-55	Axis Inclination, Steering, Wheel Alignment ....	2B-9
Angle, Included, Wheel Alignment .....	2B-9	Axle Assembly, Drive, Automatic Transaxle, On-Vehicle Service .....	3A-4
Angle, Turning, Wheel Alignment .....	2B-9	Axle Assembly, Drive, Manual Transaxle, On-Vehicle Service .....	3B-4
Antenna Mast, Power, On-Vehicle Service ....	9F-12	Axle Assembly, Rear, Rear Suspension .....	2D-8
Antenna Motor/Manual Antenna, Power, On-Vehicle Service .....	9F-13	Axle Seal Assemble, Right-Hand, 4T40-E Automatic Transaxle, Unit Repair .....	5A-258
Antenna, Diagnosis .....	9F-6	Axle Seal Install, Side Cover, 4T40-E Automatic Transaxle, Unit Repair .....	5A-257
Antenna, Manual .....	9F-14	Axle Seal Removal, Right-Hand, 4T40-E Automatic Transaxle, Unit Repair .....	5A-195
Antenna, Power .....	9F-14		
Anticorrosion Materials, Body Front End, On-Vehicle Service .....	9R-2		
Antilock Brake System Fuse .....	4F-201		
Antilock Braking Mode .....	4F-211		
Arm, Control, Front Suspension, On-Vehicle Service .....	2C-13		
Ashtray Lamp, Lighting Systems .....	9B-52		

Axle Seal, Drive, Five-Speed Manual Transaxle, On-Vehicle Service .....	5B-36
Axle with ABS, Unit Repair .....	2D-15
Axle without ABS, Rear, Unit Repair .....	2D-15
Axle, Front Drive, Automatic Transaxle .....	3A-13
Axle, Front Drive, Manual Transaxle .....	3B-12
Axle, Front Drive, Manual Transaxle, Component Locator .....	3B-2
Axles, Front Drives, Automatic Transaxle, Component Locator .....	3A-2

## B

B-Pillar Molding (Notchback and Five-Door Hatchback), Exterior Trim, On-Vehicle Service .....	9M-2
B-Pillar Molding (Three-Door Hatchback), Exterior Trim, On-Vehicle Service .....	9M-2
B-Pillar Trim Panel (Three-Door Hatchback), Lower, Interior Trim, On-Vehicle Service .....	9G-11
B-Pillar Trim Panel (Three-Door Hatchback), Upper, Interior Trim, On-Vehicle Service .....	9G-9
B-Pillar Trim Panel, Lower, Interior Trim, On-Vehicle Service .....	9G-11
B-Pillar Trim Panel, Upper, Interior Trim, On-Vehicle Service .....	9G-7
Backfire, Engine Controls, Symptom Diagnosis .....	1F-288
Backing Plate, Rear Drum Brakes .....	4E-13
Backup Lamps (Hatchback), Rear Fog/, Lighting Systems, On-Vehicle Service .....	9B-41
Backup Lamps (Notchback), Rear Fog/, Lighting Systems, On-Vehicle Service .....	9B-40
Backup Lamps Circuit, Lighting Systems, Schematic and Routing Diagrams .....	9B-3
Backup Lamps, Lighting Systems .....	9B-53
Balance Test, Fuel Injector, Engine Controls, Diagnosis .....	1F-111
Balancing, On-Vehicle .....	2E-4
Balancing, Tire and Wheel .....	2E-9
Balancing, Wheel, Off-Vehicle, Unit Repair .....	2E-7
Ball Joint and Knuckle, Front Suspension, Diagnosis .....	2C-4
Ball Joint, Front Suspension, Unit Repair .....	2C-16
Band Install, Low/Reverse, 4T40-E Automatic Transaxle, Unit Repair .....	5A-210
Base Braking Mode, Antilock Brake System .....	4F-210
Basic Knowledge Required, 4T40-E Automatic Transaxle, Diagnosis .....	5A-50
Battery (Off the Vehicle), Charging a Completely Discharged, Engine Electrical .....	1E-56
Battery Load Test, Engine Electrical, Diagnosis .....	1E-9
Battery Specifications, Engine Electrical .....	1E-2
Battery, Engine Electrical .....	1E-55

Battery/Battery Tray, Engine Electrical, On-Vehicle Service .....	1E-16
Bearing Adjustment, Wheel, Rear Suspension, On-Vehicle Service .....	2D-3
Bearing Diagnosis, Sealed Wheel, Suspension Diagnosis .....	2A-6
Bearing, Hub and, Assembly with ABS, Rear Suspension .....	2D-12
Bearing, Hub and, Assembly without ABS, Rear Suspension .....	2D-8
Bearing, Hub and, Front Suspension, Unit Repair .....	2C-16
Bearing, Rack, Manual Steering Gear, Unit Repair .....	6D-14
Bearing, Roller, Manual Steering Gear, Unit Repair .....	6D-17
Bearing, Support, Front Suspension, Unit Repair .....	2C-24
Bearing, Tapered Roller, Suspension Diagnosis .....	2A-6
Bearings and Connecting Rod Bearings - Gauging Plastic, Crankshaft, SOHC Engine Mechanical .....	1C-92
Belt Check and Adjust, Timing, SOHC Engine Mechanical, On-Vehicle Service .....	1C-31
Belt, Pump Drive, Power Steering Pump, On-Vehicle Service .....	6B-4
Belt, Timing, SOHC Engine Mechanical .....	1C-95
Belt, Timing, SOHC Engine Mechanical, On-Vehicle Service .....	1C-36
Bleeder Valve, Hydraulic Modulator, Antilock Brake System, On-Vehicle Service .....	4F-192
Bleeding System, Antilock Brake System .....	4F-189
Bleeding the Power Steering System, On-Vehicle Service .....	6A-3
Bleeding, Air, Clutch, On-Vehicle Service .....	5C-16
Block Heater, Engine, Engine Cooling .....	1D-21
Blower Electrical, Heating and Ventilation System, Diagnosis .....	7A-7
Blower Motor Resistor, Manual Control Heating, Ventilation, and Air Conditioning System .....	7B-30
Blower Motor, Heating and Ventilation System .....	7A-17
Blower Motor, Manual Control Heating, Ventilation, and Air Conditioning System .....	7B-29
Blower Noise, Heating and Ventilation System, Diagnosis .....	7A-14
Blower Resistor, Heating and Ventilation System .....	7A-19
Blower Switch, Manual Control Heating, Ventilation, and Air Conditioning System .....	7B-30
Body-to-Spacer Plate Gasket, Valve, 4T40-E Automatic Transaxle, Component Locator .....	5A-37
Body (Typical), Throttle, Engine Controls, On-Vehicle Service .....	1F-300

Body Assembly, Control Valve, 4T40-E Automatic Transaxle, Component Locator .....	5A-21
Body Construction, General, Frame and Underbody .....	9N-7
Body Front End .....	9R-13
Body Front End Anticorrosion Materials, On-Vehicle Service .....	9R-2
Body Front End Fasteners, On-Vehicle Service .....	9R-2
Body Front End Lubrication, On-Vehicle Service .....	9R-2
Body Rear End Weatherstrip, On-Vehicle Service .....	9S-11
Bolt Specifications, Standard .....	0B-8
Booster Assembly, Power, On-Vehicle Service .....	4C-3
Booster, Power .....	4C-9
Brake Adjustment, Parking .....	4G-2
Brake Adjustment, Rear Drum Brakes .....	4E-3
Brake Cable, Parking .....	4G-6
Brake Caliper Assembly, Disc .....	4D-11
Brake Fluid Level Switch, Antilock Brake System .....	4F-213
Brake Fluid Reservoir, Master Cylinder .....	4B-5
Brake Hose (Front), Hydraulic Brakes .....	4A-18
Brake Hose (Rear), Hydraulic Brakes .....	4A-17
Brake Hose Inspection, Hydraulic Brakes, Diagnosis .....	4A-5
Brake Indicator Control, ABS and, Antilock Brake System .....	4F-188
Brake Lamp Warning Circuit Diagnosis, Hydraulic Brakes .....	4A-7
Brake Lever, Parking .....	4G-3
Brake Pedal, Hydraulic Brakes .....	4A-21
Brake Proportioning Valve, Checking, Master Cylinder .....	4B-1
Brake System (ABS), Hydraulic Brakes, Component Locator .....	4A-2
Brake System (Non-ABS), Hydraulic Brakes, Component Locator .....	4A-4
Brake System Testing, Hydraulic Brakes, Diagnosis, .....	4A-5
Brake, Parking .....	4G-12
Braking Mode, Antilock .....	4F-211
Braking Mode, Base, Antilock Brake System .....	4F-210
Bucket Seat, Front, On-Vehicle Service .....	9H-2
Built-In Hydrometer, Engine Electrical .....	1E-55
Bulb Check, Supplemental Inflatable Restraints, Diagnosis .....	8B-5
Bulb Usage Chart, Lighting Systems, Specifications .....	9B-2
Bumpers .....	9O-11
Bushing and/or Bearing Ring, Gearshift Tube, Boot, Five-Speed Manual Transaxle .....	5B-17
Bushing, Rack, Manual Steering Gear, Unit Repair .....	6D-18

Bushings, Control Arm, Front Suspension, Unit Repair .....	2C-18
Bushings, Control Arm, Rear Suspension, Unit Repair .....	2D-13
Bushings, Linkage Lever and/or, On-Vehicle Service .....	5B-26

## C

C-Pillar Trim Panel (Three-Door Hatchback), Interior Trim, On-Vehicle Service .....	9G-25
C-Pillar Trim Panel, Interior Trim, On-Vehicle Service .....	9G-23
Cable Adjustment, Temperature, Manual Control Heating, Ventilation, and Air Conditioning System .....	7B-27
Cable, Parking Brake .....	4G-6
Cable, Shift Control, 4T40-E Automatic Transaxle, On-Vehicle Service .....	5A-153
Caliper Assembly, Disc Brake .....	4D-11
Caliper Assembly, Front Disc Brakes, On-Vehicle Service .....	4D-4
Caliper Overhaul, Front Disc Brakes, Unit Repair .....	4D-8
Camber and Caster Check, Front, Wheel Alignment, Diagnosis .....	2B-8
Camber Check, Rear, Wheel Alignment, Diagnosis .....	2B-8
Camber, Wheel Alignment .....	2B-9
Camshaft Gear, SOHC Engine Mechanical, On-Vehicle Service .....	1C-58
Camshaft, SOHC Engine Mechanical .....	1C-95
Camshaft, SOHC Engine Mechanical, On-Vehicle Service .....	1C-27
Canister Purge Solenoid (Typical), Engine Controls, On-Vehicle Service .....	1F-309
Canister, Evaporative Emission, Engine Controls .....	1F-314
Canister, Evaporative Emission, On-Vehicle Service .....	1F-309
Capacity, A/C System Charging, Specifications .....	7B-2
Capacity, Reserve, Engine Electrical .....	1E-55
Carpet, Floor, Interior Trim .....	9G-30
Carpet, Floor, Interior Trim, On-Vehicle Service .....	9G-17
Carrier and Reaction Gear Assembly Removal, Input, 4T40-E Automatic Transaxle, Unit Repair .....	5A-191
Carrier Assemble, Direct/Coast Clutch, Reaction, 4T40-E Automatic Transaxle, Unit Repair .....	5A-219
Carrier Assemble, Reaction Internal Gear, Input, 4T40-E Automatic Transaxle, Unit Repair .....	5A-213
Carrier Assembly, Input, 4T40-E Automatic Transaxle, Component Locator .....	5A-26

Carrier Assembly, Reaction, 4T40-E Automatic Transaxle, Component Locator .....	5A-25
Carrier Disassemble, Direct/Coast Clutch, Reaction, 4T40-E Automatic Transaxle, Unit Repair .....	5A-213
Carrier Disassemble, Reaction Internal Gear, Input, 4T40-E Automatic Transaxle, Unit Repair .....	5A-212
Carrier Install, Direct/Coast Clutch, Reaction, 4T40-E Automatic Transaxle, Unit Repair .....	5A-224
Carrier Install, Reaction Internal Gear, Input, 4T40-E Automatic Transaxle, Unit Repair .....	5A-213
Carrier Pinion Clearance Check, Reaction, 4T40-E Automatic Transaxle, Unit Repair .....	5A-218
Carrier Pinion Gear Clearance Check, Input, 4T40-E Automatic Transaxle, Unit Repair .....	5A-212
Case and Associated Parts (1 of 3), 4T40-E Automatic Transaxle, Component Locator .....	5A-32
Case and Associated Parts (2 of 3), 4T40-E Automatic Transaxle, Component Locator .....	5A-33
Case and Associated Parts (3 of 3), 4T40-E Automatic Transaxle, Component Locator .....	5A-35
Case Inspection, 4T40-E Automatic Transaxle, Unit Repair .....	5A-195
Case Passages - Bottom, 4T40-E Automatic Transaxle, Component Locator .....	5A-40
Case Passages - Channel Plate Side, 4T40-E Automatic Transaxle, Component Locator .....	5A-39
Case Porosity Repair, 4T40-E Automatic Transaxle, Diagnosis .....	5A-55
Case Porosity Repair, 4T40-E Automatic Transaxle, On-Vehicle Service .....	5A-145
Case Side Cover Pan and Gaskets, 4T40-E Automatic Transaxle, On-Vehicle Service .....	5A-161
Case Side Cover Removal, 4T40-E Automatic Transaxle, Unit Repair .....	5A-185
Case Side, Channel Plate Passages, 4T40-E Automatic Transaxle, Component Locator .....	5A-38
Case, Differential and, Five-Speed Manual Transaxle, Component Locators .....	5B-10
Case, Gears and, Five-Speed Manual Transaxle, Component Locators .....	5B-8
Case, Housing, Five-Speed Manual Transaxle, Unit Repair .....	5B-73
Cassette AM/FM Radio, Stereo, Diagnosis .....	9F-3
Cassette Care, Tape Player and .....	9F-14
Caster Check, Front Camber and, Wheel Alignment, Diagnosis .....	2B-8
Caster, Wheel Alignment .....	2B-9
Catalytic Converter .....	1G-12
Catalytic Converter/Connecting Pipe, On-Vehicle Service .....	1G-3
Center High-Mounted Stoplamp (Hatchback), Lighting Systems, On-Vehicle Service .....	9B-42
Center High-Mounted Stoplamp (Notchback), Lighting Systems, On-Vehicle Service .....	9B-42
Channel Molding, Inside, Doors, On-Vehicle Service .....	9P-35
Channel Molding, Outside, Doors, On-Vehicle Service .....	9P-36
Channel Plate-to-Case Gasket, 4T40-E Automatic Transaxle, Component Locator .....	5A-42
Channel Plate and Gasket Removal, 4T40-E Automatic Transaxle, Unit Repair .....	5A-187
Channel Plate Assembly Assemble, 4T40-E Automatic Transaxle, Unit Repair .....	5A-241
Channel Plate Assembly Disassemble, 4T40-E Automatic Transaxle, Unit Repair .....	5A-240
Channel Plate Assembly Installation, 4T40-E Automatic Transaxle, Unit Repair .....	5A-242
Channel Plate Passages - Case Side, 4T40-E Automatic Transaxle, Component Locator .....	5A-38
Channel Plate Passages - Control Valve Body Side, 4T40-E Automatic Transaxle, Component Locator .....	5A-49
Channel Plate Side, Case Passages, 4T40-E Automatic Transaxle, Component Locator .....	5A-39
Channel Plate Side, Control Valve Body Channels, 4T40-E Automatic Transaxle, Component Locator .....	5A-47
Charging a Completely Discharged Battery (Off the Vehicle), Engine Electrical .....	1E-56
Charging Procedure, Engine Electrical .....	1E-55
Charging Procedures for A/C System, Discharging, Adding Oil, Evacuating, and .....	7B-23
Charging System, Engine Electrical .....	1E-57
Charging System, Engine Electrical, Schematic and Routing Diagrams .....	1E-4
Charging Time Required, Engine Electrical .....	1E-56
Chart, Bulb Usage, Lighting Systems, Specifications .....	9B-2
Chart, Fuse, Body Wiring System, Schematic and Routing Diagrams .....	9A-9
Chart, Wire Color, Body Wiring System, Schematic and Routing Diagrams .....	9A-1
Checkball Removal, 4T40-E Automatic Transaxle, Unit Repair .....	5A-186

Checkballs Installation, 4T40-E Automatic Transaxle, Unit Repair .....	5A-243
Chemical Stability in the Refrigeration System, Maintaining .....	7B-23
Child Seat Tether Anchor .....	8A-20
Child Seat Tether Anchor, On-Vehicle Service .....	8A-19
Childproof Rear Door Lock, Doors .....	9P-40
Childproof Rear Door Lock, Doors, On-Vehicle Service .....	9P-23
Chime Module, Instrumentation/Driver Information .....	9E-48
Chime Module, Instrumentation/Driver Information, Diagnosis .....	9E-23
Chime Module, Instrumentation/Driver Information, On-Vehicle Service .....	9E-45
Chime, Headlamps On Reminder, Lighting Systems, Lighting Systems, Diagnosis .....	9B-15
Chuggles, Surges or, Engine Controls, Diagnosis .....	1F-275
Cigar Lighter, Instrumentation/Driver Information .....	9E-47
Cigar Lighter, Instrumentation/Driver Information, Diagnosis .....	9E-5
Cigar Lighter, Instrumentation/Driver Information, On-Vehicle Service .....	9E-27
Circuit Check (1.3L and 1.5L SOHC IEFI-6), Fuel Pump Relay, Engine Controls, Diagnosis .....	1F-56
Circuit Check (1.3L SOHC and 1.6L DOHC ITMS-6F), Fuel Pump Relay, Engine Controls, Diagnosis .....	1F-60
Circuit Check - With A/C (1.3L and 1.5L SOHC IEFI-6), Engine Cooling Fan, Engine Controls, Diagnosis .....	1F-96
Circuit Check - With A/C (1.3L SOHC and 1.6L DOHC ITMS-6F), Engine Cooling Fan, Engine Controls, Diagnosis .....	1F-104
Circuit Check - Without A/C (1.3L and 1.5L SOHC IEFI-6), Engine Cooling Fan, Engine Controls, Diagnosis .....	1F-88
Circuit Check - Without A/C (1.3L SOHC and 1.6L DOHC ITMS-6F), Engine Cooling Fan, Engine Controls, Diagnosis ....	1F-92
Cleanliness and Care, Engine, General Information .....	1A-11
Clearing Fault Codes, Supplemental Inflatable Restraints (SIR), Diagnosis .....	8B-5
Clearing Trouble Codes, Engine Controls, Diagnosis .....	1F-22
Clip Removal, Manual Valve, 4T40-E Automatic Transaxle, Unit Repair .....	5A-187
Clock Spring, Supplemental Inflatable Restraints (SIR) .....	8B-52
Clock Spring, Supplemental Inflatable Restraints (SIR), On-Vehicle Service .....	8B-41
Clock, Digital, Diagnosis .....	9E-7
Clock, Digital, Instrumentation/Driver Information .....	9E-47
Clock, Digital, Instrumentation/Driver Information, On-Vehicle Service .....	9E-30
Cluster (Deluxe), Instrument, Instrumentation/Driver Information .....	9E-47
Cluster (Deluxe), Instrument, Instrumentation/Driver Information, On-Vehicle Service .....	9E-31
Cluster (Standard), Instrument, Instrumentation/Driver Information, On-Vehicle Service .....	9E-31
Cluster (Standard), Instrument, Instrumentation/Driver Information .....	9E-47
Cluster Gear, Input Shaft and, Five-Speed Manual Transaxle, Unit Repair .....	5B-55
Cluster Indicator Lamps, Instrument, Instrumentation/Driver Information, Diagnosis .....	9E-19
Cluster Indicator Lamps, Instrument, Instrumentation/Driver Information, On-Vehicle Service .....	9E-35
Cluster Indicator Lamps, Instrument, Instrumentation/Driver Information .....	9E-47
Clutch and Low/Reverse Band Removal, Forward, 4T40-E Automatic Transaxle, Unit Repair .....	5A-191
Clutch and Reaction Gear Set Removal, Direct/Coast, 4T40-E Automatic Transaxle, Unit Repair .....	5A-190
Clutch Assemble, Forward Clutch Support, Low Roller, 4T40-E Automatic Transaxle, Unit Repair .....	5A-205
Clutch Assemble, Forward, 4T40-E Automatic Transaxle, Unit Repair .....	5A-208
Clutch Assemble, Reverse Input and Second Roller, 4T40-E Automatic Transaxle, Unit Repair .....	5A-228
Clutch Assemblies, Direct and Coast, 4T40-E Automatic Transaxle, Component Locator .....	5A-24
Clutch Assembly, Forward, 4T40-E Automatic Transaxle, Component Locator .....	5A-28
Clutch Assembly, Reverse Input, 4T40-E Automatic Transaxle, Component Locator .....	5A-23
Clutch Coil, Manual Control Heating, Ventilation, and Air Conditioning System, Unit Repair .....	7B-58
Clutch Components, Hydraulic, Component Locator .....	5C-4
Clutch Disassemble, Forward Clutch Support, Roller, 4T40-E Automatic Transaxle, Unit Repair .....	5A-203

Clutch Disassemble, Forward, 4T40-E Automatic Transaxle, Unit Repair .....	5A-206
Clutch Disassemble, Reverse Input and Second Roller, 4T40-E Automatic Transaxle, Unit Repair .....	5A-225
Clutch Disc and Related Components, On-Vehicle Service .....	5C-9
Clutch Functional Air Check, Forward, 4T40-E Automatic Transaxle, Unit Repair .....	5A-209
Clutch Functional Air Check, Reverse, 4T40-E Automatic Transaxle, Unit Repair .....	5A-229
Clutch Functional Air Check, Second, 4T40-E Automatic Transaxle, Unit Repair .....	5A-236
Clutch Functional Air Checks, Direct and Coast, 4T40-E Automatic Transaxle, Unit Repair .....	5A-224
Clutch Housing Removal, Reverse Input, 4T40-E Automatic Transaxle, Unit Repair .....	5A-190
Clutch Hub Assemble, Input Internal Gear, Forward, 4T40-E Automatic Transaxle, Unit Repair .....	5A-211
Clutch Hub Disassemble, Input Internal Gear, Forward, 4T40-E Automatic Transaxle, Unit Repair .....	5A-211
Clutch Hub Install, Input Internal Gear, Forward, 4T40-E Automatic Transaxle, Unit Repair .....	5A-212
Clutch Hub Removal, Input Internal Gear, Forward, 4T40-E Automatic Transaxle, Unit Repair .....	5A-191
Clutch Hub, Input Internal Gear and Forward, 4T40-E Automatic Transaxle, Component Locator .....	5A-27
Clutch Install, Forward Clutch Support, Low Roller, 4T40-E Automatic Transaxle, Unit Repair .....	5A-206
Clutch Install, Reverse Input and Second Roller, 4T40-E Automatic Transaxle, Unit Repair .....	5A-231
Clutch Installation, Forward, 4T40-E Automatic Transaxle, Unit Repair .....	5A-210
Clutch Master Cylinder Assembly, On-Vehicle Service .....	5C-16
Clutch Master Cylinder, Unit Repair .....	5C-20
Clutch Operation, Diagnosis .....	5C-2
Clutch Pedal Adjustment (Hydraulic), On-Vehicle Service .....	5C-14
Clutch Pedal, On-Vehicle Service .....	5C-7
Clutch Plate and Hub Assembly, Manual Control Heating, Ventilation, and Air Conditioning System, Unit Repair .....	7B-52
Clutch Plate Diagnosis, 4T40-E Automatic Transaxle, Diagnosis .....	5A-54
Clutch Plate Installation, Second, 4T40-E Automatic Transaxle, Unit Repair .....	5A-231
Clutch Plates Removal, Second, 4T40-E Automatic Transaxle, Unit Repair .....	5A-189
Clutch Release Cylinder Assembly, On-Vehicle Service .....	5C-19
Clutch Release Cylinder, Unit Repair .....	5C-22
Clutch Release Point Adjustment (Hydraulic), On-Vehicle Service .....	5C-16
Clutch Removal, Forward Clutch Support, Low Roller, 4T40-E Automatic Transaxle, Unit Repair .....	5A-192
Clutch Rotor and Bearing, Manual Control Heating, Ventilation, and Air Conditioning System, Unit Repair .....	7B-54
Clutch Solenoid Valve (TCC Sol. Valve), Torque Converter, 4T40-E Automatic Transaxle .....	5A-271
Clutch Support Assembly, Forward, 4T40-E Automatic Transaxle, Component Locator .....	5A-29
Clutch Support, Low Roller Clutch Assemble, Forward, 4T40-E Automatic Transaxle, Unit Repair .....	5A-205
Clutch Support, Low Roller Clutch Install, Forward, 4T40-E Automatic Transaxle, Unit Repair .....	5A-206
Clutch Support, Roller Clutch Disassemble, Forward, 4T40-E Automatic Transaxle, Unit Repair .....	5A-203
Clutch, Reaction Carrier Assemble, Direct/Coast, 4T40-E Automatic Transaxle, Unit Repair .....	5A-219
Clutch, Reaction Carrier Disassemble, Direct/Coast, 4T40-E Automatic Transaxle, Unit Repair .....	5A-213
Clutch, Reaction Carrier Install, Direct/Coast, 4T40-E Automatic Transaxle, Unit Repair .....	5A-224
CO Potentiometer (Leaded Fuel Only), Engine Controls .....	1F-315
CO Potentiometer (Leaded Fuel Only), Engine Controls, On-Vehicle Service .....	1F-303
Coast Clutch Assemblies, Direct and, 4T40-E Automatic Transaxle, Component Locator .....	5A-24
Coat Hook, Roof, On-Vehicle Service .....	9Q-15
Coat Hooks, Roof .....	9Q-16
Code Diagnosis, Trouble, Engine Controls .....	1F-22
Codes, Clearing Trouble, Engine Controls, Diagnosis .....	1F-22
Coding Procedure, Key, Immobilizer Anti-Theft System, On-Vehicle Service .....	9T-7
Cold Cranking Amperage, Engine Electrical .....	1E-55
Color Chart, Wire, Body Wiring System, Schematic and Routing Diagrams .....	9A-1

- Column Diagnosis, Steering ..... 6E-2
- Column, Standard Steering, Unit Repair ..... 6E-24
- Column, Steering Wheel and ..... 6E-42
- Column, Steering, On-Vehicle Service ..... 6E-19
- Column, Tilt Steering, Unit Repair ..... 6E-29
- Compact Disc Care ..... 9F-14
- Component Disassembly, Major,  
Five-Speed Manual Transaxle ..... 5B-44
- Component Locator (DOHC),  
Engine Controls ..... 1F-21
- Component Locator (SOHC),  
Engine Controls ..... 1F-20
- Component Resistance Chart,  
4T40-E Automatic Transaxle, Diagnosis ..... 5A-64
- Component Resistance Check Procedure,  
4T40-E Automatic Transaxle, Diagnosis ..... 5A-52
- Compression Test, Engine, Diagnosis ..... 1A-1
- Compressor Overhaul, V5 Air Conditioning,  
Manual Control Heating, Ventilation,  
and Air Conditioning System ..... 7B-52
- Compressor, Manual Control Heating,  
Ventilation, and Air Conditioning System,  
On-Vehicle Service ..... 7B-47
- Compressor, V5, Description of Operation ..... 7B-70
- Compressor, V5, General Description ..... 7B-70
- Compressor, V5, Manual Control Heating,  
Ventilation, and Air Conditioning System,  
Component Locator ..... 7B-51
- Condenser, Manual Control Heating,  
Ventilation, and Air Conditioning  
System, On-Vehicle Service ..... 7B-49
- Connecting Pipe, Engine Exhaust ..... 1G-12
- Connecting Rod Bearings - Gauging Plastic,  
Crankshaft Bearings and,  
SOHC Engine Mechanical ..... 1C-92
- Connection Box Harness Routing,  
Body Wiring System,  
Schematic and Routing Diagrams ..... 9A-7
- Connector (DLC), Data Link,  
4T40-E Automatic Transaxle ..... 5A-274
- Connector End View, Engine Controls,  
Schematic and Routing Diagrams ..... 1F-16
- Connector Face View (1 of 2), EBCM,  
Antilock Brake System ..... 4F-8
- Connector Face View (2 of 2), EBCM,  
Antilock Brake System ..... 4F-9
- Connector, Octane Number,  
Engine Controls ..... 1F-318
- Connector, Transmission Electrical,  
4T40-E Automatic Transaxle ..... 5A-273
- Console, Floor, Interior Trim ..... 9G-30
- Console, Floor, Interior Trim,  
On-Vehicle Service ..... 9G-19
- Control A/C Diagram, 1.3L SOHC and  
1.6L DOHC (ITMS-6F ECM),  
Schematic and Routing Diagrams ..... 7B-10
- Control Arm Bushings, Front Suspension,  
Unit Repair ..... 2C-18
- Control Arm Bushings, Rear Suspension,  
Unit Repair ..... 2D-13
- Control Arm, Front Suspension,  
On-Vehicle Service ..... 2C-13
- Control Assembly, Heater, Heating and  
Ventilation System, On-Vehicle Service ..... 7A-16
- Control Cable Adjustment,  
4T40-E Automatic Transaxle,  
On-Vehicle Service ..... 5A-156
- Control Module (1 of 4), Transmission,  
4T40-E Automatic Transaxle,  
Schematic and Routing Diagrams ..... 5A-15
- Control Module (2 of 4), Transmission,  
4T40-E Automatic Transaxle,  
Schematic and Routing Diagrams ..... 5A-16
- Control Module (3 of 4), Transmission,  
4T40-E Automatic Transaxle,  
Schematic and Routing Diagrams ..... 5A-17
- Control Module (4 of 4), Transmission,  
4T40-E Automatic Transaxle,  
Schematic and Routing Diagrams ..... 5A-18
- Control Shift Rod, Five-Speed Manual  
Transaxle, On-Vehicle Service ..... 5B-25
- Control Solenoid Valve (PS Sol. Valve),  
Pressure, 4T40-E Automatic Transaxle .... 5A-270
- Control System Check (1.3L and 1.5L  
SOHC IEFI-6), Idle Air, Engine Controls,  
Diagnosis ..... 1F-72
- Control System Check (1.3L SOHC and  
1.6L DOHC ITMS-6F), Idle Air,  
Engine Controls, Diagnosis ..... 1F-76
- Control Valve Assembly and TFP Switch  
Install, 4T40-E Automatic Transaxle,  
Unit Repair ..... 5A-252
- Control Valve Assembly, Manual  
Control Heating, Ventilation, and  
Air Conditioning System, Unit Repair ..... 7B-63
- Control Valve Body Assemble,  
4T40-E Automatic Transaxle,  
Unit Repair ..... 5A-248
- Control Valve Body Assembly and  
Gasket Removal, 4T40-E Automatic  
Transaxle, Unit Repair ..... 5A-186
- Control Valve Body Assembly,  
4T40-E Automatic Transaxle,  
Component Locator ..... 5A-21
- Control Valve Body Channels - Channel  
Plate Side, 4T40-E Automatic Transaxle,  
Component Locator ..... 5A-47
- Control Valve Body Channels - Oil Pump  
Side, 4T40-E Automatic Transaxle,  
Component Locator ..... 5A-48
- Control Valve Body Disassemble,  
4T40-E Automatic Transaxle,  
Unit Repair ..... 5A-244
- Control Valve Body Side, Channel  
Plate Passages, 4T40-E Automatic  
Transaxle, Component Locator ..... 5A-49



- Control Valve Install, Oil Level, 4T40-E  
Automatic Transaxle, Unit Repair ..... 5A-263
- Controls, Heating and Ventilation System ..... 7A-13
- Converter Clutch Solenoid Valve  
(TCC Sol. Valve), Torque,  
4T40-E Automatic Transaxle ..... 5A-271
- Converter, Catalytic ..... 1G-12
- Converter/Connecting Pipe, Catalytic,  
On-Vehicle Service ..... 1G-3
- Coolant Pump, Engine Cooling ..... 1D-21
- Coolant Pump, Engine Cooling,  
On-Vehicle Service ..... 1D-11
- Coolant Pump/Thermostat (DOHC),  
Engine Cooling, Component Locator ..... 1D-6
- Coolant Pump/Thermostat (SOHC),  
Engine Cooling, Component Locator ..... 1D-7
- Coolant Temperature Sensor (DOHC),  
Engine Controls, On-Vehicle Service ..... 1F-299
- Coolant Temperature Sensor (SOHC),  
Engine Controls, On-Vehicle Service ..... 1F-298
- Coolant Temperature Sensor, Engine ..... 1D-21
- Coolant Temperature Sensor,  
Engine Controls ..... 1F-315
- Coolant Temperature Sensor, Engine,  
On-Vehicle Service ..... 1D-19
- Cooler Flushing and Flow Test,  
4T40-E Automatic Transaxle, Diagnosis ..... 5A-55
- Cooler Hoses, Oil, 4T40-E Automatic  
Transaxle, On-Vehicle Service ..... 5A-166
- Cooler Line Seal Removal, Transaxle,  
4T40-E Automatic Transaxle,  
Unit Repair ..... 5A-194
- Cooler Line Seals Installation, Transaxle,  
4T40-E Automatic Transaxle,  
Unit Repair ..... 5A-197
- Cooler Pipes, Oil, 4T40-E Automatic  
Transaxle, On-Vehicle Service ..... 5A-166
- Cooling Capacity, Engine ..... 1D-1
- Cooling Fan - Auxiliary, Electric,  
On-Vehicle Service ..... 1D-14
- Cooling Fan - Main, Electric,  
On-Vehicle Service ..... 1D-12
- Cooling Fan Circuit Check - With A/C  
(1.3L and 1.5L SOHC IEFI-6), Engine,  
Engine Controls, Diagnosis ..... 1F-96
- Cooling Fan Circuit Check - With A/C  
(1.3L SOHC and 1.6L DOHC ITMS-6F),  
Engine, Engine Controls, Diagnosis ..... 1F-104
- Cooling Fan Circuit Check - Without A/C  
(1.3L and 1.5L SOHC IEFI-6), Engine,  
Engine Controls, Diagnosis ..... 1F-88
- Cooling Fan Circuit Check - Without A/C  
(1.3L SOHC and 1.6L DOHC ITMS-6F),  
Engine, Engine Controls, Diagnosis ..... 1F-92
- Cooling Fan, Electric, Engine Cooling ..... 1D-21
- Cooling System Diagnosis, Engine Cooling ..... 1D-4
- Cooling System, Draining and Refilling,  
Engine Cooling, On-Vehicle Service ..... 1D-8
- Coupling Assembly, Flange and Steering,  
Power Steering Gear, Unit Repair ..... 6C-21
- Coupling Assembly, Manual Steering Gear,  
Unit Repair ..... 6D-13
- Coupling, Flexible, Steering Wheel and  
Column, On-Vehicle Service ..... 6E-19
- Courtesy Lamp, Interior, Lighting Systems ..... 9B-52
- Courtesy Lamp, Interior, Lighting Systems,  
On-Vehicle Service ..... 9B-47
- Cover, Gearshift Lever, Five-Speed  
Manual Transaxle, On-Vehicle Service ..... 5B-34
- Cowl Vent Grille, Body Front End,  
On-Vehicle Service ..... 9R-3
- Crankshaft Bearings and Connecting  
Rod Bearings - Gauging Plastic,  
SOHC Engine Mechanical ..... 1C-92
- Crankshaft Position Sensor (Typical),  
Engine Controls, On-Vehicle Service ..... 1F-310
- Crankshaft Position Sensor,  
Engine Controls ..... 1F-313
- Crankshaft, SOHC Engine Mechanical ..... 1C-95
- Crankshaft, SOHC Engine Mechanical,  
Unit Repair ..... 1C-88
- Cross Groove Joint Seal, Manual  
Transaxle Drive Axle, Unit Repair ..... 3B-10
- Cupholder, Instrumentation/Driver  
Information, On-Vehicle Service ..... 9E-28
- Cuts Out, Misses, Engine Controls,  
Symptom Diagnosis ..... 1F-281
- Cylinder and Switch, Ignition Lock,  
Steering Wheel and Column,  
On-Vehicle Service ..... 6E-16
- Cylinder Assembly, Master,  
On-Vehicle Service ..... 4B-3
- Cylinder Assembly, Wheel, Rear Drum  
Brakes, On-Vehicle Service ..... 4E-11
- Cylinder Head and Gasket,  
SOHC Engine Mechanical ..... 1C-95
- Cylinder Head and Gasket,  
SOHC Engine Mechanical,  
On-Vehicle Service ..... 1C-13
- Cylinder Head and Valve Train Components,  
SOHC Engine Mechanical, Unit Repair ..... 1C-76
- Cylinder Lines, Hydraulic,  
Power Steering Gear, Unit Repair ..... 6C-23
- Cylinder Overhaul, Master, Unit Repair ..... 4B-8
- Cylinder to Front Head O-Ring,  
Manual Control Heating, Ventilation,  
and Air Conditioning System, Unit Repair ..... 7B-66
- Cylinder, Master ..... 4B-11

## D

- Dampener, Strut, Front Suspension,  
Diagnosis ..... 2C-4
- Dash Seal, Manual Steering Gear,  
Unit Repair ..... 6D-14

- Dash Seal, Power Steering Gear,  
   Unit Repair ..... 6C-22  
 Data Link Connector (DLC),  
   4T40-E Automatic Transaxle ..... 5A-274  
 Data Table, Scan Tool, Engine Controls,  
   Specifications ..... 1F-4  
 Deck Lid (Notchback), Rear,  
   Body Rear End ..... 9S-15  
 Deck Lid (Notchback), Rear,  
   Body Rear End, On-Vehicle Service ..... 9S-4  
 Deck Lid Remote Cable and Handle, Rear,  
   Body Rear End, On-Vehicle Service ..... 9S-6  
 Deck Lid Sill Plate Cover (Notchback),  
   Interior Trim, On-Vehicle Service ..... 9G-13  
 Definitions and Abbreviations, Transaxle,  
   4T40-E Automatic Transaxle ..... 5A-265  
 Defogger Braided Lead Wire Repair,  
   Rear Window, On-Vehicle Service ..... 9L-13  
 Defogger Grid Line Repair, Rear Window,  
   On-Vehicle Service ..... 9L-11  
 Defogger Grid Line, Testing Rear Window,  
   Diagnosis ..... 9L-3  
 Defogger Switch Assembly, A/C/  
   Manual Control Heating, Ventilation,  
   and Air Conditioning System ..... 7B-31  
 Defogger, Rear Window and Outside  
   Rearview Mirror, Schematic and  
   Routing Diagrams ..... 9L-2  
 Defrosting, Insufficient Heating or,  
   Heating and Ventilation System,  
   Diagnosis ..... 7A-4  
 Deployed Airbag Module Disposal  
   Procedure, On-Vehicle Service ..... 8B-49  
 Detection Coil, Immobilizer  
   Anti-Theft System ..... 9T-13  
 Detection Coil, Immobilizer  
   Anti-Theft System, On-Vehicle Service ..... 9T-8  
 Detent Lever, Park Lock Installation,  
   Manual Shaft, 4T40-E Automatic  
   Transaxle, Unit Repair ..... 5A-197  
 Detent Lever, Park Lock Removal,  
   Manual Shaft, 4T40-E Automatic  
   Transaxle, Unit Repair ..... 5A-193  
 Detonation/Spark Knock, Engine Controls,  
   Symptom Diagnosis ..... 1F-278  
 Diagnostic Aids, Engine Controls,  
   Diagnosis ..... 1F-26  
 Diagnostic Circuit Check,  
   Antilock Brake System ..... 4F-18  
 Diagnostic Module (SDM), Sensing and,  
   Supplemental Inflatable Restraints (SIR),  
   On-Vehicle Service ..... 8B-44  
 Diagnostic Module (SDM),  
   Sensing and, Supplemental Inflatable  
   Restraints (SIR) ..... 8B-51  
 Diagnostic System Check (1.3L and 1.5L  
   SOHC IEFI-6), Engine Controls,  
   Diagnosis ..... 1F-22  
 Diagnostic System Check (1.3L SOHC and  
   1.6L DOHC ITMS-6F), Engine Controls,  
   Diagnosis ..... 1F-24  
 Diagnostic Trouble Code (DTC) Identification,  
   4T40-E Automatic Transaxle ..... 5A-78  
 Diagnostics, Scan Tool,  
   Antilock Brake System ..... 4F-16  
 Diagram (1.3L and 1.5L SOHC - 1 of 5)  
   (IEFI-6 ECM), ECM Wiring,  
   Schematic and Routing Diagrams ..... 1F-6  
 Diagram (1.3L and 1.5L SOHC - 2 of 5)  
   (IEFI-6 ECM), ECM Wiring,  
   Schematic and Routing Diagrams ..... 1F-7  
 Diagram (1.3L and 1.5L SOHC - 3 of 5)  
   (IEFI-6 ECM), ECM Wiring,  
   Schematic and Routing Diagrams ..... 1F-8  
 Diagram (1.3L and 1.5L SOHC - 4 of 5)  
   (IEFI-6 ECM), ECM Wiring,  
   Schematic and Routing Diagrams ..... 1F-9  
 Diagram (1.3L and 1.5L SOHC - 5 of 5)  
   (IEFI-6 ECM), ECM Wiring,  
   Schematic and Routing Diagrams ..... 1F-10  
 Diagram (1.3L SOHC and 1.6L DOHC - 1 of 5)  
   (ITMS-6F ECM), ECM Wiring,  
   Schematic and Routing Diagrams ..... 1F-11  
 Diagram (1.3L SOHC and 1.6L DOHC - 2 of 5)  
   (ITMS-6F ECM), ECM Wiring,  
   Schematic and Routing Diagrams ..... 1F-12  
 Diagram (1.3L SOHC and 1.6L DOHC - 3 of 5)  
   (ITMS-6F ECM), ECM Wiring,  
   Schematic and Routing Diagrams ..... 1F-13  
 Diagram (1.3L SOHC and 1.6L DOHC - 4 of 5)  
   (ITMS-6F ECM), ECM Wiring,  
   Schematic and Routing Diagrams ..... 1F-14  
 Diagram (1.3L SOHC and 1.6L DOHC - 5 of 5)  
   (ITMS-6F ECM), ECM Wiring,  
   Schematic and Routing Diagrams ..... 1F-15  
 Dieseling, Run-On, Engine Controls,  
   Symptom Diagnosis ..... 1F-287  
 Difference Between Left and Right,  
   Wheel Alignment ..... 2B-1  
 Differential and Case, Five-Speed Manual  
   Transaxle, Component Locators ..... 5B-10  
 Differential Assembly Install,  
   Final Drive and, 4T40-E Automatic  
   Transaxle, Unit Repair ..... 5A-203  
 Differential Assembly, Final Drive and,  
   4T40-E Automatic Transaxle,  
   Component Locator ..... 5A-30  
 Differential, Five-Speed Manual Transaxle,  
   Unit Repair ..... 5B-76  
 Digital Clock, Diagnosis ..... 9E-7  
 Digital Clock, Instrumentation/Driver  
   Information ..... 9E-47  
 Digital Clock, Instrumentation/Driver  
   Information, On-Vehicle Service ..... 9E-30  
 Dimensions and Weights, Vehicle,  
   Specifications ..... 0B-6

Direct and Coast Clutch Assemblies, 4T40-E Automatic Transaxle, Component Locator .....	5A-24	Door Lock Striker, Hatchback, Body Rear End, On-Vehicle Service .....	9S-13
Direct and Coast Clutch Functional Air Checks, 4T40-E Automatic Transaxle, Unit Repair .....	5A-224	Door Lock, Childproof Rear, Doors .....	9P-40
Direct Ignition System Ignition Coil (Typical), Engine Controls, On-Vehicle Service .....	1F-311	Door Lock, Childproof Rear, Doors, On-Vehicle Service .....	9P-23
Direct Ignition System Ignition Coil, Engine Controls .....	1F-313	Door Lock, Front, Doors, On-Vehicle Service .....	9P-22
Direct/Coast Clutch and Reaction Gear Set Removal, 4T40-E Automatic Transaxle, Unit Repair .....	5A-190	Door Lock, Hatchback, Body Rear End, On-Vehicle Service .....	9S-14
Direct/Coast Clutch, Reaction Carrier Assemble, 4T40-E Automatic Transaxle, Unit Repair .....	5A-219	Door Locks (3-Door Hatchback), Power, Doors, Schematic and Routing Diagrams .....	9P-3
Direct/Coast Clutch, Reaction Carrier Disassemble, 4T40-E Automatic Transaxle, Unit Repair .....	5A-213	Door Locks (5-Door Hatchback), Power, Doors, Schematic and Routing Diagrams .....	9P-4
Direct/Coast Clutch, Reaction Carrier Install, 4T40-E Automatic Transaxle, Unit Repair .....	5A-224	Door Locks, Power, Doors .....	9P-40
Disc and Related Components, Clutch, On-Vehicle Service .....	5C-9	Door Locks, Power, Doors, Schematic and Routing Diagrams .....	9P-2
Disc Brake Caliper Assembly .....	4D-11	Door Opening Weatherstrip, Doors, On-Vehicle Service .....	9P-38
Discharging, Adding Oil, Evacuating, and Charging Procedures for A/C System .....	7B-23	Door Remote Cable and Handle, Fuel Filler, Body Rear End, On-Vehicle Service .....	9S-2
Disposal Procedure, Deployed Airbag Module, On-Vehicle Service .....	8B-49	Door Seal Trim, Doors, On-Vehicle Service .....	9P-37
DOHC Drive Pulley, Power Steering Pump, On-Vehicle Service .....	6B-6	Door Trim Panel, Front, Interior Trim, On-Vehicle Service .....	9G-3
DOHC Pump Assembly, Power Steering Pump, On-Vehicle Service .....	6B-14	Door Trim Panel, Rear, Interior Trim, On-Vehicle Service .....	9G-5
Door Escutcheon, Front, Interior Trim, On-Vehicle Service .....	9G-26	Door Weatherstrip, Doors, On-Vehicle Service .....	9P-36
Door Glass, Front, On-Vehicle Service .....	9L-13	Door, Fuel Filler, Body Rear End, On-Vehicle Service .....	9S-2
Door Glass, Rear, On-Vehicle Service .....	9L-14	Door, Hatchback, Body Rear End .....	9S-15
Door Handle, Inside, Doors, On-Vehicle Service .....	9P-26	Draining and Refilling the Cooling System, Engine Cooling, On-Vehicle Service .....	1D-8
Door Handle, Outside, Door, On-Vehicle Service .....	9P-28	Drive and Differential Assembly, Final, 4T40-E Automatic Transaxle, Component Locator .....	5A-30
Door Harness Routing, Body Wiring System, Schematic and Routing Diagrams .....	9A-15	Drive Assembly Assemble, Final, 4T40-E Automatic Transaxle, Unit Repair .....	5A-201
Door Hatchback, Body Rear End, On-Vehicle Service .....	9S-12	Drive Assembly Disassemble, Final, 4T40-E Automatic Transaxle, Unit Repair .....	5A-198
Door Hinge, Doors, On-Vehicle Service .....	9P-34	Drive Axle Assembly, Automatic Transaxle, On-Vehicle Service .....	3A-4
Door Hold Open Link, Doors, On-Vehicle Service .....	9P-34	Drive Axle Assembly, Manual Transaxle, On-Vehicle Service .....	3B-4
Door Jamb Switch, Lighting Systems, On-Vehicle Service .....	9B-46	Drive Axle Oil Seal, 4T40-E Automatic Transaxle, On-Vehicle Service .....	5A-165
Door Lock Cylinder, Door, On-Vehicle Service .....	9P-28	Drive Axle Seal, Five-Speed Manual Transaxle, On-Vehicle Service .....	5B-36
Door Lock Striker Adjustment, Doors, On-Vehicle Service .....	9P-20	Drive Axle, Front, Automatic Transaxle .....	3A-13
Door Lock Striker, Doors .....	9P-40	Drive Axle, Front, Manual Transaxle .....	3B-12
Door Lock Striker, Doors, On-Vehicle Service .....	9P-19	Drive Axle, Front, Manual Transaxle, Component Locator .....	3B-2
		Drive Belt, Pump, Power Steering Pump, On-Vehicle Service .....	6B-4
		Drive Link Assemble, Drive, Driven Sprockets and, 4T40-E Automatic Transaxle, Unit Repair .....	5A-239

Drive Link Disassemble, Drive, Driven Sprockets and, 4T40-E Automatic Transaxle, Unit Repair .....	5A-238
Drive Link Install, Drive, Driven Sprockets and, 4T40-E Automatic Transaxle, Unit Repair .....	5A-240
Drive Link Removal, Drive, Driven Sprockets, 4T40-E Automatic Transaxle, Unit Repair .....	5A-188
Drive Pinion End Play Check, Final, 4T40-E Automatic Transaxle, Unit Repair .....	5A-202
Drive Pulley, DOHC Pump, Power Steering Pump, On-Vehicle Service .....	6B-6
Drive Pulley, SOHC Pump, Power Steering Pump, On-Vehicle Service .....	6B-4
Drive Sprocket Support Assemble, 4T40-E Automatic Transaxle, Unit Repair .....	5A-235
Drive Sprocket Support Installation, 4T40-E Automatic Transaxle, Unit Repair .....	5A-196
Drive Sprocket Support Removal, 4T40-E Automatic Transaxle, Unit Repair .....	5A-194
Drive, Driven Sprockets and Drive Link Assemble, 4T40-E Automatic Transaxle, Unit Repair .....	5A-239
Drive, Driven Sprockets and Drive Link Disassemble, 4T40-E Automatic Transaxle, Unit Repair .....	5A-238
Drive, Driven Sprockets and Drive Link Install, 4T40-E Automatic Transaxle, Unit Repair .....	5A-240
Drive, Driven Sprockets, Drive Link Removal, 4T40-E Automatic Transaxle, Unit Repair .....	5A-188
Driven Members, Clutch .....	5C-24
Driven Sprocket Assembly Disassemble, 4T40-E Automatic Transaxle, Unit Repair .....	5A-232
Driven Sprocket Support Assembly Installation, 4T40-E Automatic Transaxle, Unit Repair .....	5A-236
Driven Sprocket Support Assembly Removal, 4T40-E Automatic Transaxle, Unit Repair .....	5A-189
Driven Sprocket Support Assembly/Second Clutch, 4T40-E Automatic Transaxle, Component Locator .....	5A-22
Driven Sprockets and Drive Link Assemble, Drive, 4T40-E Automatic Transaxle, Unit Repair .....	5A-239
Driven Sprockets and Drive Link Disassemble, Drive, 4T40-E Automatic Transaxle, Unit Repair .....	5A-238
Driven Sprockets and Drive Link Install, Drive, 4T40-E Automatic Transaxle, Unit Repair .....	5A-240
Driven Sprockets, Drive Link Removal, Drive, 4T40-E Automatic Transaxle, Unit Repair .....	5A-188
Driver Airbag Module, On-Vehicle Service .....	8B-40
Driver Seat Belt Warning .....	8A-20
Driver Seat Belt Warning, Schematic and Routing Diagrams .....	8A-2
Drives Axles, Front, Automatic Transaxle, Component Locator .....	3A-2
Drives in Neutral, 4T40-E Automatic Transaxle, Symptom Diagnosis .....	5A-74
Driving Members, Clutch .....	5C-24
Drum Brakes .....	4E-16
Drum, One-Piece, Rear Drum Brakes .....	4E-4
Drum, Two-Piece, Rear Drum Brakes .....	4E-5
Drums, Rear Drum Brakes, Diagnosis .....	4E-1
DTC 01 Driver Firing Circuit, Resistance Too High, SIR .....	8B-10
DTC 01 TCMPWM Low (1.3L SOHC and 1.6L DOHC ITMS-6F), Engine Controls, Diagnosis .....	1F-112
DTC 02 Driver Firing Circuit, Resistance Too Low, SIR .....	8B-12
DTC 02 TCMPWM High (1.3L SOHC and 1.6L DOHC ITMS-6F), Engine Controls, Diagnosis .....	1F-114
DTC 03 Driver Firing Circuit, Short To Ground, SIR .....	8B-14
DTC 03 Fan Number Two Low (1.3L SOHC and 1.6L DOHC ITMS-6F), Engine Controls, Diagnosis .....	1F-116
DTC 04 Driver Firing Circuit, Short To Battery Voltage, SIR .....	8B-16
DTC 04 Fan Number Two High (1.3L SOHC and 1.6L DOHC ITMS-6F), Engine Controls, Diagnosis .....	1F-120
DTC 05 Fan Number One Low (1.3L SOHC and 1.6L DOHC ITMS-6F), Engine Controls, Diagnosis .....	1F-122
DTC 05 Passenger Firing Circuit, Resistance Too High, SIR .....	8B-18
DTC 06 Fan Number One High (1.3L SOHC and 1.6L DOHC ITMS-6F), Engine Controls, Diagnosis .....	1F-124
DTC 06 Passenger Firing Circuit, Resistance Too Low, SIR .....	8B-20
DTC 07 EGR On/Off Solenoid Low (1.3L SOHC and 1.6L DOHC ITMS-6F), Engine Controls, Diagnosis .....	1F-126
DTC 07 Passenger Firing Circuit, Short To Ground, SIR .....	8B-22
DTC 08 EGR On/Off Solenoid High (1.3L SOHC and 1.6L DOHC ITMS-6F), Engine Controls, Diagnosis .....	1F-128
DTC 08 Passenger Firing Circuit, Short to Battery Voltage, SIR .....	8B-24
DTC 12 No Pulse Reference, Engine Controls, Diagnosis .....	1F-130

DTC 13 Oxygen Sensor Not Toggling (1.3L and 1.5L SOHC IEFI-6), Engine Controls, Diagnosis .....	1F-132	DTC 24 Vehicle Speed Sensor Error - Automatic Transaxle (1.3L SOHC and 1.6L DOHC ITMS-6F), Engine Controls, Diagnosis .....	1F-186
DTC 13 Oxygen Sensor Not Toggling (1.3L SOHC and 1.6L DOHC ITMS-6F), Engine Controls, Diagnosis .....	1F-136	DTC 24 Vehicle Speed Sensor Error - Manual Transaxle (1.3L and 1.5L SOHC IEFI-6), Engine Controls, Diagnosis .....	1F-180
DTC 14 Coolant Temperature High (1.3L and 1.5L SOHC IEFI-6), Engine Controls, Diagnosis .....	1F-140	DTC 24 Vehicle Speed Sensor Error - Manual Transaxle (1.3L SOHC and 1.6L DOHC ITMS-6F), Engine Controls, Diagnosis .....	1F-182
DTC 14 Coolant Temperature High (1.3L SOHC and 1.6L DOHC ITMS-6F), Engine Controls, Diagnosis .....	1F-144	DTC 25 Manifold Air Temperature Low (1.3L and 1.5L SOHC IEFI-6), Engine Controls, Diagnosis .....	1F-188
DTC 15 Coolant Temperature Low (1.3L and 1.5L SOHC IEFI-6), Engine Controls, Diagnosis .....	1F-148	DTC 25 Manifold Air Temperature Low (1.3L SOHC and 1.6L DOHC ITMS-6F), Engine Controls, Diagnosis .....	1F-190
DTC 15 Coolant Temperature Low (1.3L SOHC and 1.6L DOHC ITMS-6F), Engine Controls, Diagnosis .....	1F-152	DTC 25 Warning Lamp Failure, SIR .....	8B-30
DTC 16 Knock Sensor Failure (1.3L SOHC and 1.6L DOHC ITMS-6F), Engine Controls, Diagnosis .....	1F-156	DTC 27 Air Conditioning Pressure Sensor High Error (1.3L and 1.5L SOHC IEFI-6), Engine Controls, Diagnosis .....	1F-192
DTC 17 Injector Shorted to Ground/Battery (1.3L SOHC and 1.6L DOHC ITMS-6F), Engine Controls, Diagnosis .....	1F-158	DTC 27 Air Conditioning Pressure Sensor High Error (1.3L SOHC and 1.6L DOHC ITMS-6F), Engine Controls, Diagnosis .....	1F-194
DTC 18 DSNEF Control Error Failure (1.3L SOHC and 1.6L DOHC ITMS-6F), Engine Controls, Diagnosis .....	1F-162	DTC 29 Fuel Pump Relay Shorted to Ground (1.3L SOHC and 1.6L DOHC ITMS-6F), Diagnosis, Engine Controls .....	1F-196
DTC 19 58X Signal Error (A and B) (1.3L and 1.5L SOHC IEFI-6), Engine Controls, Diagnosis .....	1F-164	DTC 31 SDM Internal Fault, SIR .....	8B-33
DTC 19 58X Signal Error (A and B) (1.3L SOHC and 1.6L DOHC ITMS-6F), Engine Controls, Diagnosis .....	1F-166	DTC 32 Fuel Pump Relay Shorted to Battery (1.3L SOHC and 1.6L DOHC ITMS-6F), Engine Controls, Diagnosis .....	1F-198
DTC 21 Throttle Position Sensor High (1.3L and 1.5L SOHC IEFI-6), Engine Controls, Diagnosis .....	1F-168	DTC 32 SDM Crash Recorded, SIR .....	8B-33
DTC 21 Throttle Position Sensor High (1.3L SOHC and 1.6L DOHC ITMS-6F), Engine Controls, Diagnosis .....	1F-168	DTC 33 Manifold Absolute Pressure Sensor High (1.3L and 1.5L SOHC IEFI-6), Engine Controls, Diagnosis .....	1F-200
DTC 22 Throttle Position Sensor Low (1.3L and 1.5L SOHC IEFI-6), Engine Controls, Diagnosis .....	1F-172	DTC 33 Manifold Absolute Pressure Sensor High (1.3L SOHC and 1.6L DOHC ITMS-6F), Engine Controls, Diagnosis .....	1F-204
DTC 22 Throttle Position Sensor Low (1.3L SOHC and 1.6L DOHC ITMS-6F), Engine Controls, Diagnosis .....	1F-174	DTC 34 Manifold Absolute Pressure Sensor Low (1.3L and 1.5L SOHC IEFI-6), Engine Controls, Diagnosis .....	1F-208
DTC 23 Ignition Input Circuit, Voltage Too High, SIR .....	8B-26	DTC 34 Manifold Absolute Pressure Sensor Low (1.3L SOHC and 1.6L DOHC ITMS-6F), Engine Controls, Diagnosis .....	1F-212
DTC 23 Manifold Air Temperature High (1.3L and 1.5L SOHC IEFI-6), Engine Controls, Diagnosis .....	1F-176	DTC 35 Idle Air Control Error (1.3L and 1.5L SOHC IEFI-6), Engine Controls, Diagnosis .....	1F-216
DTC 23 Manifold Air Temperature High (1.3L SOHC and 1.6L DOHC ITMS-6F), Engine Controls, Diagnosis .....	1F-178	DTC 35 Idle Air Control Error (1.3L SOHC and 1.6L DOHC ITMS-6F), Engine Controls, Diagnosis .....	1F-220
DTC 24 Ignition Input Circuit, Voltage Too Low, SIR .....	8B-28	DTC 36 Exhaust Gas Recirculation Error (1.3L and 1.5L SOHC IEFI-6), Engine Controls, Diagnosis .....	1F-224
DTC 24 Vehicle Speed Sensor Error - Automatic Transaxle (1.3L and 1.5L SOHC IEFI-6), Engine Controls, Diagnosis .....	1F-184	DTC 41 Electronic Spark Timing "B" Shorted to Battery (1.3L and 1.5L SOHC IEFI-6), Diagnosis, Engine Controls .....	1F-226

DTC 41 Electronic Spark Timing "B" Shorted to Battery (1.3L SOHC and 1.6L DOHC ITMS-6F), Engine Controls, Diagnosis . . . . .	1F-228	DTC 64 Electronic Spark Timing "A" Shorted to Ground (1.3L and 1.5L SOHC IEFI-6), Engine Controls, Diagnosis . . . . .	1F-260
DTC 42 Electronic Spark Timing "A" Shorted to Battery (1.3L and 1.5L SOHC IEFI-6), Diagnosis, Engine Controls . . . . .	1F-230	DTC 64 Electronic Spark Timing "A" Shorted to Ground (1.3L SOHC and 1.6L DOHC ITMS-6F), Engine Controls, Diagnosis . . . . .	1F-262
DTC 42 Electronic Spark Timing "A" Shorted to Battery (1.3L SOHC and 1.6L DOHC ITMS-6F), Engine Controls, Diagnosis . . . . .	1F-232	DTC 87 A/C Cut Shorted to Ground (1.3L SOHC and 1.6L DOHC ITMS-6F), Engine Controls, Diagnosis . . . . .	1F-264
DTC 44 Oxygen Sensor Lean (1.3L and 1.5L SOHC IEFI-6), Engine Controls, Diagnosis . . . . .	1F-234	DTC 88 A/C Cut Shorted to Battery (1.3L SOHC and 1.6L DOHC ITMS-6F), Engine Controls, Diagnosis . . . . .	1F-266
DTC 44 Oxygen Sensor Lean (1.3L SOHC and 1.6L DOHC ITMS-6F), Engine Controls, Diagnosis . . . . .	1F-236	DTC 93 QDM Failure (1.3L SOHC and 1.6L DOHC ITMS-6F), Engine Controls, Diagnosis . . . . .	1F-268
DTC 45 Oxygen Sensor Rich (1.3L and 1.5L SOHC IEFI-6), Engine Controls, Diagnosis . . . . .	1F-238	DTC A014 ABS Enable Relay Contact Circuit Open . . . . .	4F-20
DTC 45 Oxygen Sensor Rich (1.3L SOHC and 1.6L DOHC ITMS-6F), Engine Controls, Diagnosis . . . . .	1F-240	DTC A015 ABS Enable Relay Circuit Shorted to Battery or Always Closed . . . . .	4F-26
DTC 49 Battery Voltage Too High (1.3L SOHC and 1.6L DOHC ITMS-6F), Engine Controls, Diagnosis . . . . .	1F-242	DTC A016 ABS Enable Relay Coil Circuit Open . . . . .	4F-28
DTC 51 ECM Error (Checksum or KKPGMID Error) (1.3L and 1.5L SOHC IEFI-6) (1.3L SOHC and 1.6L DOHC ITMS-6F), Engine Controls, Diagnosis . . . . .	1F-243	DTC A017 ABS Enable Relay Coil Circuit Shorted to Ground . . . . .	4F-32
DTC 53 ECM Immobilized Error (1.3L and 1.5L SOHC IEFI-6) (1.3L SOHC and 1.6L DOHC ITMS-6F), Engine Controls, Diagnosis . . . . .	1F-244	DTC A018 ABS Enable Relay Coil Circuit Shorted to Battery . . . . .	4F-34
DTC 53 ECM Immobilized Error, Immobilizer Anti-Theft System, Diagnosis . . . . .	9T-4	DTC A021 Left Front Wheel Speed = 0 . . . . .	4F-36
DTC 54 CO Adjust Error (1.3L and 1.5L SOHC IEFI-6), Engine Controls, Diagnosis . . . . .	1F-246	DTC A022 Right Front Wheel Speed = 0 . . . . .	4F-40
DTC 54 CO Adjust Error (1.3L SOHC and 1.6L DOHC ITMS-6F), Engine Controls, Diagnosis . . . . .	1F-248	DTC A023 Left Rear Wheel Speed = 0 . . . . .	4F-44
DTC 55 EEPROM or Config Reg Error (1.3L SOHC and 1.6L DOHC ITMS-6F), Engine Controls, Diagnosis . . . . .	1F-250	DTC A024 Right Rear Wheel Speed = 0 . . . . .	4F-50
DTC 61 Controlled Canister Purge Solenoid Shorted to Ground (1.3L SOHC and 1.6L DOHC ITMS-6F), Engine Controls, Diagnosis . . . . .	1F-252	DTC A025 Left Front Excessive Wheel Speed Variation . . . . .	4F-56
DTC 62 Controlled Canister Purge Solenoid Shorted to Battery (1.3L SOHC and 1.6L DOHC ITMS-6F), Engine Controls, Diagnosis . . . . .	1F-254	DTC A026 Right Front Excessive Wheel Speed Variation . . . . .	4F-60
DTC 63 Electronic Spark Timing "B" Shorted to Ground (1.3L and 1.5L SOHC IEFI-6), Engine Controls, Diagnosis . . . . .	1F-256	DTC A027 Left Rear Excessive Wheel Speed Variation . . . . .	4F-64
DTC 63 Electronic Spark Timing "B" Shorted to Ground (1.3L SOHC and 1.6L DOHC ITMS-6F), Engine Controls, Diagnosis . . . . .	1F-258	DTC A028 Right Rear Excessive Wheel Speed Variation . . . . .	4F-70
		DTC A032 Left Front Speed Sensor Circuit Open or Shorted to Ground or Battery . . . . .	4F-76
		DTC A033 Right Front Speed Sensor Circuit Open or Shorted to Ground or Battery . . . . .	4F-80
		DTC A034 Left Rear Speed Sensor Circuit Open or Shorted to Ground or Battery . . . . .	4F-84
		DTC A035 Right Rear Speed Sensor Circuit Open or Shorted to Ground or Battery . . . . .	4F-88
		DTC A036 Low System Voltage . . . . .	4F-92
		DTC A037 High System Voltage . . . . .	4F-96
		DTC A038 Left Front ESB Will Not Hold Motor . . . . .	4F-98
		DTC A041 Right Front ESB Will Not Hold Motor . . . . .	4F-100
		DTC A042 Rear Axle ESB Will Not Hold Motor . . . . .	4F-102
		DTC A044 Left Front Channel Will Not Move . . . . .	4F-104
		DTC A045 Right Front Channel Will Not Move . . . . .	4F-108

DTC A046 Rear Axle Channel		
Will Not Move	4F-112	
DTC A047 Left Front Motor Free Spins	4F-116	
DTC A048 Right Front Motor Free Spins	4F-120	
DTC A051 Rear Motor Free Spins	4F-124	
DTC A052 Left Front Channel In Release		
Too Long	4F-128	
DTC A053 Right Front Channel In Release		
Too Long	4F-132	
DTC A054 Rear Channel In Release		
Too Long	4F-136	
DTC A055 EBCM Malfunction	4F-138	
DTC A056 Left Front Motor Circuit Open	4F-140	
DTC A057 Left Front Motor Circuit		
Shorted to Ground	4F-142	
DTC A058 Left Front Motor Circuit		
Shorted to Battery or Motor Shorted	4F-144	
DTC A061 Right Front Motor Circuit Open	4F-146	
DTC A062 Right Front Motor Circuit		
Shorted to Ground	4F-148	
DTC A063 Right Front Motor Circuit		
Shorted to Battery or Motor Shorted	4F-150	
DTC A064 Rear Axle Motor Circuit Open	4F-152	
DTC A065 Rear Axle Motor Circuit		
Shorted to Ground	4F-154	
DTC A066 Rear Axle Motor Circuit		
Shorted to Battery or Motor Shorted	4F-156	
DTC A076 Left Front Solenoid Circuit		
Open or Shorted to Ground	4F-158	
DTC A077 Left Front Solenoid Circuit		
Shorted to Battery	4F-160	
DTC A078 Right Front Solenoid Circuit		
Open or Shorted to Ground	4F-162	
DTC A081 Right Front Solenoid Circuit		
Shorted to Battery	4F-164	
DTC A082 Calibration Malfunction	4F-166	
DTC A086 EBCM Turned on the Red		
Brake Warning Lamp	4F-167	
DTC A087 Red Brake Warning Lamp		
Circuit Open or Short to Battery	4F-168	
DTC A091 Open Stoplamp Switch		
During Deceleration	4F-172	
DTC A092 Open Stoplamp Switch		
When ABS Was Required	4F-176	
DTC A093 Code A091 or A092 Set in		
Current or Previous Ignition Cycle	4F-180	
DTC A094 Stoplamp Switch Contacts		
Always Closed	4F-182	
DTC A095 Stoplamp Switch Circuit Open	4F-184	
DTC P0218 Transaxle Fluid Overtemperature,		
4T40-E Automatic Transaxle	5A-80	
DTC P0711 Transmission Fluid Temperature		
Sensor Circuit Range/Performance,		
4T40-E Automatic Transaxle	5A-82	
DTC P0712 Transmission Fluid		
Temperature Sensor Circuit Low Input,		
4T40-E Automatic Transaxle	5A-86	
DTC P0713 Transmission Fluid		
Temperature Sensor Circuit High Input,		
4T40-E Automatic Transaxle	5A-88	
DTC P0716 Automatic Transmission Input		
Speed Sensor Circuit Range/Performance,		
4T40-E Automatic Transaxle	5A-90	
DTC P0717 Automatic Transmission Input		
Speed Sensor Circuit No Signal,		
4T40-E Automatic Transaxle	5A-92	
DTC P0719 Brake Switch Circuit Low,		
4T40-E Automatic Transaxle	5A-94	
DTC P0722 Automatic Transmission Output		
Speed Sensor (A/T OSS) Low Input,		
4T40-E Automatic Transaxle	5A-96	
DTC P0723 Automatic Transmission Output		
Speed Sensor (A/T OSS Intermittent,		
4T40-E Automatic Transaxle	5A-98	
DTC P0724 Brake Switch Circuit High,		
4T40-E Automatic Transaxle	5A-100	
DTC P0726 Engine Speed Sensor		
Circuit Intermittent,		
4T40-E Automatic Transaxle	5A-102	
DTC P0727 Engine Speed Sensor		
Circuit Low Input,		
4T40-E Automatic Transaxle	5A-104	
DTC P0730 Incorrect Gear Ratio,		
4T40-E Automatic Transaxle	5A-106	
DTC P0741 TCC Circuit Stuck Off,		
4T40-E Automatic Transaxle	5A-108	
DTC P0742 TCC Circuit Stock On,		
4T40-E Automatic Transaxle	5A-112	
DTC P0748 PC Solenoid		
Circuit Electrical, 4T40-E		
Automatic Transaxle	5A-116	
DTC P0751 1-2 Shift Solenoid		
Performance, 4T40-E		
Automatic Transaxle	5A-120	
DTC P0756 2-3 Shift Solenoid		
Performance, 4T40-E		
Automatic Transaxle	5A-124	
DTC P1790 TCM Checksum Error,		
4T40-E Automatic Transaxle	5A-128	
DTC P1810 Automatic Transmission Fluid		
Pressure Manual Valve Position Switch		
(TFP Val. Position Sw.) Malfunction,		
4T40-E Automatic Transaxle	5A-130	
DTC P1811 Maximum Adapt and Long		
Shift, 4T40-E Automatic Transaxle	5A-134	
DTC P1814 Torque Converter Overstress,		
4T40-E Automatic Transaxle	5A-138	
DTC P1887 TCC Release Switch		
Circuit Malfunction,		
4T40-E Automatic Transaxle	5A-140	
DTCs, Clearing, Antilock Brake System	4F-16	
DTCs, Displaying, Antilock Brake System	4F-16	
Dual Horns, On-Vehicle Service	9C-3	

## E

- Each Time the Oil is Changed,  
Owner Inspections and Services ..... 0B-14
- EBCM Connector Face View (1 of 2),  
Antilock Brake System ..... 4F-8
- EBCM Connector Face View (2 of 2),  
Antilock Brake System ..... 4F-9
- ECM Wiring Diagram (1.3L and 1.5 L  
SOHC - 1 of 5) (IEFI-6 ECM),  
Schematic and Routing Diagrams ..... 1F-6
- ECM Wiring Diagram (1.3L and 1.5 L  
SOHC - 2 of 5) (IEFI-6 ECM),  
Schematic and Routing Diagrams ..... 1F-7
- ECM Wiring Diagram (1.3L and 1.5 L  
SOHC - 3 of 5) (IEFI-6 ECM),  
Schematic and Routing Diagrams ..... 1F-8
- ECM Wiring Diagram (1.3L and 1.5 L  
SOHC - 4 of 5) (IEFI-6 ECM),  
Schematic and Routing Diagrams ..... 1F-9
- ECM Wiring Diagram (1.3L and 1.5 L  
SOHC - 5 of 5) (IEFI-6 ECM),  
Schematic and Routing Diagrams ..... 1F-10
- ECM Wiring Diagram (1.3L SOHC and  
1.6L DOHC - 1 of 5) (ITMS-6F ECM),  
Schematic and Routing Diagrams ..... 1F-11
- ECM Wiring Diagram (1.3L SOHC and  
1.6L DOHC - 2 of 5) (ITMS-6F ECM),  
Schematic and Routing Diagrams ..... 1F-12
- ECM Wiring Diagram (1.3L SOHC and  
1.6L DOHC - 3 of 5) (ITMS-6F ECM),  
Schematic and Routing Diagrams ..... 1F-13
- ECM Wiring Diagram (1.3L SOHC and  
1.6L DOHC - 4 of 5) (ITMS-6F ECM),  
Schematic and Routing Diagrams ..... 1F-14
- ECM Wiring Diagram (1.3L SOHC and  
1.6L DOHC - 5 of 5) (ITMS-6F ECM),  
Schematic and Routing Diagrams ..... 1F-15
- Electric Control Outside Rearview Mirrors,  
Diagnosis ..... 9L-4
- Electric Control Outside Rearview Mirrors,  
Schematic and Routing Diagrams ..... 9L-3
- Electric Cooling Fan - Auxiliary,  
On-Vehicle Service ..... 1D-14
- Electric Cooling Fan - Main,  
On-Vehicle Service ..... 1D-12
- Electric Cooling Fan, Engine Cooling ..... 1D-21
- Electrical Connector, Transmission,  
4T40-E Automatic Transaxle ..... 5A-273
- Electrical/Garage Shift Tests,  
4T40-E Automatic Transaxle, Diagnosis ..... 5A-57
- Electronic Brake Control Module (EBCM) ..... 4F-212
- Electronic Brake Control Module (EBCM),  
Antilock Brake System,  
On-Vehicle Service ..... 4F-196
- Electronic Component Location Views,  
4T40-E Automatic Transaxle,  
Component Locator ..... 5A-46
- Electronic Control Module (Typical),  
Engine Controls, On-Vehicle Service ..... 1F-311
- Electronic Control Module, Engine Controls ..... 1F-317
- Electronic Control Module,  
Immobilizer Anti-Theft System ..... 9T-13
- Electronically Coded Keys,  
Immobilizer Anti-Theft System ..... 9T-13
- Emblems and Lettering, Exterior Trim ..... 9M-4
- Emission Canister, Evaporative,  
Engine Controls ..... 1F-314
- Emission Canister, Evaporative,  
On-Vehicle Service ..... 1F-309
- Emission Control System Operation,  
Evaporative, Engine Controls ..... 1F-314
- Emmissions or Odors, Excessive Exhaust,  
Engine Controls, Symptom Diagnosis ..... 1F-286
- Enable Relay, ABS ..... 4F-213
- Enable Relay, ABS, On-Vehicle Service ..... 4F-202
- End Play Specifications,  
4T40-E Automatic Transaxle ..... 5A-5
- End View, Connector, Engine Controls,  
Schematic and Routing Diagrams ..... 1F-16
- Energy Absorber, Front Bumper,  
On-Vehicle Service ..... 9O-4
- Energy Absorber, Rear Bumper,  
On-Vehicle Service ..... 9O-9
- Engine Block Heater, Engine Cooling ..... 1D-21
- Engine Controls, Specifications ..... 1F-4
- Engine Coolant in Transaxle,  
4T40-E Automatic Transaxle, Diagnosis ..... 5A-54
- Engine Coolant Temperature Sensor ..... 1D-21
- Engine Coolant Temperature Sensor,  
On-Vehicle Service ..... 1D-19
- Engine Cooling Capacity ..... 1D-1
- Engine Cooling Fan Circuit Check -  
With A/C (1.3L and 1.5L SOHC IEFI-6),  
Engine Controls, Diagnosis ..... 1F-96
- Engine Cooling Fan Circuit Check - With A/C  
(1.3L SOHC and 1.6L DOHC ITMS-6F),  
Diagnosis, Engine Controls ..... 1F-104
- Engine Cooling Fan Circuit Check -  
Without A/C (1.3L and 1.5L SOHC IEFI-6),  
Engine Controls, Diagnosis ..... 1F-88
- Engine Cooling Fan Circuit Check -  
Without A/C (1.3L SOHC and 1.6L DOHC  
ITMS-6F), Engine Controls, Diagnosis ..... 1F-92
- Engine Cranks But Will Not Start  
(1.3L and 1.5L SOHC IEFI-6),  
Engine Controls, Diagnosis ..... 1F-27
- Engine Cranks But Will Not Start  
(1.3L SOHC and 1.6L DOHC ITMS-6F),  
Engine Controls, Diagnosis ..... 1F-33
- Engine Mount, SOHC Engine Mechanical,  
On-Vehicle Service ..... 1C-49
- Engine Specifications,  
SOHC Engine Mechanical ..... 1C-2
- Engine Stall, Symptom 4T40-E  
Automatic Transaxle, Diagnosis ..... 5A-71



Engine Under Covers, Frame and Underbody . . . .	9N-7
Engine Under Covers, Frame and Underbody, On-Vehicle Service . . . . .	9N-6
Engine, SOHC Engine Mechanical, On-Vehicle Service . . . . .	1C-60
Evaporative Emission Canister, Engine Controls . . . . .	1F-314
Evaporative Emission Canister, On-Vehicle Service . . . . .	1F-309
Evaporative Emission Control System Operation, Engine Controls . . . . .	1F-314
Evaporator Core, Manual Control Heating, Ventilation, and Air Conditioning System . . . .	7B-43
Excessive Exhaust Emissions or Odors, Engine Controls, Symptom Diagnosis . . . . .	1F-286
Excessive Friction Check, Front Suspension, Diagnosis . . . . .	2C-5
Excessive Friction Check, Rear Suspension, Diagnosis . . . . .	2D-2
Exhaust Emissions or Odors, Excessive, Engine Controls, Symptom Diagnosis . . . . .	1F-286
Exhaust Gas Recirculation Valve (DOHC), Engine Controls, On-Vehicle Service . . . . .	1F-306
Exhaust Gas Recirculation Valve (SOHC), Engine Controls, On-Vehicle Service . . . . .	1F-306
Exhaust Gas Recirculation Valve Solenoid (Typical), Engine Controls, On-Vehicle Service . . . . .	1F-307
Exhaust Gas Recirculation Valve, Engine Controls . . . . .	1F-315
Exhaust Gas Recirculation Valve, SOHC Engine Mechanical . . . . .	1C-95
Exhaust Manifold, SOHC Engine Mechanical . . . . .	1C-95
Exhaust Manifold, SOHC Engine Mechanical, On-Vehicle Service . . . . .	1C-57
Exhaust Pipe, On-Vehicle Service . . . . .	1G-9
Exhaust System . . . . .	1G-12
Exhaust System, Component Locator . . . . .	1G-2
Explanation of Scheduled Maintenance Services . . . . .	0B-9

## F

Fan - Auxiliary, Electric Cooling, On-Vehicle Service . . . . .	1D-14
Fan - Main, Electric Cooling, On-Vehicle Service . . . . .	1D-12
Fan, Electric Cooling, Engine Cooling . . . . .	1D-21
Fan/Radiator, Engine Cooling, Component Locator . . . . .	1D-5
Fascia, Front Bumper, On-Vehicle Service . . . . .	9O-2
Fascia, Rear Bumper, On-Vehicle Service . . . . .	9O-5
Fasteners, Body Front End, On-Vehicle Service . . . . .	9R-2
Fault Codes, Clearing, Supplemental Inflatable Restraints (SIR), Diagnosis . . . . .	8B-5
Fault Codes, Supplemental Inflatable Restraints (SIR), Diagnosis . . . . .	8B-9
Fault Indication, Supplemental Inflatable Restraints (SIR), Diagnosis . . . . .	8B-5
Feed Pipes Assemble, Oil, 4T40-E Automatic Transaxle, Unit Repair . . . . .	5A-261
Fender, Body Front End, On-Vehicle Service . . . . .	9R-10
Filter Assembly and Seal Install, 4T40-E Automatic Transaxle, Unit Repair . . . . .	5A-262
Filter, Fuel, Engine Controls, On-Vehicle Service . . . . .	1F-292
Filter, Pan, Gasket and, 4T40-E Automatic Transaxle, On-Vehicle Service . . . . .	5A-158
Final Drive and Differential Assembly Install, 4T40-E Automatic Transaxle, Unit Repair . . . . .	5A-203
Final Drive and Differential Assembly, 4T40-E Automatic Transaxle, Component Locator . . . . .	5A-30
Final Drive Assembly Assemble, 4T40-E Automatic Transaxle, Unit Repair . . . . .	5A-201
Final Drive Assembly Disassemble, 4T40-E Automatic Transaxle, Unit Repair . . . . .	5A-198
Final Drive Assembly Removal, Output Shaft and, 4T40-E Automatic Transaxle, Unit Repair . . . . .	5A-193
Final Drive Internal Gear Install, Fretting Ring, 4T40-E Automatic Transaxle, Unit Repair . . . . .	5A-203
Final Drive Internal Gear Removal, 4T40-E Automatic Transaxle, Unit Repair . . . . .	5A-193
Final Drive Pinion End Play Check, 4T40-E Automatic Transaxle, Unit Repair . . . . .	5A-202
Fire Extinguisher, Body Rear End . . . . .	9S-15
First and Fourth Gears Only, 4T40-E Automatic Transaxle, Symptom Diagnosis . . . . .	5A-72
First and Second Gears Only, 4T40-E Automatic Transaxle, Symptom Diagnosis . . . . .	5A-71
First Gear, Manual First, 4T40-E Automatic Transaxle . . . . .	5A-296
First Gear, Overdrive Range, 4T40-E Automatic Transaxle . . . . .	5A-282
Five-Speed Manual Transaxle . . . . .	5B-93
Flange and Steering Coupling Assembly, Power Steering Gear, Unit Repair . . . . .	6C-21
Flexible Coupling, Steering Wheel and Column, On-Vehicle Service . . . . .	6E-19
Flexplate/Torque Converter Vibration Test Procedure, 4T40-E Automatic Transaxle, Diagnosis . . . . .	5A-60

- Floor Carpet, Interior Trim ..... 9G-30  
 Floor Carpet, Interior Trim,  
     On-Vehicle Service ..... 9G-17  
 Floor Console, Interior Trim ..... 9G-30  
 Floor Console, Interior Trim,  
     On-Vehicle Service ..... 9G-19  
 Floor Harness Routing, Body Wiring System,  
     Schematic and Routing Diagrams ..... 9A-12  
 Floor Pan Insulators, Frame and Underbody,  
     On-Vehicle Service ..... 9N-5  
 Flow Test, Cooler Flushing and,  
     4T40-E Automatic Transaxle, Diagnosis ..... 5A-55  
 Fluid Capacity, Specifications,  
     4T40-E Automatic Transaxle ..... 5A-5  
 Fluid Foaming, 4T40-E Automatic  
     Transaxle, Symptom Diagnosis ..... 5A-74  
 Fluid Leak Diagnosis and Repair,  
     4T40-E Automatic Transaxle, Diagnosis ..... 5A-55  
 Fluid Leaks, Repairing, 4T40-E Automatic  
     Transaxle, On-Vehicle Service ..... 5A-144  
 Fluid Leaks, 4T40-E Automatic  
     Transaxle, Symptom Diagnosis ..... 5A-74  
 Fluid Level Checking Procedure,  
     Transaxle, 4T40-E Automatic Transaxle,  
         On-Vehicle Service ..... 5A-143  
 Fluid Level Sensor, Master Cylinder ..... 4B-11  
 Fluid Level Set After Service,  
     4T40-E Automatic Transaxle,  
         On-Vehicle Service ..... 5A-146  
 Fluid Level Switch, Brake,  
     Antilock Brake System ..... 4F-213  
 Fluid Level, Checking, Five-Speed  
     Manual Transaxle, On-Vehicle Service ..... 5B-14  
 Fluid Pressure Manual Valve Position  
     Switch Resistance Check,  
     Automatic Transmission,  
     4T40-E Automatic Transaxle, Diagnosis ..... 5A-64  
 Fluid Lever Service Procedure,  
     4T40-E Automatic Transaxle, Diagnosis ..... 5A-56  
 Fluid Reservoir, Power Steering System ..... 6A-4  
 Fluid, Changing, 4T40-E Automatic  
     Transaxle, On-Vehicle Service ..... 5A-144  
 Fluid, Checking and Adding,  
     Power Steering System ..... 6A-3  
 Fluids and Lubricants, Recommended,  
     Owner Inspections and Services ..... 0B-15  
 Flushing, Oil Cooler, 4T40-E Automatic  
     Transaxle, On-Vehicle Service ..... 5A-146  
 Fog Lamps Circuit (Without Rear Fog Lamps),  
     Front, Lighting Systems,  
         Schematic and Routing Diagrams ..... 9B-6  
 Fog Lamps Circuit (Without Rear Fog Lamps),  
     Rear, Lighting Systems,  
         Schematic and Routing Diagrams ..... 9B-7  
 Fog Lamps Circuit, Front and Rear,  
     Lighting Systems, Schematic and  
         Routing Diagrams ..... 9B-5  
 Fog Lamps, Front, Lighting Systems,  
     On-Vehicle Service ..... 9B-43  
 Fog Lamps, Lighting Systems ..... 9B-52  
 Fog Lamps, Lighting Systems, Diagnosis ..... 9B-32  
 Fog/Backup Lamps (Hatchback), Rear,  
     Lighting Systems, On-Vehicle Service ..... 9B-41  
 Fog/Backup Lamps (Notchback), Rear,  
     Lighting Systems, On-Vehicle Service ..... 9B-40  
 Forward Clutch and Low/Reverse Band  
     Removal, 4T40-E Automatic Transaxle,  
         Unit Repair ..... 5A-191  
 Forward Clutch Assemble,  
     4T40-E Automatic Transaxle,  
         Unit Repair ..... 5A-208  
 Forward Clutch Assembly,  
     4T40-E Automatic Transaxle,  
         Component Locator ..... 5A-28  
 Forward Clutch Disassemble,  
     4T40-E Automatic Transaxle,  
         Unit Repair ..... 5A-206  
 Forward Clutch Functional Air Check,  
     4T40-E Automatic Transaxle,  
         Unit Repair ..... 5A-209  
 Forward Clutch Hub Assemble, Input  
     Internal Gear, 4T40-E Automatic  
         Transaxle, Unit Repair ..... 5A-211  
 Forward Clutch Hub Disassemble, Input  
     Internal Gear, 4T40-E Automatic  
         Transaxle, Unit Repair ..... 5A-211  
 Forward Clutch Hub Install, Input  
     Internal Gear, 4T40-E Automatic  
         Transaxle, Unit Repair ..... 5A-212  
 Forward Clutch Hub Removal, Input  
     Internal Gear, 4T40-E Automatic  
         Transaxle, Unit Repair ..... 5A-191  
 Forward Clutch Installation,  
     4T40-E Automatic Transaxle,  
         Unit Repair ..... 5A-210  
 Forward Clutch Support Assembly,  
     4T40-E Automatic Transaxle,  
         Component Locator ..... 5A-29  
 Forward Clutch Support, Low Roller  
     Clutch Assemble, 4T40-E Automatic  
         Transaxle, Unit Repair ..... 5A-205  
 Forward Clutch Support, Low Roller  
     Clutch Install, 4T40-E Automatic  
         Transaxle, Unit Repair ..... 5A-206  
 Forward Clutch Support, Low Roller  
     Clutch Removal, 4T40-E Automatic  
         Transaxle, Unit Repair ..... 5A-192  
 Forward Clutch Support, Roller Clutch  
     Disassemble, 4T40-E Automatic  
         Transaxle, Unit Repair ..... 5A-203  
 Four Wheel Alignment ..... 2B-8  
 Fourth Band Assembly Install,  
     Intermediate, 4T40-E Automatic  
         Transaxle, Unit Repair ..... 5A-231  
 Fourth Band Removal,  
     Intermediate, 4T40-E Automatic  
         Transaxle, Unit Repair ..... 5A-190

Fourth Gear, Overdrive Range, 4T40-E Automatic Transaxle .....	5A-288
Fourth Servo Disassemble, Assemble, and Install, Inter, 4T40-E Automatic Transaxle, Unit Repair .....	5A-259
Fretting Ring, Final Drive Internal Gear Install, 4T40-E Automatic Transaxle, Unit Repair .....	5A-203
Friction Check, Excessive, Front Suspension, Diagnosis .....	2C-5
Friction Check, Excessive, Rear Suspension, Diagnosis .....	2D-2
Front and Rear Fog Lamps Circuit, Lighting Systems, Schematic and Routing Diagrams .....	9B-5
Front and Rear Speakers .....	9F-14
Front Bucket Seat, On-Vehicle Service .....	9H-2
Front Bumper Energy Absorber, On-Vehicle Service .....	9O-4
Front Bumper Fascia, On-Vehicle Service .....	9O-2
Front Bumper Impact Bar, On-Vehicle Service .....	9O-4
Front Camber and Caster Check, Wheel Alignment, Diagnosis .....	2B-8
Front Door Assembly, Doors, On-Vehicle Service .....	9P-31
Front Door Escutcheon, Interior Trim, On-Vehicle Service .....	9G-26
Front Door Glass Run, Doors, On-Vehicle Service .....	9P-17
Front Door Glass, On-Vehicle Service .....	9L-13
Front Door Lock, Doors, On-Vehicle Service ...	9P-22
Front Door Secondary Weatherstrip, Doors, On-Vehicle Service .....	9P-18
Front Door Trim Panel, Interior Trim, On-Vehicle Service .....	9G-3
Front Drive Axle, Automatic Transaxle .....	3A-13
Front Drive Axle, Manual Transaxle .....	3B-12
Front Drive Axle, Manual Transaxle, Component Locator .....	3B-2
Front Drive Axles, Automatic Transaxle, Component Locator .....	3A-2
Front End Anticorrosion Materials, Body, On-Vehicle Service .....	9R-2
Front End Fasteners, Body, On-Vehicle Service .....	9R-2
Front End Lubrication, Body, On-Vehicle Service .....	9R-2
Front End Sealing, Body Front End, On-Vehicle Service .....	9R-2
Front End, Body .....	9R-13
Front Fog Lamps Circuit (Without Rear Fog Lamps), Lighting Systems, Schematic and Routing Diagrams .....	9B-6
Front Fog Lamps, Lighting Systems, On-Vehicle Service .....	9B-43
Front Harness Routing, Body Wiring System, Schematic and Routing Diagrams .....	9A-10
Front Muffler, On-Vehicle Service .....	1G-5
Front Rocker Trim Panel, Interior Trim, On-Vehicle Service .....	9G-16
Front Seat Adjusters, On-Vehicle Service .....	9H-6
Front Seat Belt (Three-Door Hatchback), Three-Point ELR, On-Vehicle Service .....	8A-7
Front Seat Belt (Three-Door Hatchback), Three-Point WLR/GCC, On-Vehicle Service .....	8A-13
Front Seat Belt (With Airbag), Three-Point ELR .....	8A-20
Front Seat Belt (With Airbag), Three-Point ELR, On-Vehicle Service .....	8A-5
Front Seat Belt Height Adjuster, On-Vehicle Service .....	8A-15
Front Seat Belt, Three-Point WLR .....	8A-20
Front Seat Belt, Three-Point WLR/GCC, On-Vehicle Service .....	8A-10
Front Seat Cushion, On-Vehicle Service .....	9H-5
Front Seat Trim, Seats, On-Vehicle Service .....	9H-7
Front Seatback, On-Vehicle Service .....	9H-4
Front Speakers, On-Vehicle Service .....	9F-9
Front Spring/Strut Cartridge, Front Suspension, Unit Repair .....	2C-20
Front Suspension (DOHC Engine) .....	2C-26
Front Suspension (SOHC Engine) .....	2C-26
Front Suspension, Component Locator .....	2C-6
Front Toe Adjustment, Wheel Alignment, Diagnosis .....	2B-8
Front Wheel Speed Sensor Jumper Harness, Antilock Brake System, On-Vehicle Service .....	4F-198
Front Wheel Speed Sensor Rings, Antilock Brake System .....	4F-213
Front Wheel Speed Sensor, Antilock Brake System, On-Vehicle Service .....	4F-196
Front Wheel Speed Sensors, Antilock Brake System .....	4F-213
Fuel Control System Operation, Engine Controls .....	1F-313
Fuel Economy, Poor, Symptom Diagnosis .....	1F-283
Fuel Filler Door Remote Cable and Handle, Body Rear End, On-Vehicle Service .....	9S-2
Fuel Filler Door, Body Rear End .....	9S-15
Fuel Filler Door, Body Rear End, On-Vehicle Service .....	9S-2
Fuel Filter, Engine Controls, On-Vehicle Service .....	1F-292
Fuel Gauge (Deluxe Cluster), Temperature Gauge and, Instrumentation/Driver Information, On-Vehicle Service .....	9E-34
Fuel Gauge, Instrumentation/Driver Information .....	9E-47
Fuel Gauge, Instrumentation/Driver Information, Diagnosis .....	9E-16
Fuel Injector Balance Test, Engine Controls, Diagnosis .....	1F-111

Fuel Injector, Engine Controls .....	1F-317
Fuel Pressure Regulator (DOHC), Engine Controls, On-Vehicle Service .....	1F-297
Fuel Pressure Regulator (SOHC), Engine Controls, On-Vehicle Service .....	1F-296
Fuel Pump Relay Circuit Check (1.3L and 1.5L SOHC IEFI-6), Engine Controls, Diagnosis .....	1F-56
Fuel Pump Relay Circuit Check (1.3L SOHC and 1.6L DOHC ITMS-6F), Engine Controls, Diagnosis .....	1F-60
Fuel Pump, Engine Controls, On-Vehicle Service .....	1F-291
Fuel Rail and Injectors (DOHC), On-Vehicle Service .....	1F-294
Fuel Rail and Injectors (SOHC), On-Vehicle Service .....	1F-293
Fuel System Pressure Test, Engine Controls, Diagnosis .....	1F-52
Fuel Tank, Engine Controls, On-Vehicle Service .....	1F-289
Functional Air Check, Forward Clutch, 4T40-E Automatic Transaxle, Unit Repair .....	5A-209
Functional Air Check, Reverse Clutch, 4T40-E Automatic Transaxle, Unit Repair .....	5A-229
Functional Air Check, Second Clutch, 4T40-E Automatic Transaxle, Unit Repair .....	5A-236
Functional Air Checks, Direct and Coast Clutch, 4T40-E Automatic Transaxle, Unit Repair .....	5A-224
Functional Check Procedure, 4T40-E Automatic Transaxle, Diagnosis .....	5A-50
Functional Check, Power Booster, Diagnosis .....	4C-1
Fuse Block Locator (Engine), Body Wiring System, Schematic and Routing Diagrams .....	9A-8
Fuse Block Locator, (Passenger Compartment), Body Wiring System, Schematic and Routing Diagrams .....	9A-8
Fuse Chart, Body Wiring System, Schematic and Routing Diagrams .....	9A-9
Fuse, ABS Solenoid, On-Vehicle Service .....	4F-203
Fuse, Antilock Brake System .....	4F-201

## G

Garnish Molding, Hatchback Door Lower, Interior Trim, On-Vehicle Service .....	9G-15
Garnish Molding, Hatchback Door Upper, Interior Trim, On-Vehicle Service .....	9G-14
Garnish Molding, Rear Door Interior, Interior Trim, On-Vehicle Service .....	9G-13
Gas Support Assemblies, Body Rear End, On-Vehicle Service .....	9S-12
Gasket and Filter, Pan, 4T40-E Automatic Transaxle, On-Vehicle Service .....	5A-158
Gasket Install, Oil Pan and, 4T40-E Automatic Transaxle, Unit Repair .....	5A-263
Gasket Removal, Channel Plate and, 4T40-E Automatic Transaxle, Unit Repair .....	5A-187
Gasket Removal, Control Valve Body Assembly and, 4T40-E Automatic Transaxle, Unit Repair .....	5A-186
Gasket Removal, Oil Pan and, 4T40-E Automatic Transaxle, Unit Repair .....	5A-183
Gasket Removal, Spacer Plate and, 4T40-E Automatic Transaxle, Unit Repair .....	5A-186
Gasket, Channel Plate-to-Case, 4T40-E Automatic Transaxle, Component Locator .....	5A-42
Gasket, Cylinder Head and, SOHC Engine Mechanical .....	1C-95
Gasket, Spacer Plate-to-Channel Plate, 4T40-E Automatic Transaxle, Component Locator .....	5A-41
Gasket, Valve Body-to-Spacer Plate, 4T40-E Automatic Transaxle, Component Locator .....	5A-37
Gasket, Valve Plate, Reed Plate, and O-Ring, Rear Head, Manual Control Heating, Ventilation and Air Conditioning System, Unit Repair .....	7B-64
Gaskets, Case Side Cover Pan and, 4T40-E Automatic Transaxle, On-Vehicle Service .....	5A-161
Gaskets, Disassemble, Assemble, Install, Side Cover/, 4T40-E Automatic Transaxle, Unit Repair .....	5A-254
Gear Cover, Antilock Brake System .....	4F-206
Gear Ratios, Specifications, 4T40-E Automatic Transaxle .....	5A-7
Gear Replacement, Antilock Brake System, Unit Repair .....	4F-207
Gear Set Removal, Direct/Coast Clutch and Reaction, 4T40-E Automatic Transaxle, Unit Repair .....	5A-190
Gear Tension Relief Sequence, Antilock Brake System .....	4F-188
Gear, Speedometer-Driven, On-Vehicle Service .....	5B-32
Gears and Case, Five-Speed Manual Transaxle, Component Locators .....	5B-8
Gearshift Lever Cover, Five-Speed Manual Transaxle, On-Vehicle Service .....	5B-34
Gearshift Lever, On-Vehicle Service, Five-Speed Manual Transaxle .....	5B-16
Gearshift Tube, Boot, Bushing and/or Bearing Ring, Five-Speed Manual Transaxle .....	5B-17

General Diagnosis, Suspension Diagnosis .....	2A-1
Generator (C5-121D), Engine Electrical, Unit Repair .....	1E-40
Generator (C5-128D), Engine Electrical, Unit Repair .....	1E-47
Generator Output Test, Engine Electrical, Diagnosis .....	1E-10
Generator Specifications, Engine Electrical .....	1E-2
Generator System Check, Engine Electrical, Diagnosis .....	1E-10
Generator, Engine Electrical .....	1E-57
Generator, Engine Electrical, On-Vehicle Service .....	1E-11
Glass Run, Front Door, Doors, On-Vehicle Service .....	9P-17
Glass Run, Rear Door, Doors, On-Vehicle Service .....	9P-17
Glass, Front Door, On-Vehicle Service .....	9L-13
Glass, Rear Door, On-Vehicle Service .....	9L-14
Glass, Rear Window, On-Vehicle Service .....	9L-9
Glass, Stationary .....	9L-21
Glove Box, Instrumentation/Driver Information .....	9E-47
Glove Box, Instrumentation/Driver Information, On-Vehicle Service .....	9E-29
Grille, Cowl Vent, Body Front End, On-Vehicle Service .....	9R-3
Grille, Radiator, Body Front End, On-Vehicle Service .....	9R-9
Guide Replacement, Actuator, 4T40-E Automatic Transaxle, Unit Repair .....	5A-196

## H

Handles, Passenger Assist, Roof .....	9Q-16
Hard Start, Symptom Diagnosis .....	1F-273
Harness Routing, Door, Body Wiring System, Schematic and Routing Diagrams .....	9A-15
Harness Routing, Floor, Body Wiring System, Schematic and Routing Diagrams .....	9A-12
Harness Routing, Front, Body Wiring System, Schematic and Routing Diagrams .....	9A-10
Harness Routing, Left-Hand Drive Instrument, Body Wiring System, Schematic and Routing Diagrams .....	9A-13
Harness Routing, Rear, Body Wiring System, Schematic and Routing Diagrams .....	9A-11
Harness Routing, Right-Hand Drive Instrument, Body Wiring System, Schematic and Routing Diagrams .....	9A-14
Harsh Shifts, 4T40-E Automatic Transaxle, Symptom Diagnosis .....	5A-67
Hatchback Door Lock Striker, Body Rear End, On-Vehicle Service .....	9S-13
Hatchback Door Lock, Body Rear End, On-Vehicle Service .....	9S-14

Hatchback Door Lower Garnish Molding, Interior Trim, On-Vehicle Service .....	9G-15
Hatchback Door Upper Garnish Molding, Interior Trim, On-Vehicle Service .....	9G-14
Hatchback Door, Body Rear End .....	9S-15
Hatchback Door, Body Rear End, On-Vehicle Service .....	9S-12
Hazard Lamps Circuit, Turn and, Lighting Systems, Schematic and Routing Diagrams .....	9B-13
Head and Gasket, Cylinder, SOHC Engine Mechanical .....	1C-95
Head and Gasket, Cylinder, SOHC Engine Mechanical, On-Vehicle Service .....	1C-13
Head and Valve Train Components, Cylinder, SOHC Engine Mechanical, Unit Repair .....	1C-76
Head Restraint, On-Vehicle Service .....	9H-3
Headlamp Leveling Circuit, Lighting Systems, Schematic and Routing Diagrams .....	9B-10
Headlamp Leveling, Lighting Systems, Diagnosis .....	9B-20
Headlamps-On Reminder Chime, Lighting Systems .....	9B-52
Headlamps-On Reminder Chime, Lighting Systems, Lighting Systems, Diagnosis .....	9B-15
Headlamps-On Reminder Chime, Lighting Systems, Schematic and Routing Diagrams .....	9B-8
Headlamps Circuit, Lighting Systems, Schematic and Routing Diagrams .....	9B-9
Headlamps, Lighting Systems .....	9B-52
Headlamps, Lighting Systems, Diagnosis .....	9B-16
Headlamps, Lighting Systems, Lighting Systems, On-Vehicle Service .....	9B-36
Headliner, Formed, Roof, On-Vehicle Service .....	9Q-9
Heat, Too Much, Heating and Ventilation System .....	7A-11
Heater Control Assembly, Heating and Ventilation System, On-Vehicle Service .....	7A-16
Heater Core, Heating and Ventilation System .....	7A-21
Heater Core, Manual Control Heating, Ventilation, and Air Conditioning System .....	7B-41
Heater Hoses, Heating and Ventilation System .....	7A-20
Heater Hoses, Manual Control Heating, Ventilation, and Air Conditioning System .....	7B-41
Heater System Diagnosis .....	7A-4
Heater Temperature Specifications .....	7A-1
Heater, Engine Block, Engine Cooling .....	1D-21

Heater, Rear, Heating and Ventilation System .....	7A-23
Heater/Air Distribution Case Assembly, Manual Control Heating, Ventilation, and Air Conditioning System .....	7B-35
Heating and Ventilation System .....	7A-24
Heating and Ventilation System Controls .....	7A-13
Heating or Defrosting, Insufficient, Heating and Ventilation System, Diagnosis .....	7A-4
Height Adjuster, Front Seat Belt, On-Vehicle Service .....	8A-15
Hesitation, Sag, Stumble, Engine Controls, Symptom Diagnosis .....	1F-280
High-Blower Relay, Heating and Ventilation System .....	7A-18
High-Blower Relay, Manual Control Heating, Ventilation, and Air Conditioning System ....	7B-30
High or Low Line Pressure, 4T40-E Automatic Transaxle, Symptom Diagnosis .....	5A-66
High Side Pressure Relationship Chart, Low and, Manual Control Heating, Ventilation, and Air Conditioning System ....	7B-21
Hinges, Hood, Body Front End, On-Vehicle Service .....	9R-5
Hood Hinges, Body Front End, On-Vehicle Service .....	9R-5
Hood Latch Release Cable, Body Front End On-Vehicle Service .....	9R-7
Hood Prop Rod, Body Front End, On-Vehicle Service .....	9R-5
Hood Secondary Latch, Body Front End, On-Vehicle Service .....	9R-6
Hood, Body Front End, On-Vehicle Service .....	9R-4
Horn Wiring System, Schematic and Routing Diagrams .....	9C-2
Horns .....	9C-4
Horns, Dual, On-Vehicle Service .....	9C-3
Hoses and Pipes, Power Steering System .....	6A-5
Hoses, Heater, Heating and Ventilation System .....	7A-20
Hoses, Heater, Manual Control Heating, Ventilation, and Air Conditioning System ....	7B-41
Hoses, Oil Cooler, 4T40-E Automatic Transaxle, On-Vehicle Service .....	5A-166
Hoses, Windshield Washer, On-Vehicle Service .....	9D-18
Housing Case, Five-Speed Manual Transaxle, Unit Repair .....	5B-73
Hub and Bearing Assembly with ABS, Rear Suspension .....	2D-12
Hub and Bearing Assembly without ABS, Rear Suspension .....	2D-8
Hub and Bearing, Front Suspension, Unit Repair .....	2C-16
Hub Assembly, Clutch Plate and, Manual Control Heating, Ventilation, and Air Conditioning System, Unit Repair .....	7B-52
HVAC Cables .....	7B-26
Hydra-Matic 4T40-E Shift Speed Chart, 4T40-E Automatic Transaxle, Diagnosis .....	5A-61
Hydraulic Clutch Components, Component Locator .....	5C-4
Hydraulic Cylinder Lines, Power Steering Gear, Unit Repair .....	6C-23
Hydraulic Functional Control, Antilock Brake System, Diagnosis .....	4F-186
Hydraulic Modulator Bleeder Valve, Antilock Brake System, On-Vehicle Service .....	4F-192
Hydraulic Modulator, Antilock Brake System, Unit Repair .....	4F-208
Hydraulic Modulator/Motor Pack Assembly, Antilock Brake System, On-Vehicle Service .....	4F-194
Hydrometer, Built-In, Engine Electrical .....	1E-55
<b>I</b>	
Identification (ID) Code Reprogramming, Immobilizer Anti-Theft System .....	9T-7
Identification, Vehicle and Component, General Description .....	0B-17
Idle Air Control System Check (1.3L and 1.5L SOHC IEFI-6), Engine Controls, Diagnosis .....	1F-72
Idle Air Control System Check (1.3L SOHC and 1.6L DOHC ITMS-6F), Engine Controls, Diagnosis .....	1F-76
Idle Air Control Valve (Typical), Engine Controls, On-Vehicle Service .....	1F-304
Idle Air Control Valve, Engine Controls .....	1F-316
Idle Air System Operation, Engine Controls .....	1F-313
Idle Learn Procedure, Engine Controls, Diagnosis .....	1F-22
Ignition Coil (Typical), Direct Ignition System, Engine Controls, On-Vehicle Service .....	1F-311
Ignition Coil, Direct Ignition System, Engine Controls .....	1F-313
Ignition Key Transponder, Immobilizer Anti-Theft System, On-Vehicle Service .....	9T-8
Ignition Lock Cylinder and Switch, Steering Wheel and Column, On-Vehicle Service .....	6E-16
Ignition System Check (1.3L and 1.5L SOHC IEFI-6), Engine Controls, Diagnosis .....	1F-80
Ignition System Check (1.3L SOHC and 1.6L DOHC ITMS-6F), Engine Controls, Diagnosis .....	1F-84
Ignition System Operation, Engine Controls .....	1F-313
Immobilizer and Test Equipment, Communication Between, Immobilizer Anti-Theft System .....	9T-6

Immobilizer Anti-Theft System Diagnosis .....	9T-3	Input and Second Roller Clutch Disassemble, Reverse, 4T40-E Automatic Transaxle, Unit Repair .....	5A-225
Immobilizer Control Unit, Immobilizer Anti-Theft System .....	9T-13	Input and Second Roller Clutch Install, Reverse, 4T40-E Automatic Transaxle, Unit Repair .....	5A-231
Immobilizer Control Unit, Immobilizer Anti-Theft System, On-Vehicle Service .....	9T-10	Input Carrier and Reaction Gear Assembly Removal, 4T40-E Automatic Transaxle, Unit Repair .....	5A-191
Immobilizer System, Immobilizer Anti-Theft System .....	9T-12	Input Carrier Assemble, Reaction Internal Gear, 4T40-E Automatic Transaxle, Unit Repair .....	5A-213
Immobilizer System, Schematic and Routing Diagrams .....	9T-2	Input Carrier Assembly, 4T40-E Automatic Transaxle, Component Locator .....	5A-26
Impact Bar, Front Bumper, On-Vehicle Service .....	9O-4	Input Carrier Disassemble, Reaction Internal Gear, 4T40-E Automatic Transaxle, Unit Repair .....	5A-212
Impact Bar, Rear Bumper, On-Vehicle Service .....	9O-10	Input Carrier Install, Reaction Internal Gear, 4T40-E Automatic Transaxle, Unit Repair .....	5A-213
Important Preliminary Checks, Engine Controls .....	1F-271	Input Carrier Pinion Gear Clearance Check, 4T40-E Automatic Transaxle, Unit Repair .....	5A-212
Improper Air Delivery or No Mode Shift, Heating and Ventilation System .....	7A-9	Input Internal Gear and Forward Clutch Hub, 4T40-E Automatic Transaxle, Component Locator .....	5A-27
Inaccurate/Inconsistent Shift Positions, 4T40-E Automatic Transaxle, Symptom Diagnosis .....	5A-66	Input Internal Gear, Forward Clutch Hub Assemble, 4T40-E Automatic Transaxle, Unit Repair .....	5A-211
Included Angle, Wheel Alignment .....	2B-9	Input Internal Gear, Forward Clutch Hub Disassemble, 4T40-E Automatic Transaxle, Unit Repair .....	5A-211
Inconsistent Shift Positions, Inaccurate/ 4T40-E Automatic Transaxle, Symptom Diagnosis .....	5A-66	Input Internal Gear, Forward Clutch Hub Install, 4T40-E Automatic Transaxle, Unit Repair .....	5A-212
Incorrect Idle, Stalling, Rough, Unstable, or, Symptom Diagnosis .....	1F-284	Input Internal Gear, Forward Clutch Hub Removal, 4T40-E Automatic Transaxle, Unit Repair .....	5A-191
Independent Lamp Activation, Microprocessor, Supplemental Inflatable Restraints (SIR) .....	8B-5	Input Shaft and Cluster Gear, Five-Speed Manual Transaxle, Unit Repair .....	5B-55
Indicators, ABS, On-Vehicle Service .....	4F-204	Input Speed Sensor Install, 4T40-E Automatic Transaxle, Unit Repair .....	5A-237
Induction System Operation, Variable Geometry, Engine Controls .....	1F-314	Input Speed Sensor Removal, 4T40-E Automatic Transaxle, Unit Repair .....	5A-188
Induction System, Variable Geometry, Engine Controls, On-Vehicle Service .....	1F-305	Inside Channel Molding, Doors, On-Vehicle Service .....	9P-35
Inflation of Tires .....	2E-11	Inside Door Handle, Doors, On-Vehicle Service .....	9P-26
Inflation Pressure Conversion Specifications .....	2E-2	Inside Lock Rod, Doors, On-Vehicle Service .....	9P-27
Injector Balance Test, Fuel, Engine Controls, Diagnosis .....	1F-111	Inside Rearview Mirror .....	9L-21
Injector, Fuel, Engine Controls .....	1F-317	Inside Rearview Mirror, On-Vehicle Service .....	9L-18
Injectors (DOHC), Fuel Rail and, On-Vehicle Service .....	1F-294	Instructions, General Repair .....	0B-16
Injectors (SOHC), Fuel Rail and, On-Vehicle Service .....	1F-293		
Inner Tie Rod, Manual Steering Gear, On-Vehicle Service .....	6D-6		
Inner Tie Rod, Power Steering Gear, On-Vehicle Service .....	6C-15		
Inner Tripot Seal, Automatic Transaxle Drive Axle, Unit Repair .....	3A-9		
Input (Shaft) Speed Sensor (A/T OSS), Automatic Transmission, 4T40-E Automatic Transaxle .....	5A-269		
Input and Second Roller Clutch Assemble, Reverse, 4T40-E Automatic Transaxle, Unit Repair .....	5A-228		

- Instrument Cluster (Deluxe),  
Instrumentation/Driver Information ..... 9E-47
- Instrument Cluster (Deluxe),  
Instrumentation/Driver Information,  
On-Vehicle Service ..... 9E-31
- Instrument Cluster (Standard),  
Instrumentation/Driver Information,  
On-Vehicle Service ..... 9E-31
- Instrument Cluster (Standard),  
Instrumentation/Driver Information ..... 9E-47
- Instrument Cluster Indicator Lamps  
Specifications, Instrumentation/Driver  
Information ..... 9E-2
- Instrument Cluster Indicator Lamps,  
Instrumentation/Driver Information,  
Diagnosis ..... 9E-21
- Instrument Cluster Indicator Lamps,  
Instrumentation/Driver Information,  
On-Vehicle Service ..... 9E-35
- Instrument Cluster Indicator Lamps,  
Instrumentation/Driver Information ..... 9E-47
- Instrument Cluster Trim Panel Vents,  
Instrumentation/Driver Information,  
On-Vehicle Service ..... 9E-29
- Instrument Cluster Trim Panel,  
Instrumentation/Driver Information,  
On-Vehicle Service ..... 9E-42
- Instrument Cluster, Instrumentation/Driver  
Information, Schematic and  
Routing Diagrams ..... 9E-3
- Instrument Panel Illumination,  
Instrumentation/Driver Information,  
Schematic and Routing Diagrams ..... 9E-3
- Instrument Panel Illumination,  
Instrumentation/Driver Information,  
Diagnosis ..... 9E-9
- Instrument Panel Vents,  
Instrumentation/Driver Information ..... 9E-47
- Instrument Panel, Instrumentation/Driver  
Information, On-Vehicle Service ..... 9E-35
- Instruments Circuit, Lighting Systems,  
Schematic and Routing Diagrams ..... 9B-4
- Insufficient Cooling "Quick Check"  
Procedure, Manual Control Heating,  
Ventilation, and Air Conditioning System .... 7B-11
- Insufficient Cooling Diagnosis,  
V5 System Air Conditioning Diagnosis ..... 7B-15
- Insulators, Floor Pan, Frame and Underbody,  
On-Vehicle Service ..... 9N-5
- Insulators, Springs and, Rear Suspension ..... 2D-5
- Insulators, Stabilizer Shaft and,  
Front Suspension ..... 2C-8
- Intake Manifold, SOHC Engine Mechanical .... 1C-95
- Intake Manifold, SOHC Engine Mechanical,  
On-Vehicle Service ..... 1C-51
- Inter Fourth Servo Disassemble, Assemble,  
and Install, 4T40-E Automatic Transaxle,  
Unit Repair ..... 5A-259
- Inter Fourth Servo Removal, 4T40-E  
Automatic Transaxle, Unit Repair ..... 5A-184
- Interior Courtesy Lamp/Power  
Sunroof Control Switch, Roof,  
On-Vehicle Service ..... 9Q-8
- Interior Courtesy and Luggage Compartment  
Lamp Circuit, Lighting Systems,  
Schematic and Routing Diagrams ..... 9B-14
- Interior Courtesy and Luggage Compartment  
Lamps, Lighting Systems, Diagnosis ..... 9B-30
- Interior Courtesy Lamp, Lighting Systems ..... 9B-52
- Interior Courtesy Lamp, Lighting Systems,  
On-Vehicle Service ..... 9B-47
- Interior Garnish Molding, Rear Door,  
Interior Trim, On-Vehicle Service ..... 9G-13
- Interior Trim Panels ..... 9G-30
- Intermediate Fourth Band Assembly Install,  
4T40-E Automatic Transaxle,  
Unit Repair ..... 5A-231
- Intermediate Fourth Band Removal,  
4T40-E Automatic Transaxle,  
Unit Repair ..... 5A-190
- Intermittent Windshield Wipers,  
Diagnosis ..... 9D-4
- Intermittents and Poor Connections,  
Antilock Brake System ..... 4F-16
- Intermittents, Symptom Engine Controls,  
Diagnosis ..... 1F-271
- Internal Gear and Forward Clutch Hub,  
Input, 4T40-E Automatic Transaxle,  
Component Locator ..... 5A-27
- Internal Gear Removal, Final Drive,  
4T40-E Automatic Transaxle,  
Unit Repair ..... 5A-193
- Internal Gear, Forward Clutch Hub  
Assemble, Input, 4T40-E Automatic  
Transaxle, Unit Repair ..... 5A-211
- Internal Gear, Forward Clutch Hub  
Disassemble, Input, 4T40-E Automatic  
Transaxle, Unit Repair ..... 5A-211
- Internal Gear, Forward Clutch Hub  
Install, Input, 4T40-E Automatic  
Transaxle, Unit Repair ..... 5A-212
- Internal Gear, Forward Clutch Hub  
Removal, Input, 4T40-E Automatic  
Transaxle, Unit Repair ..... 5A-191
- Internal Gear, Input Carrier Assemble,  
Reaction, 4T40-E Automatic Transaxle,  
Unit Repair ..... 5A-213
- Internal Gear, Input Carrier Disassemble,  
Reaction, 4T40-E Automatic Transaxle,  
Unit Repair ..... 5A-212
- Internal Gear, Input Carrier Install,  
Reaction, 4T40-E Automatic Transaxle,  
Unit Repair ..... 5A-213
- Internal Wiring Harness Check,  
4T40-E Automatic Transaxle, Diagnosis ..... 5A-61



## J

Joint Seal, Cross Groove, Manual	
Transaxle Drive Axle, Unit Repair	3B-10
Joint Seal, Outer, Automatic Transaxle	
Drive Axle, Unit Repair	3A-8
Joint Seal, Outer, Manual Transaxle	
Drive Axle, Unit Repair	3B-8
Jump-Starting Procedure, Engine Electrical	1E-56

## K

Key Coding Procedure, Immobilizer	
Anti-Theft System, On-Vehicle Service	9T-7
Key Status Errors, Immobilizer	
Anti-Theft System, Diagnosis	9T-5
Key Transponder, Ignition, Immobilizer	
Anti-Theft System, On-Vehicle Service	9T-8
Keys, Electronically Coded,	
Immobilizer Anti-Theft System	9T-13
Kick Panel, Interior Trim,	
On-Vehicle Service	9G-15
Knock Diagnosis, Engine	1A-4
Knock Sensor, Engine Controls	1F-317
Knock Sensor, Engine Controls,	
On-Vehicle Service	1F-307
Knuckle, Ball Joint and, Front Suspension,	
Diagnosis	2C-4
Knuckle, Front Suspension, Unit Repair	2C-25
Knuckle/Strut Assembly, Front Suspension,	
On-Vehicle Service	2C-9

## L

Lack of Power, Sluggishness, or Sponginess,	
Engine Controls, Diagnosis	1F-277
Lamp Activation, Microprocessor -	
Independent, Supplemental Inflatable	
Restraints (SIR)	8B-5
Lamp Driver Module, Antilock Brake System,	
On-Vehicle Service	4F-204
Lamp Operation, Warning, Hydraulic Brakes,	
Diagnosis	4A-6
Lamp, SIR Warning	8B-52
Lead/Pull, Radial Tire, Wheel Alignment,	
Diagnosis	2B-3
Leak Inspection Points, 4T40-E Automatic	
Transaxle Component Locator	5A-45
Leak Test, Power Steering System,	
Diagnosis	6A-2
Leak Testing (External), Manual Control	
Heating, Ventilation, and Air Conditioning	
System	7B-68
Leak Testing the Refrigerant System,	
Manual Control Heating, Ventilation,	
and Air Conditioning System	7B-14

Learn Procedure, Idle, Engine Controls,	
Diagnosis	1F-22
Left-Hand Drive Instrument Harness Routing,	
Body Wiring System, Schematic and	
Routing Diagrams	9A-13
Lettering, Emblems and, Exterior Trim	9M-4
Level Sensor, Fluid, Master Cylinder	4B-11
Level, Checking Fluid, Five-Speed	
Manual Transaxle, On-Vehicle Service	5B-14
Lever and/or Bushings, Linkage,	
On-Vehicle Service	5B-26
Lever Cover, Gearshift, Five-Speed	
Manual Transaxle, On-Vehicle Service	5B-34
Lever, Gearshift, Five-Speed Manual	
Transaxle, On-Vehicle Service	5B-16
Lever, Parking Brake	4G-3
Lever, Shift Control, 4T40-E Automatic	
Transaxle, On-Vehicle Service	5A-147
Lever, Turn Signal Switch and,	
Steering Wheel and Column,	
On-Vehicle Service	6E-7
Lever, Wiper Switch and,	
Steering Wheel and Column,	
On-Vehicle Service	6E-9
License Lamps Circuit, Position,	
Tail and, Lighting Systems,	
Schematic and Routing Diagrams	9B-11
License Plate Lamp, Lighting Systems	9B-52
License Plate Lamps, Lighting Systems,	
On-Vehicle Service	9B-46
Lighter, Cigar, Instrumentation/Driver	
Information	9E-47
Lighter, Cigar, Instrumentation/Driver	
Information, Diagnosis	9E-5
Lighter, Cigar, Instrumentation/Driver	
Information, On-Vehicle Service	9E-27
Line Pressure Check Procedure,	
4T40-E Automatic Transaxle, Diagnosis	5A-51
Line Pressure Specifications,	
4T40-E Automatic Transaxle	5A-7
Line Seal Removal, Transaxle Cooler,	
4T40-E Automatic Transaxle,	
Unit Repair	5A-194
Lines and Fitting, Refrigerant, Handling of	7B-22
Lining Inspection, Front Disc Brakes	4D-1
Lining Inspection, Rear Drum Brakes,	
Diagnosis	4E-1
Lining, Shoe and, Front Disc Brakes	4D-3
Lining, Shoe and, Rear Drum Brakes	4E-6
Linkage Adjustment, Shift, Five-Speed	
Manual Transaxle, On-Vehicle Service	5B-14
Linkage Lever and/or Bushings,	
On-Vehicle Service	5B-26
Linkage, Shift, Five-Speed Manual	
Transaxle, Component Locators	5B-12
Load Test, Battery, Engine Electrical,	
Diagnosis	1E-9

- Locator, Fuse Block (Engine), Body Wiring System, Schematic and Routing Diagrams . . . . 9A-8
- Locator, Fuse Block, (Passenger Compartment), Body Wiring System, Schematic and Routing Diagrams . . . . . 9A-8
- Lock (Notchback), Luggage Compartment, Body Rear End, On-Vehicle Service . . . . . 9S-10
- Lock Assembly, Rear Seatback, On-Vehicle Service . . . . . 9H-13
- Lock Cylinder and Switch, Ignition, Steering Wheel and Column, On-Vehicle Service . . . . . 6E-16
- Lock Cylinder, Door, Doors, On-Vehicle Service . . . . . 9P-28
- Lock Cylinder, Luggage Compartment, Body Rear End, On-Vehicle Service . . . . . 9S-8
- Lock Rod, Inside, Doors, On-Vehicle Service . . . . . 9P-27
- Lock Striker (Notchback), Luggage Compartment, Body Rear End, On-Vehicle Service . . . . . 9S-9
- Lock Striker Adjustment, Door, Doors, On-Vehicle Service . . . . . 9P-20
- Lock Striker, Door, Doors . . . . . 9P-40
- Lock Striker, Door, Doors, On-Vehicle Service . . . . . 9P-19
- Lock Striker, Hatchback Door, Body Rear End, On-Vehicle Service . . . . . 9S-13
- Lock Striker, Rear Seatback, On-Vehicle Service . . . . . 9H-11
- Loss of Drive, 4T40-E Automatic Transaxle, Symptom Diagnosis . . . . . 5A-70
- Loss of Power, 4T40-E Automatic Transaxle, Symptom Diagnosis . . . . . 5A-71
- Low and High Side Pressure Relationship Chart, Manual Control Heating, Ventilation, and . . . . .
- Low Line Pressure, High or, 4T40-E Automatic Transaxle, Symptom Diagnosis . . . . . 5A-66
- Low Roller Clutch Assemble, Forward Clutch Support, 4T40-E Automatic Transaxle, Unit Repair . . . . . 5A-205
- Low Roller Clutch Install, Forward Clutch Support, 4T40-E Automatic Transaxle, Unit Repair . . . . . 5A-206
- Low Roller Clutch Removal, Forward Clutch Support, 4T40-E Automatic Transaxle, Unit Repair . . . . . 5A-192
- Low/Reverse Band Install, 4T40-E Automatic Transaxle, Unit Repair . . . . . 5A-210
- Low/Reverse Band Removal, Forward Clutch and, 4T40-E Automatic Transaxle, Unit Repair . . . . . 5A-191
- Low/Reverse Servo Assembly Assemble, 4T40-E Automatic Transaxle, Unit Repair . . . . . 5A-261
- Low/Reverse Servo Assembly Disassemble, 4T40-E Automatic Transaxle, Unit Repair . . . . . 5A-261
- Low/Reverse Servo Removal, 4T40-E Automatic Transaxle, Unit Repair . . . . . 5A-184
- Lower B-Pillar Trim Panel (Three-Door Hatchback), Interior Trim, On-Vehicle Service . . . . . 9G-11
- Lower B-Pillar Trim Panel, Interior Trim, On-Vehicle Service . . . . . 9G-11
- Lower End, SOHC Engine Mechanical, Component Locator . . . . . 1C-10
- Lower Garnish Molding, Hatchback Door, Interior Trim, On-Vehicle Service . . . . . 9G-15
- Lubricants, Recommended Fluids and, Owner Inspections and Services . . . . . 0B-15
- Lubrication, Body Front End, On-Vehicle Service . . . . . 9R-2
- Lubrication, Maintenance and, General Information . . . . . 0B-9
- Luggage Compartment Lamp Circuit, Interior Courtesy and, Lighting Systems, Schematic and Routing Diagrams . . . . . 9B-14
- Luggage Compartment Lamp, Lighting Systems . . . . . 9B-53
- Luggage Compartment Lamp, Lighting Systems, On-Vehicle Service . . . . . 9B-50
- Luggage Compartment Lamps, Interior Courtesy and, Lighting Systems, Diagnosis . . . . . 9B-30
- Luggage Compartment Lock (Notchback), Body Rear End, On-Vehicle Service . . . . . 9S-10
- Luggage Compartment Lock Cylinder, Body Rear End, On-Vehicle Service . . . . . 9S-8
- Luggage Compartment Lock Striker (Notchback), Body Rear End, On-Vehicle Service . . . . . 9S-9
- Luggage Compartment Rear Quarter Trim Panel (Notchback), Interior Trim, On-Vehicle Service . . . . . 9G-28
- Luggage Compartment Rear Trim Panel, Interior Trim, On-Vehicle Service . . . . . 9G-29
- Luggage Compartment Wheelhouse Trim Panel (Hatchback), Interior Trim, On-Vehicle Service . . . . . 9G-27
- Luggage Compartment Wheelhouse Trim Panel (Notchback), Interior Trim, On-Vehicle Service . . . . . 9G-27

## M

- Mainshaft, Five-Speed Manual Transaxle, Unit Repair . . . . . 5B-58
- Maintenance and Lubrication, General Information . . . . . 0B-9
- Maintenance Charts, Scheduled, Maintenance and Lubrication . . . . . 0B-11
- Maintenance Services, Explanation of Scheduled . . . . . 0B-9
- Major Component Assembly, Five-Speed Manual Transaxle, Unit Repair . . . . . 5B-84

Major Component Disassembly, Five-Speed Manual Transaxle .....	5B-44
Manifold Absolute Pressure Check (1.3L and 1.5L SOHC IEFI-6), Engine Controls, Diagnosis .....	1F-64
Manifold Absolute Pressure Check (1.3L SOHC and 1.6L DOHC ITMS-6F), Engine Controls, Diagnosis .....	1F-66
Manifold Absolute Pressure Sensor (Typical), Engine Controls, On-Vehicle Service .....	1F-305
Manifold Absolute Pressure Sensor, Engine Controls .....	1F-316
Manifold Air Temperature Sensor (Typical), Engine Controls, On-Vehicle Service .....	1F-303
Manifold Air Temperature Sensor, Engine Controls .....	1F-316
Manifold, Exhaust, SOHC Engine Mechanical ..	1C-95
Manifold, Exhaust, SOHC Engine Mechanical, On-Vehicle Service .....	1C-57
Manifold, Intake, SOHC Engine Mechanical ....	1C-95
Manifold, Intake, SOHC Engine Mechanical, On-Vehicle Service .....	1C-51
Manual Antenna .....	9F-14
Manual Antenna, Power Antenna Motor/, On-Vehicle Service .....	9F-13
Manual Bleeding the Brakes, Hydraulic Brakes .....	4A-13
Manual Control Heating, Ventilation, and Air Conditioning System Control Assembly .....	7B-28
Manual Control Heating, Ventilation, and Air Conditioning System Control Assembly Knob Lighting .....	7B-29
Manual First - First Gear, 4T40-E Automatic Transaxle .....	5A-296
Manual Front Window Regulator, Doors, On-Vehicle Service .....	9P-29
Manual Rack and Pinion .....	6D-20
Manual Rack and Pinion Steering Gear, Diagnosis .....	6D-3
Manual Rear Window Regulator, Doors, On-Vehicle Service .....	9P-30
Manual Second - Second Gear, 4T40-E Automatic Transaxle .....	5A-294
Manual Shaft, Detent Lever, Park Lock Installation, 4T40-E Automatic Transaxle, Unit Repair .....	5A-197
Manual Shaft, Detent Lever, Park Lock Removal, 4T40-E Automatic Transaxle, Unit Repair .....	5A-193
Manual Shaft, Parking Panel and Actuator Assembly, 4T40-E Automatic Transaxle, Component Locator .....	5A-31
Manual Third - Third Gear, 4T40-E Automatic Transaxle .....	5A-292
Manual Transaxle, Five-Speed .....	5B-93
Manual Valve Clip Removal, 4T40-E Automatic Transaxle, Unit Repair .....	5A-187
Manual Valve Install, 4T40-E Automatic Transaxle, Unit Repair .....	5A-242
Manual Window Regulator Handle, Doors, On-Vehicle Service .....	9P-38
Master Cylinder .....	4B-11
Master Cylinder Assembly, Clutch, On-Vehicle Service .....	5C-16
Master Cylinder Assembly, On-Vehicle Service .....	4B-3
Master Cylinder Overhaul, Unit Repair .....	4B-8
Master Cylinder, Clutch, Unit Repair .....	5C-20
Microprocessor - Independent Lamp Activation, Supplemental Inflatable Restraints (SIR) .....	8B-5
Mirror, Inside Rearview .....	9L-21
Mirror, Outside Rearview .....	9L-21
Mirror, Rearview Inside, On-Vehicle Service .....	9L-18
Mirrors, Electric Control Outside Rearview, Diagnosis .....	9L-4
Mirrors, Electric Control Outside Rearview, Schematic and Routing Diagrams .....	9L-3
Mirrors, Rearview Outside, On-Vehicle Service .....	9L-19
Misses, Cuts Out, Engine Controls, Symptom Diagnosis .....	1F-281
Modulator Test, Automated, Antilock Brake System, Diagnosis .....	4F-186
Modulator, Hydraulic, Antilock Brake System, Unit Repair .....	4F-208
Module, Lamp Driver, Antilock Brake System, On-Vehicle Service .....	4F-204
Molding (Notchback and Five-Door Hatchback), B-Pillar, Exterior Trim, On-Vehicle Service .....	9M-2
Molding (Three-Door Hatchback), B-Pillar, Exterior Trim, On-Vehicle Service .....	9M-2
Molding, Inside Channel, Doors, On-Vehicle Service .....	9P-35
Molding, Outside Channel, Doors, On-Vehicle Service .....	9P-36
Molding, Roof, Exterior Trim, On-Vehicle Service .....	9M-3
Motor (0.8 Kilowatts), Starter, Engine Electrical, Unit Repair .....	1E-19
Motor (1.4 Kilowatts), Starter, Engine Electrical, Unit Repair .....	1E-28
Motor Pack Assembly, Hydraulic Modulator/, Antilock Brake System, On-Vehicle Service .....	4F-194
Motor Pack Diagnosis Test, Automated, Antilock Brake System, Diagnosis .....	4F-186
Motor Pack Functional Test, Antilock Brake System, Diagnosis .....	4F-187
Motor Pack, Antilock Brake System, Unit Repair .....	4F-206
Motor Rehome Function, Antilock Brake System .....	4F-188

Motor Testing, Antilock Brake System, Diagnosis .....	4F-186
Mount, Engine, SOHC Engine Mechanical, On-Vehicle Service .....	1C-49
Mounting and Dismounting, Tire, Unit Repair .....	2E-8
Movable Quarter Window (Three-Door Hatchback), On-Vehicle Service .....	9L-16
Mud Guards, Exterior Trim .....	9M-4
Muffler .....	1G-12
Muffler - Front, On-Vehicle Service .....	1G-5
Muffler - Rear, On-Vehicle Service .....	1G-7

## N

Neutral (Engine Running), 4T40-E Automatic Transaxle .....	5A-280
Neutral Start Switch, 4T40-E Automatic Transaxle, On-Vehicle Service .....	5A-156
Neutral Switch (1.3L and 1.5L SOHC IEFI-6), Park/, Engine Controls, Diagnosis .....	1F-68
Neutral Switch (1.3L SOHC and 1.6L DOHC ITMS-6F), Park/, Engine Controls, Diagnosis .....	1F-70
Neutral, Drives in, 4T40-E Automatic Transaxle, Symptom Diagnosis .....	5A-74
No Crank, Engine Electrical, Diagnosis .....	1E-5
No Engine Braking; All Manual Ranges, 4T40-E Automatic Transaxle, Symptom Diagnosis .....	5A-73
No Engine Braking; Manual First - First Gear, 4T40-E Automatic Transaxle, Symptom Diagnosis .....	5A-73
No Engine Braking; Manual Second - Second Gear, 4T40-E Automatic Transaxle, Symptom Diagnosis .....	5A-73
No First Gear, Slips in First Gear, 4T40-E Automatic Transaxle, Symptom Diagnosis .....	5A-68
No Fourth Gear, Slips in Fourth Gear, 4T40-E Automatic Transaxle, Symptom Diagnosis .....	5A-70
No Gear Movement, Antilock Brake System, Diagnosis .....	4F-186
No Gear Selection, 4T40-E Automatic Transaxle, Symptom Diagnosis .....	5A-74
No Park, 4T40-E Automatic Transaxle, Symptom Diagnosis .....	5A-72
No Reverse, Slips in Reverse, 4T40-E Automatic Transaxle, Symptom Diagnosis .....	5A-67
No Second Gear, Slips in Second Gear, 4T40-E Automatic Transaxle, Symptom Diagnosis .....	5A-68
No Service Engine Soon Lamp (1.3L and 1.5L SOHC IEFI-6), Engine Controls, Diagnosis .....	1F-40

No Service Engine Soon Lamp (1.3L SOHC and 1.6L DOHC ITMS-6F), Engine Controls, Diagnosis .....	1F-44
No Shift Mode, Improper Air Delivery or, Heating and Ventilation System .....	7A-9
No TCC Release, 4T40-E Automatic Transaxle, Symptom Diagnosis .....	5A-77
No TCC/Slipping/Soft Apply, 4T40-E Automatic Transaxle, Symptom Diagnosis .....	5A-76
No Third Gear, Slips in Third Gear, 4T40-E Automatic Transaxle, Symptom Diagnosis ...	5A-69
Noise Diagnosis, Engine .....	1A-8
Noise, Isolate, Five-Speed Manual Transaxle, Diagnosis .....	5B-5
Noise, Ratcheting, Symptom 4T40-E Automatic Transaxle, Diagnosis .....	5A-72
Noise, Starter Motor, Engine Electrical, Diagnosis .....	1E-9
Noise, 4T40-E Automatic Transaxle, Symptom Diagnosis .....	5A-75
Non-A/C Diagram, Heating and Ventilation System, Schematic and Routing Diagrams .....	7A-2
Normal Vehicle Use, Maintenance and Lubrication .....	0B-9
Nozzle, Rear Window Washer, On-Vehicle Service .....	9D-20
Nozzles, Windshield Washer, On-Vehicle Service .....	9D-17

## O

O-Ring Replacement, Manual Control Heating, Ventilation, and Air Conditioning System .....	7B-22
Octane Number Connector, Engine Controls .....	1F-318
Odometer/Trip Odometer, Speedometer/, Instrumentation/Driver Information On-Vehicle Service .....	9E-33
Odometer/Trip Odometer, Speedometer/, Instrumentation/Driver Information .....	9E-47
Odors, Excessive Exhaust Emissions or, Engine Controls, Symptom Diagnosis .....	1F-286
Oil Channels, Pump Body, 4T40-E Automatic Transaxle, Component Locator .....	5A-44
Oil Cooler Flushing, 4T40-E Automatic Transaxle, On-Vehicle Service .....	5A-146
Oil Cooler Hoses, 4T40-E Automatic Transaxle, On-Vehicle Service .....	5A-166
Oil Cooler Pipes, 4T40-E Automatic Transaxle, On-Vehicle Service .....	5A-166
Oil Feed Pipes Assemble, 4T40-E Automatic Transaxle, Unit Repair .....	5A-261
Oil Feed Pipes Removal, 4T40-E Automatic Transaxle, Unit Repair .....	5A-183

Oil Filter/Seal, Oil Level Control Valve Removal, 4T40-E Automatic Transaxle, Unit Repair .....	5A-183
Oil Leak Diagnosis, Engine .....	1A-3
Oil Level Control Valve Install, 4T40-E Automatic Transaxle, Unit Repair .....	5A-263
Oil Level Control Valve Removal, Oil Filter/Seal, 4T40-E Automatic Transaxle, Unit Repair .....	5A-183
Oil Pan and Gasket Install, 4T40-E Automatic Transaxle, Unit Repair .....	5A-263
Oil Pan and Gasket Removal, 4T40-E Automatic Transaxle, Unit Repair .....	5A-183
Oil Pan, SOHC Engine Mechanical .....	1C-95
Oil Pan, SOHC Engine Mechanical, On-Vehicle Service .....	1C-47
Oil Pressure Test, Engine, Diagnosis .....	1A-2
Oil Pump and Oil Pump Shaft Removal, 4T40-E Automatic Transaxle, Unit Repair .....	5A-185
Oil Pump Assembly Installation, 4T40-E Automatic Transaxle, Unit Repair .....	5A-254
Oil Pump Assembly, 4T40-E Automatic Transaxle, Component Locator .....	5A-20
Oil Pump Clean and Inspect, 4T40-E Automatic Transaxle, Unit Repair .....	5A-254
Oil Pump Shaft Removal, Oil Pump and, 4T40-E Automatic Transaxle, Unit Repair .....	5A-185
Oil Pump Side, Control Valve Body Channels, 4T40-E Automatic Transaxle, Component Locator .....	5A-48
Oil Pump, SOHC Engine Mechanical .....	1C-95
Oil Pump, SOHC Engine Mechanical, On-Vehicle Service .....	1C-42
Oil Seal, Drive Axle, 4T40-E Automatic Transaxle, On-Vehicle Service .....	5A-165
On-Engine Service, General Information .....	1A-11
One-Piece Drum, Rear Drum Brakes .....	4E-4
Operating Members, Clutch .....	5C-24
Operational and Functional Checks, Seat Belts .....	8A-20
Outer Joint Seal, Automatic Transaxle Drive Axle, Unit Repair .....	3A-8
Outer Joint Seal, Manual Transaxle Drive Axle, Unit Repair .....	3B-8
Outer Tie Rod, Manual Steering Gear, On-Vehicle Service .....	6D-6
Outer Tie Rod, Power Steering Gear, On-Vehicle Service .....	6C-14
Output (Shaft) Speed Sensor (A/T OSS), Automatic Transmission, 4T40-E Automatic Transaxle .....	5A-269
Output Shaft and Final Drive Assembly Removal, 4T40-E Automatic Transaxle, Unit Repair .....	5A-193
Output Shaft and Sleeve Assembly Install, 4T40-E Automatic Transaxle, Unit Repair .....	5A-257
Output Shaft Sleeve Assemble, 4T40-E Automatic Transaxle, Unit Repair .....	5A-256
Output Shaft Sleeve Removal, 4T40-E Automatic Transaxle, Unit Repair .....	5A-188
Output Speed Sensor Installation, 4T40-E Automatic Transaxle, Unit Repair .....	5A-259
Output Speed Sensor, (A/T OSS) Automatic Transmission, 4T40-E Automatic Transaxle, On-Vehicle Service .....	5A-158
Output Test, Generator, Engine Electrical, Diagnosis .....	1E-10
Outside Channel Molding, Doors, On-Vehicle Service .....	9P-36
Outside Door Handle, Door, On-Vehicle Service .....	9P-28
Outside Rearview Mirror .....	9L-21
Outside Rearview Mirrors, Electric Control, Diagnosis .....	9L-4
Outside Rearview Mirrors, On-Vehicle Service .....	9L-19
Overdrive Range - First Gear, 4T40-E Automatic Transaxle .....	5A-282
Overdrive Range - Four-Three Downshift, 4T40-E Automatic Transaxle .....	5A-290
Overdrive Range - Fourth Gear, 4T40-E Automatic Transaxle .....	5A-288
Overdrive Range - Second Gear, 4T40-E Automatic Transaxle .....	5A-284
Overdrive Range - Third Gear, 4T40-E Automatic Transaxle .....	5A-286
Oxygen Sensor (Typical), Engine Controls, On-Vehicle Service .....	1F-302
Oxygen Sensor, Engine Controls .....	1F-315

## P

Pan and Gasket Install, Oil, 4T40-E Automatic Transaxle, Unit Repair .....	5A-263
Pan, Gasket, and Filter, 4T40-E Automatic Transaxle, On-Vehicle Service .....	5A-158
Pan, Oil, SOHC Engine Mechanical .....	1C-95
Pan, Oil, SOHC Engine Mechanical, On-Vehicle Service .....	1C-47
Panel Illumination, Instrument, Instrumentation/Driver Information, Diagnosis .....	9E-9

- Park (Engine Running),  
4T40-E Automatic Transaxle ..... 5A-276
- Park Lock Installation, Manual Shaft,  
Detent Lever, 4T40-E Automatic  
Transaxle, Unit Repair ..... 5A-197
- Park Lock Removal, Manual Shaft,  
Detent Lever, 4T40-E Automatic  
Transaxle, Unit Repair ..... 5A-193
- Park/Neutral Switch (1.3L and 1.5L SOHC  
IEFI-6), Engine Controls, Diagnosis ..... 1F-68
- Park/Neutral Switch (1.3L SOHC and  
1.6L DOHC ITMS-6F), Engine Controls,  
Diagnosis ..... 1F-70
- Parking and Turn Signal Lamps,  
Lighting Systems ..... 9B-52
- Parking Brake ..... 4G-12
- Parking Brake Adjustment ..... 4G-2
- Parking Brake Cable ..... 4G-6
- Parking Brake Lever ..... 4G-3
- Parking Lamps, Lighting Systems,  
Lighting Systems, On-Vehicle Service ..... 9B-37
- Parking Panel and Actuator Assembly,  
Manual Shaft, 4T40-E Automatic  
Transaxle, Component Locator ..... 5A-31
- Passenger Airbag Module,  
Supplemental Inflatable Restraints (SIR),  
On-Vehicle Service ..... 8B-43
- Passenger Assist Handles,  
On-Vehicle Service ..... 9Q-14
- Passenger Assist Handles, Roof ..... 9Q-16
- Pedal Adjustment (Hydraulic), Clutch,  
On-Vehicle Service ..... 5C-14
- Pedal, Clutch, On-Vehicle Service ..... 5C-7
- Pinion Assembly (Left-Hand Drive),  
Rack and, Power Steering Gear,  
On-Vehicle Service ..... 6C-6
- Pinion Assembly (Right-Hand Drive),  
Rack and, Power Steering Gear,  
On-Vehicle Service ..... 6C-9
- Pinion Assembly, Rack and, Manual Steering  
Gear, On-Vehicle Service ..... 6D-4
- Pinion Boot, Rack and,  
Manual Steering Gear, Unit Repair ..... 6D-12
- Pinion Boot, Rack and, Power Steering  
Gear, Unit Repair ..... 6C-20
- Pinion Clearance Check, Reaction Carrier,  
4T40-E Automatic Transaxle,  
Unit Repair ..... 5A-218
- Pinion End Play Check, Final Drive,  
4T40-E Automatic Transaxle,  
Unit Repair ..... 5A-202
- Pinion Gear Clearance Check, Input Carrier,  
4T40-E Automatic Transaxle,  
Unit Repair ..... 5A-212
- Pinion Shaft, Manual Steering Gear,  
Unit Repair ..... 6D-16
- Pinion, Manual Rack and ..... 6D-20
- Pinion, Power Rack and ..... 6C-30
- Pinion, Rack and, Manual Steering Gear,  
Unit Repair ..... 6D-8
- Pinion, Rack and, Power Steering Gear,  
Unit Repair ..... 6C-20
- Pipe, Connecting, Engine Exhaust ..... 1G-12
- Pipe, Exhaust, On-Vehicle Service ..... 1G-9
- Pipes Assemble, Oil Feed, 4T40-E  
Automatic Transaxle, Unit Repair ..... 5A-261
- Pipes, Hoses and, Power Steering System ..... 6A-5
- Pipes, Oil Cooler, 4T40-E Automatic  
Transaxle, On-Vehicle Service ..... 5A-166
- Pistons and Rods, SOHC Engine  
Mechanical, On-Vehicle Service ..... 1C-70
- Plate and Gasket Removal, Channel,  
4T40-E Automatic Transaxle,  
Unit Repair ..... 5A-187
- Plate and Gasket Removal, Spacer,  
4T40-E Automatic Transaxle,  
Unit Repair ..... 5A-186
- Plate and Gaskets Install, Spacer,  
4T40-E Automatic Transaxle,  
Unit Repair ..... 5A-243
- Plate Assembly Assemble, Channel,  
4T40-E Automatic Transaxle,  
Unit Repair ..... 5A-241
- Plate Assembly Disassemble, Channel,  
4T40-E Automatic Transaxle,  
Unit Repair ..... 5A-240
- Plate Assembly Installation, Channel,  
4T40-E Automatic Transaxle,  
Unit Repair ..... 5A-242
- Plate, Backing, Rear Drum Brakes ..... 4E-13
- Plates Removal, Second Clutch,  
4T40-E Automatic Transaxle,  
Unit Repair ..... 5A-189
- Poor Connections, Intermittents and,  
Antilock Brake System ..... 4F-16
- Poor Fuel Economy, Symptom Diagnosis ..... 1F-283
- Porosity Repair, Case,  
4T40-E Automatic Transaxle, Diagnosis ..... 5A-55
- Porosity Repair, Case,  
4T40-E Automatic Transaxle,  
On-Vehicle Service ..... 5A-145
- Position Sensor (Typical), Crankshaft,  
Engine Controls, On-Vehicle Service ..... 1F-310
- Position Sensor (Typical), Throttle,  
Engine Controls, On-Vehicle Service ..... 1F-299
- Position Sensor, Crankshaft,  
Engine Controls ..... 1F-313
- Position Sensor, Throttle,  
Engine Controls ..... 1F-315
- Position, Tail and License Lamps Circuit,  
Lighting Systems, Schematic and  
Routing Diagrams ..... 9B-11
- Positive Crankcase Ventilation System  
Operation, Engine Controls ..... 1F-315
- Power Antenna ..... 9F-14
- Power Antenna Mast, On-Vehicle Service ..... 9F-12

Power Antenna Motor/Manual Antenna, On-Vehicle Service .....	9F-13
Power Booster .....	4C-9
Power Booster Assembly, On-Vehicle Service ....	4C-3
Power Booster Functional Check, Diagnosis .....	4C-1
Power Distribution Schematic, Body Wiring System .....	9A-3
Power Door Locks (Three-Door Hatchback), Doors, Schematic and Routing Diagrams .....	9P-3
Power Door Locks (Five-Door Hatchback), Doors, Schematic and Routing Diagrams .....	9P-4
Power Door Locks, Doors .....	9P-40
Power Door Locks, Doors, Schematic and Routing Diagrams .....	9P-2
Power Rack and Pinion .....	6C-30
Power Rack and Pinion Steering Gear Bench Testing, Diagnosis .....	6C-5
Power Rack and Pinion Steering Gear, Diagnosis .....	6C-3
Power Steering Pump .....	6B-23
Power Steering Pump Diagnosis .....	6B-2
Power Steering System .....	6A-10
Power Steering System Leak Test, Diagnosis .....	6A-2
Power Steering System Pressure Test, Diagnosis .....	6A-2
Power Steering System, Bleeding the, On-Vehicle Service .....	6A-3
Power Sunroof Control Switch, Interior Courtesy/, Roof, On-Vehicle Service .....	9Q-8
Power Sunroof Control Switch, Roof .....	9Q-16
Power Sunroof System, Roof, Schematic and Routing Diagrams .....	9Q-2
Power Sunroof, Roof .....	9Q-16
Power Sunroof, Roof, Diagnosis .....	9Q-3
Power Sunroof, Roof, On-Vehicle Service .....	9Q-5
Power Window Regulator, Doors, On-Vehicle Service .....	9P-30
Power Windows (Front and Rear), Doors, Schematic and Routing Diagrams .....	9P-6
Power Windows (Front Only), Doors, Schematic and Routing Diagrams .....	9P-5
Power Windows, Doors .....	9P-40
Power Windows, Doors, Diagnosis .....	9P-7
Power, Lack of, Sluggishness, or Sponginess, Engine Controls, Diagnosis .....	1F-277
Precautions, General, Supplemental Inflatable Restraints (SIR) .....	8B-53
Preliminary Inspection, Wheel Alignment, Diagnosis .....	2B-8
Pressure-Temperature Relationship of R-134a, Manual Control Heating, Ventilation, and Air Conditioning System .....	7B-13
Pressure Bleeding the Brakes, Hydraulic Brakes .....	4A-16
Pressure Check (1.3L and 1.5L SOHC IEFI-6), Manifold Absolute, Engine Controls, Diagnosis .....	1F-64
Pressure Check (1.3L SOHC and 1.6L DOHC ITMS-6F), Manifold Absolute, Engine Controls, Diagnosis .....	1F-66
Pressure Control Solenoid Valve (PS Sol. Valve) 4T40-E Automatic Transaxle .....	5A-270
Pressure Control Solenoid, 4T40-E Automatic Transaxle, On-Vehicle Service .....	5A-164
Pressure Conversion Specifications, Inflation .....	2E-2
Pressure Regulator (DOHC), Fuel, Engine Controls, On-Vehicle Service .....	1F-297
Pressure Regulator (SOHC), Fuel, Engine Controls, On-Vehicle Service .....	1F-296
Pressure Relief Valve, Manual Control Heating, Ventilation, and Air Conditioning System, Unit Repair .....	7B-62
Pressure Relief Vent, Interior Trim .....	9G-30
Pressure Sensor (Typical), Manifold Absolute, Engine Controls, On-Vehicle Service .....	1F-305
Pressure Sensor, Manifold Absolute, Engine Controls .....	1F-316
Pressure Specifications, Tire Size and .....	2E-1
Pressure Switch Assembly Removal, 4T40-E Automatic Transaxle, Unit Repair .....	5A-185
Pressure Switch Assembly Resistance Check, 4T40-E Automatic Transaxle, Diagnosis .....	5A-53
Pressure Test Chart (R-134a System), Manual Control Heating, Ventilation, and Air Conditioning System .....	7B-19
Pressure Test, Fuel System, Engine Controls, Diagnosis .....	1F-52
Pressure Test, Power Steering System, Diagnosis .....	6A-2
Prop Rod, Hood, Body Front End, On-Vehicle Service .....	9R-5
Proportioning Valve, Checking Brake, Master Cylinder .....	4B-1
Proportioning Valves, Master Cylinder .....	4B-11
Proportioning Valves, Master Cylinder, On-Vehicle Service .....	4B-7
Pulley, DOHC Pump Drive, Power Steering Pump, On-Vehicle Service .....	6B-6
Pulley, SOHC Pump Drive, Power Steering Pump, On-Vehicle Service .....	6B-4
Pump Assembly Installation, Oil, 4T40-E Automatic Transaxle, Unit Repair .....	5A-254
Pump Assembly, DOHC, Power Steering Pump, On-Vehicle Service .....	6B-14
Pump Assembly, Oil, 4T40-E Automatic Transaxle, Component Locator .....	5A-20
Pump Assembly, SOHC, Power Steering Pump, On-Vehicle Service .....	6B-9

Pump Body Oil Channels, 4T40-E Automatic Transaxle, Component Locator .....	5A-44
Pump Clean and Inspect, Oil, 4T40-E Automatic Transaxle, Unit Repair .....	5A-254
Pump Diagnosis, Power Steering .....	6B-2
Pump Drive Belt, Power Steering Pump, On-Vehicle Service .....	6B-4
Pump Drive Pulley, DOHC, Power Steering Pump, On-Vehicle Service .....	6B-6
Pump Drive Pulley, SOHC, Power Steering Pump, On-Vehicle Service .....	6B-4
Pump Relay Circuit Check (1.3L and 1.5L SOHC IEFI-6), Fuel, Engine Controls, Diagnosis .....	1F-56
Pump Relay Circuit Check (1.3L SOHC and 1.6L DOHC ITMS-6F), Fuel, Engine Controls, Diagnosis .....	1F-60
Pump(s), Windshield Washer, On-Vehicle Service .....	9D-17
Pump, Coolant, Engine Cooling .....	1D-21
Pump, Coolant, Engine, Cooling, On-Vehicle Service .....	1D-11
Pump, Fuel, Engine Controls, On-Vehicle Service .....	1F-291
Pump, Oil, SOHC Engine Mechanical .....	1C-95
Pump, Oil, SOHC Engine Mechanical, On-Vehicle Service .....	1C-42
Pump, Power Steering .....	6B-23
Pump, Power Steering Pump, Unit Repair .....	6B-22

## Q

Quarter Window (Three-Door Hatchback), Movable, On-Vehicle Service .....	9L-16
---	-------

## R

Rack and Pinion Assembly (Left-Hand Drive), Power Steering Gear, On-Vehicle Service .....	6C-6
Rack and Pinion Assembly (Right-Hand Drive), Power Steering Gear, On-Vehicle Service .....	6C-9
Rack and Pinion Assembly, Manual Steering Gear, On-Vehicle Service .....	6D-4
Rack and Pinion Boot, Manual Steering Gear, Unit Repair .....	6D-12
Rack and Pinion Boot, Power Steering Gear, Unit Repair .....	6C-20
Rack and Pinion Steering Gear Bench Testing, Power, Diagnosis .....	6C-5
Rack and Pinion Steering Gear, Manual, Diagnosis .....	6D-3
Rack and Pinion Steering Gear, Power, Diagnosis .....	6C-3
Rack and Pinion, Manual .....	6D-20

Rack and Pinion, Manual Steering Gear, Unit Repair .....	6D-8
Rack and Pinion, Power .....	6C-30
Rack and Pinion, Power Steering Gear, Unit Repair .....	6C-20
Rack Bearing Preload On-Vehicle Adjustment, Manual Steering Gear .....	6D-7
Rack Bearing Preload On-Vehicle Adjustment, Power Steering Gear .....	6C-18
Rack Bearing, Manual Steering Gear, Unit Repair .....	6D-14
Rack Bushing, Manual Steering Gear, Unit Repair .....	6D-18
Rack, Manual Steering Gear, Unit Repair .....	6D-17
Radial Tire Lead/Pull, Wheel Alignment, Diagnosis .....	2B-3
Radiator Grille, Body Front End, On-Vehicle Service .....	9R-9
Radiator, Engine Cooling .....	1D-21
Radiator, Engine Cooling, On-Vehicle Service .....	1D-16
Radiator/Fan, Engine Cooling, Component Locator .....	1D-5
Radio, Stereo Cassette AM/FM, Diagnosis .....	9F-3
Radius, Scrub, Wheel Alignment .....	2B-9
Range Reference Chart, 4T40-E Automatic Transaxle .....	5A-268
Range Reference, Specifications, 4T40-E Automatic Transaxle .....	5A-6
Ratcheting Noise, 4T40-E Automatic Transaxle, Symptom Diagnosis .....	5A-72
Ratings, Engine Electrical .....	1E-55
Rattle Diagnosis, Squeak and .....	9K-1
Rattle Repair, Squeak and, On-Vehicle Service .....	9K-3
Reaction Carrier Assemble, Direct/Coast Clutch, 4T40-E Automatic Transaxle, Unit Repair .....	5A-219
Reaction Carrier Assembly, 4T40-E Automatic Transaxle, Component Locator .....	5A-25
Reaction Carrier Disassemble, Direct/Coast Clutch, 4T40-E Automatic Transaxle, Unit Repair .....	5A-213
Reaction Carrier Install, Direct/Coast Clutch, 4T40-E Automatic Transaxle, Unit Repair .....	5A-224
Reaction Carrier Pinion Clearance Check, 4T40-E Automatic Transaxle, Unit Repair .....	5A-218
Reaction Gear Assembly Removal, Input Carrier and, 4T40-E Automatic Transaxle, Unit Repair .....	5A-191
Reaction Gear Set Removal, Direct/Coast Clutch and, 4T40-E Automatic Transaxle, Unit Repair .....	5A-190
Reaction Internal Gear, Input Carrier Assemble, 4T40-E Automatic Transaxle, Unit Repair .....	5A-213



Reaction Internal Gear, Input Carrier Disassemble, 4T40-E Automatic Transaxle, Unit Repair .....	5A-212
Reaction Internal Gear, Input Carrier Install, 4T40-E Automatic Transaxle, Unit Repair .....	5A-213
Rear Axle Assembly, Rear Suspension .....	2D-8
Rear Axle with ABS, Unit Repair .....	2D-15
Rear Axle without ABS, Unit Repair .....	2D-15
Rear Bumper Energy Absorber, On-Vehicle Service .....	9O-9
Rear Bumper Fascia, On-Vehicle Service .....	9O-5
Rear Bumper Impact Bar, On-Vehicle Service .....	9O-10
Rear Camber Check, Wheel Alignment, Diagnosis .....	2B-8
Rear Center Seat Belt, Two-Point Lap .....	8A-20
Rear Center Seat Belt, Two-Point Lap, On-Vehicle Service .....	8A-18
Rear Compartment Security Cover (Hatchback), Interior Trim .....	9G-30
Rear Deck Lid (Notchback) Body Rear End .....	9S-15
Rear Deck Lid (Notchback), Body Rear End, On-Vehicle Service .....	9S-4
Rear Deck Lid Remote Cable and Handle, Body Rear End, On-Vehicle Service .....	9S-6
Rear Door Assembly, Doors, On-Vehicle Service .....	9P-32
Rear Door Glass Run, Doors, On-Vehicle Service .....	9P-17
Rear Door Glass, On-Vehicle Service .....	9L-14
Rear Door Interior Garnish Molding, Interior Trim, On-Vehicle Service .....	9G-13
Rear Door Lock, Childproof, Doors .....	9P-40
Rear Door Lock, Childproof, Doors, On-Vehicle Service .....	9P-23
Rear Door Secondary Weatherstrip, Doors, On-Vehicle Service .....	9P-19
Rear Door Trim Panel, Interior Trim, On-Vehicle Service .....	9G-5
Rear Fog Lamps Circuit (Without Front Fog Lamps), Lighting Systems, Schematic and Routing Diagrams .....	9B-7
Rear Fog Lamps Circuit, Front and, Lighting Systems, Schematic and Routing Diagrams .....	9B-5
Rear Fog/Backup Lamps (Hatchback), Lighting Systems, On-Vehicle Service .....	9B-41
Rear Fog/Backup Lamps (Notchback), Lighting Systems, On-Vehicle Service .....	9B-40
Rear Harness Routing, Body Wiring System, Schematic and Routing Diagrams .....	9A-11
Rear Head, Gasket, Valve Plate, Reed Plate, and O-Ring, Manual Control Heating, Ventilation, and Air Conditioning System, Unit Repair .....	7B-64
Rear Heater, Heating and Ventilation System .....	7A-23
Rear Heating Duct, Airflow Through Vents with, Heating and Ventilation System, Schematic and Routing Diagrams .....	7A-3
Rear Muffler, On-Vehicle Service .....	1G-7
Rear Outboard Seat Belt, Three-Point ELR .....	8A-20
Rear Outboard Seat Belt, Three-Point ELR, On-Vehicle Service .....	8A-16
Rear Quarter Trim Panel (Notchback), Luggage Compartment, Interior Trim, On-Vehicle Service .....	9G-28
Rear Rocker Trim Panel, Interior Trim, On-Vehicle Service .....	9G-17
Rear Seat Cushion, Seats, On-Vehicle Service .....	9H-8
Rear Seatback Lock Assembly, On-Vehicle Service .....	9H-13
Rear Seatback Lock Striker, On-Vehicle Service .....	9H-11
Rear Seatback, On-Vehicle Service .....	9H-9
Rear Seatback, Split, On-Vehicle Service .....	9H-10
Rear Speakers (Hatchback), On-Vehicle Service .....	9F-12
Rear Speakers (Notchback), On-Vehicle Service .....	9F-10
Rear Speakers, Front and .....	9F-14
Rear Suspension .....	2D-16
Rear Timing Belt Cover, SOHC Engine Mechanical, On-Vehicle Service .....	1C-59
Rear Toe Check, Wheel Alignment, Diagnosis .....	2B-8
Rear Trim Panel, Luggage Compartment, Interior Trim, On-Vehicle Service .....	9G-29
Rear Wheel Speed Sensor Jumper Harness, Antilock Brake System, On-Vehicle Service .....	4F-200
Rear Wheel Speed Sensor, Antilock Brake System, On-Vehicle Service .....	4F-200
Rear Wheel Speed Sensors and Rings, Antilock Brake System .....	4F-213
Rear Window and Outside Rearview Mirror Defogger, Schematic and Routing Diagrams .....	9L-2
Rear Window Defogger Braided Lead Wire Repair, On-Vehicle Service .....	9L-13
Rear Window Defogger Grid Line Repair, On-Vehicle Service .....	9L-11
Rear Window Defogger Grid Line, Testing, Diagnosis .....	9L-3
Rear Window Glass, On-Vehicle Service .....	9L-9
Rear Window Washer Nozzle, On-Vehicle Service .....	9D-20
Rear Window Washer System (Hatchback), Diagnosis .....	9D-10
Rear Window Wiper (Hatchback), Diagnosis .....	9D-9
Rear Window Wiper and Washer System, Schematic and Routing Diagrams .....	9D-3

- Rear Window Wiper Arm,  
On-Vehicle Service ..... 9D-19
- Rear Window Wiper Motor,  
On-Vehicle Service ..... 9D-19
- Rear Window Wiper/Washer System ..... 9D-21
- Rearview Mirror, Inside ..... 9L-21
- Rearview Mirror, Inside, On-Vehicle Service .... 9L-18
- Rearview Mirror, Outside ..... 9L-21
- Rearview Mirrors, Electric Control Outside,  
Schematic and Routing Diagrams ..... 9L-3
- Rearview Mirrors, Outside,  
On-Vehicle Service ..... 9L-19
- Receiver-Dryer, Manual Control Heating,  
Ventilation, and Air Conditioning System .... 7B-45
- Recommended Fluids and Lubricants,  
Owner Inspections and Services ..... 0B-15
- Recommended Materials for  
Waterleak Repairs, Specifications ..... 9I-1
- Reference Chart, Range,  
4T40-E Automatic Transaxle ..... 5A-268
- Refilling the Cooling System, Draining and,  
Engine Cooling, On-Vehicle Service ..... 1D-8
- Refrigerant Lines and Fittings,  
Handling of ..... 7B-22
- Refrigerant System, Leak Testing the,  
Manual Control Heating, Ventilation,  
and Air Conditioning System ..... 7B-14
- Refrigerant System, Testing the,  
Manual Control Heating, Ventilation,  
and Air Conditioning System ..... 7B-11
- Refrigerant, Handling ..... 7B-22
- Refrigeration System, Maintaining  
Chemical Stability in the ..... 7B-23
- Regulator (DOHC), Fuel Pressure,  
Engine Controls, On-Vehicle Service ..... 1F-297
- Regulator (SOHC), Fuel Pressure,  
Engine Controls, On-Vehicle Service ..... 1F-296
- Rehome Function, Motor,  
Antilock Brake System ..... 4F-188
- Relay Circuit Check (1.3L and 1.5L  
SOHC IEFI-6), Fuel Pump,  
Engine Controls, Diagnosis ..... 1F-56
- Relay Circuit Check (1.3L SOHC and  
1.6L DOHC ITMS-6F), Fuel Pump,  
Engine Controls, Diagnosis ..... 1F-60
- Release Cylinder, Clutch, Unit Repair ..... 5C-22
- Relief Vent, Pressure, Interior Trim ..... 9G-30
- Reminder Chime, Headlamps-On,  
Lighting Systems, Diagnosis ..... 9B-15
- Reminder Chime, Headlamps-On,  
Lighting Systems, Schematic and  
Routing Diagrams ..... 9B-8
- Reserve Capacity, Engine Electrical ..... 1E-55
- Reservoir, Brake Fluid, Master Cylinder ..... 4B-5
- Reservoir, Fluid, Power Steering System ..... 6A-4
- Reservoir, Windshield Washer,  
On-Vehicle Service ..... 9D-15
- Resistance Check, Pressure Switch  
Assembly, 4T40-E Automatic Transaxle,  
Diagnosis ..... 5A-53
- Resistor, Blower Motor, Manual Control  
Heating, Ventilation, and Air  
Conditioning System ..... 7B-30
- Reverse Clutch Functional Air Check,  
4T40-E Automatic Transaxle,  
Unit Repair ..... 5A-229
- Reverse Input and Second Roller Clutch  
Assemble, 4T40-E Automatic Transaxle,  
Unit Repair ..... 5A-228
- Reverse Input and Second Roller  
Clutch Disassemble, 4T40-E Automatic  
Transaxle, Unit Repair ..... 5A-225
- Reverse Input and Second Roller Clutch  
Install, 4T40-E Automatic Transaxle,  
Unit Repair ..... 5A-231
- Reverse Input Clutch Assembly,  
4T40-E Automatic Transaxle,  
Component Locator ..... 5A-23
- Reverse Input Clutch Housing Removal,  
4T40-E Automatic Transaxle,  
Unit Repair ..... 5A-190
- Reverse, 4T40-E Automatic Transaxle ..... 5A-278
- Reverse/Low Servo Assembly,  
4T40-E Automatic Transaxle,  
On-Vehicle Service ..... 5A-160
- Right-Hand Axle Seal Assemble,  
4T40-E Automatic Transaxle,  
Unit Repair ..... 5A-258
- Right-Hand Axle Seal Removal,  
4T40-E Automatic Transaxle,  
Unit Repair ..... 5A-195
- Right-Hand Drive Instrument Harness  
Routing, Body Wiring System,  
Schematic and Routing Diagrams ..... 9A-14
- Rings, Front Wheel Speed Sensor,  
Antilock Brake System ..... 4F-213
- Rings, Rear Wheel Speed Sensors and,  
Antilock Brake System ..... 4F-213
- Road Test Procedure,  
4T40-E Automatic Transaxle, Diagnosis ..... 5A-57
- Rocker Trim Panel, Front, Interior Trim,  
On-Vehicle Service ..... 9G-16
- Rocker Trim Panel, Rear, Interior Trim,  
On-Vehicle Service ..... 9G-17
- Rod, Control Shift, Five-Speed Manual  
Transaxle, On-Vehicle Service ..... 5B-25
- Rods, Pistons and, SOHC Engine Mechanical,  
On-Vehicle Service ..... 1C-70
- Roller Bearing, Manual Steering Gear,  
Unit Repair ..... 6D-17
- Roller Bearing, Tapered, Suspension  
Diagnosis ..... 2A-6
- Roller Clutch Disassemble, Forward Clutch  
Support, 4T40-E Automatic Transaxle,  
Unit Repair ..... 5A-203

Roof .....	9Q-16
Roof Molding, Exterior Trim, On-Vehicle Service .....	9M-3
Rotor Inspection, Front Disc Brakes .....	4D-1
Rotor, Front Disc Brakes .....	4D-6
Rough, Unstable, or Incorrect Idle, Stalling, Symptom Diagnosis .....	1F-284
Run-On, Dieseling, Engine Controls, Symptom Diagnosis .....	1F-287

## S

Sag, Stumble, Hesitation, Engine Controls, Symptom Diagnosis .....	1F-280
Scan Tool Data Table, Engine Controls, Specifications .....	1F-4
Scan Tool Diagnostics, Antilock Brake System .....	4F-16
Scheduled Maintenance Charts, Maintenance and Lubrication .....	0B-11
Scheduled Maintenance Services, Explanation of .....	0B-9
Scrub Radius, Wheel Alignment .....	2B-9
SDM, Supplemental Inflatable Restraints (SIR) .....	8B-51
SDM, Supplemental Inflatable Restraints (SIR), On-Vehicle Service .....	8B-44
Seal Assemble, Right-Hand Axle, 4T40-E Automatic Transaxle, Unit Repair .....	5A-258
Seal Install, Filter Assembly and, 4T40-E Automatic Transaxle, Unit Repair .....	5A-262
Seal Install, Side Cover Axle, 4T40-E Automatic Transaxle, Unit Repair .....	5A-257
Seal Installation, Torque Converter, 4T40-E Automatic Transaxle, Unit Repair .....	5A-197
Seal Removal, Right-Hand Axle, 4T40-E Automatic Transaxle, Unit Repair .....	5A-195
Seal Removal, Torque Converter, 4T40-E Automatic Transaxle, Unit Repair .....	5A-194
Seal Trim, Door, Doors, On-Vehicle Service .....	9P-37
Seal, Dash, Manual Steering Gear, Unit Repair .....	6D-14
Seal, Dash, Power Steering Gear, Unit Repair .....	6C-22
Sealed Wheel Bearing Diagnosis, Suspension Diagnosis .....	2A-6
Sealing, Front End, Body Front End, On-Vehicle Service .....	9R-2
Seals and Upper Bearing, Stub Shaft, Power Steering Gear, Unit Repair .....	6C-24

Seals Installation, Transaxle Cooler Line, 4T40-E Automatic Transaxle, Unit Repair .....	5A-197
Seals, Power Steering Pump .....	6B-23
Seat Adjuster, Front, On-Vehicle Service .....	9H-6
Seat Belt (Three-Door Hatchback), Three-Point ELR, Front, On-Vehicle Service .....	8A-7
Seat Belt (Three-Door Hatchback), Three-Point WLR/GCC, Front, On-Vehicle Service .....	8A-13
Seat Belt (With Airbag), Three-Point ELR Front .....	8A-20
Seat Belt (With Airbag), Three-Point ELR Front, On-Vehicle Service .....	8A-5
Seat Belt Height Adjuster, Front, On-Vehicle Service .....	8A-15
Seat Belt Warning Lamp is Inoperative, Diagnosis .....	8A-3
Seat Belt Warning, Driver, Schematic and Routing Diagrams .....	8A-2
Seat Belt, Three-Point ELR Rear Outboard .....	8A-20
Seat Belt, Three-Point ELR Rear Outboard, On-Vehicle Service .....	8A-16
Seat Belt, Three-Point WLR Front .....	8A-20
Seat Belt, Three-Point WLR/GCC, Front, On-Vehicle Service .....	8A-10
Seat Belt, Two-Point Lap Rear Center .....	8A-20
Seat Belt, Two-Point Lap Rear Center, On-Vehicle Service .....	8A-18
Seat Covers, Seats, On-Vehicle Service .....	9H-13
Seat Cushion, Front, On-Vehicle Service .....	9H-5
Seat Cushion, Rear, Seats, On-Vehicle Service .....	9H-8
Seat Trim, Front, Seats, On-Vehicle Service ....	9H-7
Seat, Front Bucket, On-Vehicle Service .....	9H-2
Seatback Lock Assembly, Rear, On-Vehicle Service .....	9H-13
Seatback Lock Striker, Rear, On-Vehicle Service .....	9H-11
Seatback, Front, On-Vehicle Service .....	9H-4
Seatback, Rear, On-Vehicle Service .....	9H-9
Seatback, Split Rear, On-Vehicle Service .....	9H-10
Seats .....	9H-15
Second and Third Gears Only, 4T40-E Automatic Transaxle, Symptom Diagnosis .....	5A-72
Second Clutch Functional Air Check, 4T40-E Automatic Transaxle, Unit Repair .....	5A-236
Second Clutch Plate Installation, 4T40-E Automatic Transaxle, Unit Repair .....	5A-231
Second Clutch Plates Removal, 4T40-E Automatic Transaxle, Unit Repair .....	5A-189

- Second Gear Only, 4T40-E Automatic Transaxle, Symptom Diagnosis ..... 5A-69
- Second Gear, Manual Second, 4T40-E Automatic Transaxle ..... 5A-294
- Second Gear, Overdrive Range, 4T40-E Automatic Transaxle ..... 5A-284
- Second Roller Clutch Assemble, Reverse Input and, 4T40-E Automatic Transaxle, Unit Repair ..... 5A-228
- Second Roller Clutch Disassemble, Reverse Input and, 4T40-E Automatic Transaxle, Unit Repair ..... 5A-225
- Second Roller Clutch Install, Reverse Input and, 4T40-E Automatic Transaxle, Unit Repair ..... 5A-231
- Second/Fourth Servo Assembly, 4T40-E Automatic Transaxle, On-Vehicle Service ..... 5A-160
- Secondary Latch, Hood, Body Front End, On-Vehicle Service ..... 9R-6
- Security Cover (Hatchback), Rear Compartment, Interior Trim ..... 9G-30
- Security System, Audio ..... 9F-14
- Self-Diagnostics, Antilock Brake System ..... 4F-16
- Sensing and Diagnostic Module (SDM), Supplemental Inflatable Restraints (SIR), On-Vehicle Service ..... 8B-44
- Sensing and Diagnostic Module (SDM), Supplemental Inflatable Restraints (SIR) ..... 8B-51
- Sensor (DOHC), Coolant Temperature, Engine Controls, On-Vehicle Service ..... 1F-299
- Sensor (SOHC), Coolant Temperature, Engine Controls, On-Vehicle Service ..... 1F-298
- Sensor (Typical), Crankshaft Position, Engine Controls, On-Vehicle Service ..... 1F-310
- Sensor (Typical), Manifold Absolute Pressure, Engine Controls, On-Vehicle Service ..... 1F-305
- Sensor (Typical), Manifold Air Temperature, Engine Controls, On-Vehicle Service ..... 1F-303
- Sensor (Typical), Oxygen, Engine Controls, On-Vehicle Service ..... 1F-302
- Sensor (Typical), Throttle Position, Engine Controls, On-Vehicle Service ..... 1F-299
- Sensor Jumper Harness, Front Wheel Speed, Antilock Brake System, On-Vehicle Service ..... 4F-198
- Sensor Jumper Harness, Rear Wheel Speed, Antilock Brake System, On-Vehicle Service ..... 4F-200
- Sensor Rings, Front Wheel Speed, Antilock Brake System ..... 4F-213
- Sensor, Coolant Temperature, Engine Controls ..... 1F-315
- Sensor, Crankshaft Position, Engine Controls ..... 1F-313
- Sensor, Fluid Level, Master Cylinder ..... 4B-11
- Sensor, Front Wheel Speed, Antilock Brake System, On-Vehicle Service ..... 4F-196
- Sensor, Knock, Engine Controls, ..... 1F-317
- Sensor, Manifold Air Temperature, Engine Controls ..... 1F-316
- Sensor, Oxygen, Engine Controls ..... 1F-315
- Sensor, Rear Wheel Speed, Antilock Brake System, On-Vehicle Service ..... 4F-200
- Sensor, Throttle Position, Engine Controls ..... 1F-315
- Sensor, Transmission Fluid Temperature (TFT), 4T40-E Automatic Transaxle ..... 5A-272
- Sensors and Rings, Rear Wheel Speed, Antilock Brake System ..... 4F-213
- Sensors, Front Wheel Speed, Antilock Brake System ..... 4F-213
- Serial Data Link, Immobilizer Anti-Theft System ..... 9T-13
- Service Precautions, Antilock Brake System ..... 4F-189
- Servo Assembly Assemble, Low/Reverse, 4T40-E Automatic Transaxle, Unit Repair ..... 5A-261
- Servo Assembly Disassemble, Low/Reverse, 4T40-E Automatic Transaxle, Unit Repair ..... 5A-261
- Servo Assembly, Second/Fourth, 4T40-E Automatic Transaxle, On-Vehicle Service ..... 5A-160
- Servo Disassemble, Assemble, and Install, Fourth Inter, 4T40-E Automatic Transaxle, Unit Repair ..... 5A-259
- Setback, Wheel Alignment ..... 2B-9
- Shaft and Cluster Gear, Input, Five-Speed Manual Transaxle, Unit Repair ..... 5B-55
- Shaft and Final Drive Assembly Removal, Output, 4T40-E Automatic Transaxle, Unit Repair ..... 5A-193
- Shaft and Insulators, Stabilizer, Front Suspension ..... 2C-8
- Shaft and Sleeve Assembly Install, Output, 4T40-E Automatic Transaxle, Unit Repair ..... 5A-257
- Shaft Seal Replacement, Manual Control Heating, Ventilation, and Air Conditioning System, Unit Repair ..... 7B-60
- Shaft Seals and Upper Bearing, Stub, Power Steering Gear, Unit Repair ..... 6C-24
- Shaft Sleeve Assemble and Install, Stub, 4T40-E Automatic Transaxle, Unit Repair ..... 5A-258
- Shaft Sleeve Assemble, Output, 4T40-E Automatic Transaxle, Unit Repair ..... 5A-256
- Shaft Sleeve Removal, Output, 4T40-E Automatic Transaxle, Unit Repair ..... 5A-188

Shaft, Detent Lever, Park Lock Installation, Manual, 4T40-E Automatic Transaxle, Unit Repair .....	5A-197	Sleeve Assemble, Output Shaft, 4T40-E Automatic Transaxle, Unit Repair .....	5A-256
Shaft, Detent Lever, Park Lock Removal, Manual, 4T40-E Automatic Transaxle, Unit Repair .....	5A-193	Sleeve Assembly Install, Output Shaft and, 4T40-E Automatic Transaxle, Unit Repair .....	5A-257
Shaft, Pinion, Manual Steering Gear, Unit Repair .....	6D-16	Sleeve Removal, Output Shaft, 4T40-E Automatic Transaxle, Unit Repair .....	5A-188
Shield, Splash, Front Disc Brakes .....	4D-7	Slipping/Soft Apply, No TCC/, 4T40-E Automatic Transaxle, Symptom, Diagnosis .....	5A-76
Shift Control Cable, 4T40-E Automatic Transaxle, On-Vehicle Service .....	5A-153	Slips in First Gear, No First Gear, 4T40-E Automatic Transaxle, Symptom, Diagnosis .....	5A-68
Shift Control Lever, 4T40-E Automatic Transaxle, On-Vehicle Service .....	5A-147	Slips in Fourth Gear, No Fourth Gear, 4T40-E Automatic Transaxle, Symptom, Diagnosis .....	5A-70
Shift Indicator Indicates Wrong Gear Selection, 4T40-E Automatic Transaxle, Symptom, Diagnosis .....	5A-74	Slips in Reverse, No Reverse, 4T40-E Automatic Transaxle, Diagnosis .....	5A-67
Shift Linkage Adjustment, Five-Speed Manual Transaxle, On-Vehicle Service .....	5B-14	Slips in Second Gear, No Second Gear, Symptom, 4T40-E Automatic Transaxle, Symptom, Diagnosis .....	5A-68
Shift Linkage, Five-Speed Manual Transaxle, Component Locators .....	5B-12	Slips in Third Gear, No Third Gear, 4T40-E Automatic Transaxle, Symptom, Diagnosis .....	5A-69
Shift Rod, Control, Five-Speed Manual Transaxle, On-Vehicle Service .....	5B-25	Soft Apply, No TCC/Slipping/, 4T40-E Automatic Transaxle, Symptom, Diagnosis .....	5A-76
Shift Solenoid, One-Two, 4T40-E Automatic Transaxle, On-Vehicle Service .....	5A-162	SOHC Pump Assembly, Power Steering Pump, On-Vehicle Service .....	6B-9
Shift Solenoid, Two-Three, 4T40-E Automatic Transaxle, On-Vehicle Service .....	5A-163	SOHC Pump Drive Pulley, Power Steering Pump, On-Vehicle Service .....	6B-4
Shift Solenoids: One-Two and Two-Three, 4T40-E Automatic Transaxle .....	5A-269	Solenoid (Typical), Canister Purge, Engine Controls, On-Vehicle Service .....	1F-309
Shift Speed Chart, Hydra-Matic, 4T40-E Automatic Transaxle, Diagnosis .....	5A-61	Solenoid (Typical), Exhaust Gas Recirculation Valve, Engine Controls, On-Vehicle Service .....	1F-307
Shift, Speed, Specifications, 4T40-E Automatic Transaxle .....	5A-7	Solenoid Fuse, ABS, On-Vehicle Service .....	4F-203
Shock Absorber, Rear Suspension, On-Vehicle Service .....	2D-3	Solenoid Test, Antilock Brake System, Diagnosis .....	4F-187
Shoe and Lining, Front Disc Brakes .....	4D-3	Solenoid Valve (PS Sol. Valve), Pressure Control, 4T40-E Automatic Transaxle .....	5A-270
Shoe and Lining, Rear Drum Brakes .....	4E-6	Solenoid Valve (TCC Sol. Valve), Torque Converter Clutch, 4T40-E Automatic Transaxle .....	5A-271
Side Cover Axle Seal Install, 4T40-E Automatic Transaxle, Unit Repair .....	5A-257	Solenoid, ABS .....	4F-193
Side Cover/Gaskets, Disassemble, Assemble, Install, 4T40-E Automatic Transaxle, Unit Repair .....	5A-254	Solenoid, One-Two Shift, 4T40-E Automatic Transaxle, On-Vehicle Service .....	5A-162
Side Turn Signal Lamps, Lighting Systems, Lighting Systems, On-Vehicle Service .....	9B-39	Solenoid, Pressure Control, 4T40-E Automatic Transaxle, On-Vehicle Service .....	5A-164
Signal Switch and Lever, Turn, Steering Wheel and Column, On-Vehicle Service .....	6E-7	Solenoid, TCC, 4T40-E Automatic Transaxle, On-Vehicle Service .....	5A-164
Sill Plate Cover (Notchback), Deck Lid, Interior Trim, On-Vehicle Service .....	9G-13	Solenoid, Two-Three Shift, 4T40-E Automatic Transaxle, On-Vehicle Service .....	5A-163
SIR Component Locator, Schematic and Routing Diagrams .....	8B-4		
SIR Fault Indication, Diagnosis .....	8B-5		
SIR System .....	8B-53		
SIR Warning Lamp .....	8B-52		

- Solenoids: One-Two and Two-Three,  
   Shift, 4T40-E Automatic Transaxle ..... 5A-269  
 Spacer Plate-to-Channel Plate Gasket,  
   4T40-E Automatic Transaxle,  
   Component Locator ..... 5A-41  
 Spacer Plate and Gasket Removal,  
   4T40-E Automatic Transaxle,  
   Unit Repair ..... 5A-186  
 Spacer Plate and Gaskets Install,  
   4T40-E Automatic Transaxle,  
   Unit Repair ..... 5A-243  
 Spacer Plate, 4T40-E Automatic Transaxle,  
   Component Locator ..... 5A-43  
 Spare Tire ..... 2E-11  
 Spark Knock/Detonation, Engine Controls,  
   Symptom Diagnosis ..... 1F-278  
 Speakers (Hatchback), Rear,  
   On-Vehicle Service ..... 9F-12  
 Speakers (Notchback), Rear,  
   On-Vehicle Service ..... 9F-10  
 Speakers, Diagnosis ..... 9F-5  
 Speakers, Front and Rear ..... 9F-14  
 Speakers, Front, On-Vehicle Service ..... 9F-9  
 Specifications, Engine Controls ..... 1F-4  
 Specifications, Standard Bolt ..... 0B-8  
 Speed Sensor (A/T OSS),  
   Automatic Transmission Input (Shaft),  
   4T40-E Automatic Transaxle ..... 5A-269  
 Speed Sensor (A/T OSS),  
   Automatic Transmission Output (Shaft),  
   4T40-E Automatic Transaxle ..... 5A-269  
 Speed Sensor Install, Input,  
   4T40-E Automatic Transaxle,  
   Unit Repair ..... 5A-237  
 Speed Sensor Installation, Output,  
   4T40-E Automatic Transaxle,  
   Unit Repair ..... 5A-259  
 Speed Sensor Jumper Harness,  
   Front Wheel, Antilock Brake System,  
   On-Vehicle Service ..... 4F-198  
 Speed Sensor Jumper Harness,  
   Rear Wheel, Antilock Brake System,  
   On-Vehicle Service ..... 4F-200  
 Speed Sensor Removal, Input,  
   4T40-E Automatic Transaxle,  
   Unit Repair ..... 5A-188  
 Speed Sensor Rings, Front Wheel,  
   Antilock Brake System ..... 4F-213  
 Speed Sensor, Front Wheel, Antilock  
   Brake System, On-Vehicle Service ..... 4F-196  
 Speed Sensor, Rear Wheel, Antilock  
   Brake System, On-Vehicle Service ..... 4F-200  
 Speed Sensors and Rings, Rear Wheel,  
   Antilock Brake System ..... 4F-213  
 Speed Sensors, Front Wheel,  
   Antilock Brake System ..... 4F-213  
 Speed Shift, Specifications,  
   4T40-E Automatic Transaxle ..... 5A-7  
 Speedometer-Driven Gear,  
   On-Vehicle Service ..... 5B-32  
 Speedometer, Instrumentation/Driver  
   Information, Diagnosis ..... 9E-13  
 Speedometer/Odometer/Trip Odometer,  
   Instrumentation/Driver Information,  
   On-Vehicle Service ..... 9E-34  
 Speedometer/Odometer/Trip Odometer,  
   Instrumentation/Driver Information ..... 9E-47  
 Splash Shield, Front Disc Brakes ..... 4D-7  
 Split Rear Seatback, On-Vehicle Service ..... 9H-10  
 Spring Removal, Actuator, 4T40-E  
   Automatic Transaxle, Unit Repair ..... 5A-187  
 Spring, Clock, Supplemental Inflatable  
   Restraints (SIR) ..... 8B-52  
 Spring, Clock, Supplemental Inflatable  
   Restraints (SIR), On-Vehicle Service ..... 8B-41  
 Spring/Strut Cartridge, Front,  
   Front Suspension, Unit Repair ..... 2C-20  
 Springs and Insulators, Rear Suspension ..... 2D-5  
 Springs Install, Accumulator,  
   4T40-E Automatic Transaxle,  
   Unit Repair ..... 5A-241  
 Sprocket Assembly Disassemble,  
   Driven, 4T40-E Automatic Transaxle,  
   Unit Repair ..... 5A-232  
 Sprocket Support Assemble, Drive,  
   4T40-E Automatic Transaxle,  
   Unit Repair ..... 5A-235  
 Sprocket Support Assembly Installation,  
   Driven, 4T40-E Automatic Transaxle,  
   Unit Repair ..... 5A-236  
 Sprocket Support Assembly/Second Clutch,  
   Driven, 4T40-E Automatic Transaxle,  
   Component Locator ..... 5A-22  
 Sprocket Support Removal, Drive,  
   4T40-E Automatic Transaxle,  
   Unit Repair ..... 5A-194  
 Sprockets and Drive Link Assemble,  
   Drive, Driven, 4T40-E Automatic  
   Transaxle, Unit Repair ..... 5A-239  
 Sprockets and Drive Link Disassemble,  
   Drive, Driven, 4T40-E Automatic  
   Transaxle, Unit Repair ..... 5A-238  
 Sprockets and Drive Link Install, Drive,  
   Driven, 4T40-E Automatic Transaxle,  
   Unit Repair ..... 5A-240  
 Sprockets, Drive Link Removal, Drive,  
   Driven, 4T40-E Automatic Transaxle,  
   Unit Repair ..... 5A-188  
 Squeak and Rattle Diagnosis ..... 9K-1  
 Squeak and Rattle Repair,  
   On-Vehicle Service ..... 9K-3  
 Stabilizer Shaft and Insulators,  
   Front Suspension ..... 2C-8  
 Stabilizer, Rear Suspension, ..... 2D-4  
 Stalling, Rough, Unstable, or Incorrect Idle,  
   Symptom Diagnosis ..... 1F-284

Stand Specifications, Watertest, Waterleaks . . . . .	9I-1	Stub Shaft Seals and Upper Bearing, Power Steering Gear, Unit Repair . . . . .	6C-24
Standard Steering Column, Unit Repair . . . . .	6E-25	Stub Shaft Sleeve Assemble and Install, 4T40-E Automatic Transaxle, Unit Repair . . . . .	5A-258
Start Switch, Neutral, 4T40-E Automatic Transaxle, On-Vehicle Service . . . . .	5A-156	Stumble, Hesitation, Sag, Engine Controls, Symptom Diagnosis . . . . .	1F-280
Starter Motor (0.8 Kilowatts), Engine Electrical, Unit Repair . . . . .	1E-19	Sun Visors, Roof . . . . .	9Q-16
Starter Motor (1.4 Kilowatts), Engine Electrical, Unit Repair . . . . .	1E-28	Sun Visors, Roof, On-Vehicle Service . . . . .	9Q-13
Starter Motor Noise, Engine Electrical, Diagnosis . . . . .	1E-9	Sunroof Control Switch, Interior Courtesy/ Power, Roof, On-Vehicle Service . . . . .	9Q-8
Starter Specifications, Engine Electrical . . . . .	1E-1	Sunroof Control Switch, Power, Roof . . . . .	9Q-16
Starter, Engine Electrical . . . . .	1E-57	Sunroof System, Power, Roof, Schematic and Routing Diagrams . . . . .	9Q-2
Starter, Engine Electrical, On-Vehicle Service . . . . .	1E-15	Sunroof, Power, Roof . . . . .	9Q-16
Starting System, Engine Electrical . . . . .	1E-57	Sunroof, Power, Roof, Diagnosis . . . . .	9Q-3
Starting System, Engine Electrical, Schematic and Routing Diagrams . . . . .	1E-3	Sunroof, Power, Roof, On-Vehicle Service . . . . .	9Q-5
Stationary Glass . . . . .	9L-21	Supplemental Inflatable Restraints (SIR), Fault Indication, Diagnosis . . . . .	8B-5
Steer, Torque, Suspension Diagnosis . . . . .	2A-6	Supplemental Inflatable Restraints System (SIR) Electrical Schematic . . . . .	8B-3
Steering Axis Inclination, Wheel Alignment . . . . .	2B-9	Support Assembly/Second Clutch, Driven Sprocket, 4T40-E Automatic Transaxle, Component Locator . . . . .	5A-22
Steering Column Diagnosis . . . . .	6E-2	Support Bearing, Front Suspension, Unit Repair . . . . .	2C-24
Steering Column, On-Vehicle Service . . . . .	6E-19	Surge Tank Cap Test, Engine Cooling, Diagnosis . . . . .	1D-3
Steering Column, Standard, Unit Repair . . . . .	6E-24	Surge Tank, Engine Cooling . . . . .	1D-21
Steering Column, Tilt, Unit Repair . . . . .	6E-29	Surge Tank, Engine Cooling, On-Vehicle Service . . . . .	1D-16
Steering Coupling Assembly, Flange and, Power Steering Gear, Unit Repair . . . . .	6C-21	Surges or Chuggles, Engine Controls, Diagnosis . . . . .	1F-275
Steering Gear Bench Testing, Power Rack and Pinion, Diagnosis . . . . .	6C-5	Suspension (DOHC Engine), Front . . . . .	2C-26
Steering Gear, Manual Rack and Pinion, Diagnosis . . . . .	6D-3	Suspension (SOHC Engine), Front . . . . .	2C-26
Steering Gear, Power Rack and Pinion, Diagnosis . . . . .	6C-3	Suspension, Front, Component Locator . . . . .	2C-6
Steering Pump Diagnosis, Power . . . . .	6B-2	Suspension, Rear . . . . .	2D-16
Steering Pump, Power . . . . .	6B-23	Symptom Diagnosis, Five-Speed Manual Transaxle . . . . .	5B-6
Steering System, Power . . . . .	6A-10	System Check (1.3L and 1.5L SOHC IEFI-6), Diagnostic, Engine Controls, Diagnosis . . . . .	1F-22
Steering Wheel and Column . . . . .	6E-42	System Check (1.3L SOHC and 1.6L DOHC ITMS-6F), Diagnostic, Engine Controls, Diagnosis . . . . .	1F-24
Steering Wheel with SIR, Steering Wheel and Column, On-Vehicle Service . . . . .	6E-15	System Check, Supplemental Inflatable Restraints (SIR), Diagnosis . . . . .	8B-6
Steering Wheel without SIR, Steering Wheel and Column, On-Vehicle Service . . . . .	6E-13		
Stereo Cassette AM/FM Radio . . . . .	9F-14		
Stereo Cassette AM/FM Radio, Diagnosis . . . . .	9F-3		
Stoplamp Switch, Hydraulic Brakes . . . . .	4A-20		
Stoplamps Circuit, Lighting Systems, Schematic and Routing Diagrams . . . . .	9B-12		
Straight-Ahead Check, Manual Steering Gear, Diagnosis . . . . .	6D-3		
Straight-Ahead Check, Power Steering Gear, On-Vehicle Service . . . . .	6C-18		
Strut Assembly, Knuckle/, Front Suspension, On-Vehicle Service . . . . .	2C-9		
Strut Cartridge, Front Spring/, Front Suspension, Unit Repair . . . . .	2C-20		
Strut Dampener, Front Suspension, Diagnosis . . . . .	2C-4		
Stub Shaft Removal, 4T40-E Automatic Transaxle, Unit Repair . . . . .	5A-182		

## T

Table, Scan Tool Data, Engine Controls, Specifications . . . . .	1F-4
Tachometer (Deluxe Cluster), Instrumentation/Driver Information . . . . .	9E-47
Tachometer, Instrumentation/Driver Information, On-Vehicle Service . . . . .	9E-33
Tachometer, Instrumentation/Driver Information, Diagnosis . . . . .	9E-14

Tail and License Lamps Circuit, Position, Lighting Systems, Schematic and Routing Diagrams .....	9B-11
Tailamps (Hatchback), Lighting Systems, Lighting Systems, On-Vehicle Service .....	9B-39
Tailamps (Notchback), Lighting Systems, Lighting Systems, On-Vehicle Service .....	9B-38
Tailamps, Lighting Systems .....	9B-52
Tailamps, Lighting Systems, Diagnosis .....	9B-21
Tank, Fuel, Engine Controls, On-Vehicle Service .....	1F-289
Tank, Surge, Engine Cooling .....	1D-21
Tank, Surge, Engine Cooling, On-Vehicle Service .....	1D-16
Tape Player and Cassette Care .....	9F-14
Tapered Roller Bearing, Suspension Diagnosis .....	2A-6
TCC Apply with Cold Engine, 4T40-E Automatic Transaxle, Symptom, Diagnosis .....	5A-77
TCC Shudder, 4T40-E Automatic Transaxle, Diagnosis .....	5A-60
TCC Shudder, 4T40-E Automatic Transaxle, Symptom, Diagnosis .....	5A-77
TCC Solenoid, 4T40-E Automatic Transaxle, On-Vehicle Service .....	5A-164
TCM Inputs that Affect the 4T40-E Transmission .....	5A-274
Technical Data, Specifications .....	0B-1
Temperature Cable Adjustment, Heating and Ventilation System .....	7A-16
Temperature Cable Adjustment, Manual Control Heating, Ventilation, and Air Conditioning System .....	7B-27
Temperature Gauge and Fuel Gauge (Deluxe Cluster), Instrumentation/Driver Information, On-Vehicle Service .....	9E-34
Temperature Gauge, Instrumentation/Driver Information .....	9E-47
Temperature Gauge, Instrumentation/Driver Information, Diagnosis .....	9E-18
Temperature Sensor (DOHC), Coolant, Engine Controls, On-Vehicle Service .....	1F-299
Temperature Sensor (SOHC), Coolant, Engine Controls, On-Vehicle Service .....	1F-298
Temperature Sensor, Coolant, Engine Controls .....	1F-315
Temperature Sensor, Engine Coolant .....	1D-21
Temperature Sensor, Engine Coolant, On-Vehicle Service .....	1D-19
Temperature Specifications, Heater .....	7A-1
Tension Relief Sequence, Gear, Antilock Brake System .....	4F-188
Test Equipment, Communication Between Immobilizer and, Immobilizer Anti-Theft System .....	9T-6
Testing the Refrigerant System, Manual Control Heating, Ventilation, and Air Conditioning System .....	7B-11
Tether Anchor, Child Seat .....	8A-20
Tether Anchor, Child Seat, On-Vehicle Service .....	8A-19
TFP Switch Install, Control Valve Assembly and, 4T40-E Automatic Transaxle, Unit Repair .....	5A-252
Thermostat Test, Engine Cooling, Diagnosis .....	1D-3
Thermostat, Engine Cooling .....	1D-21
Thermostat, Engine Cooling, On-Vehicle Service .....	1D-9
Thermostat/Coolant Pump (DOHC), Engine Cooling, Component Locator .....	1D-6
Thermostat/Coolant Pump (SOHC), Engine Cooling, Component Locator .....	1D-7
Third and Fourth Gears Only, 4T40-E Automatic Transaxle, Symptom Diagnosis .....	5A-71
Third Gear, Manual Third, 4T40-E Automatic Transaxle .....	5A-292
Third Gear, Overdrive Range, 4T40-E Automatic Transaxle .....	5A-286
Three-Point ELR Front Seat Belt (Three-Door Hatchback), On-Vehicle Service .....	8A-7
Three-Point ELR Front Seat Belt (With Airbag) .....	8A-20
Three-Point ELR Front Seat Belt (With Airbag), On-Vehicle Service .....	8A-5
Three-Point ELR Rear Outboard Seat Belt .....	8A-20
Three-Point ELR Rear Outboard Seat Belt, On-Vehicle Service .....	8A-16
Three-Point WLR Front Seat Belt .....	8A-20
Three-Point WLR/GCC Front Seat Belt (Three-Door Hatchback), On-Vehicle Service .....	8A-13
Three-Point WLR/GCC Front Seat Belt, On-Vehicle Service .....	8A-10
Throttle Body (Typical), Engine Controls, On-Vehicle Service .....	1F-300
Throttle Position Sensor (Typical), Engine Controls, On-Vehicle Service .....	1F-299
Throttle Position Sensor, Engine Controls .....	1F-315
Tie Rod, Inner, Manual Steering Gear, On-Vehicle Service .....	6D-6
Tie Rod, Inner, Power Steering Gear, On-Vehicle Service .....	6C-15
Tie Rod, Outer, Manual Steering Gear, On-Vehicle Service .....	6D-6
Tie Rod, Outer, Power Steering Gear, On-Vehicle Service .....	6C-14
Tilt Steering Column, Unit Repair .....	6E-29
Time Required, Charging, Engine Electrical .....	1E-56
Timing Belt Check and Adjust, SOHC Engine Mechanical, On-Vehicle Service .....	1C-31
Timing Belt Cover, Rear, SOHC Engine Mechanical, On-Vehicle Service .....	1C-59



Timing Belt, SOHC Engine Mechanical .....	1C-95	Transaxle Cooler Line Seal Removal, 4T40-E Automatic Transaxle, Unit Repair .....	5A-194
Timing Belt, SOHC Engine Mechanical, On-Vehicle Service .....	1C-36	Transaxle Cooler Line Seals Installation, 4T40-E Automatic Transaxle, Unit Repair .....	5A-197
Tire and Wheel Balancing .....	2E-9	Transaxle Definitions and Abbreviations, 4T40-E Automatic Transaxle .....	5A-265
Tire and Wheel Match-Mounting, Unit Repair .....	2E-7	Transaxle Functional Check Procedure, 4T40-E Automatic Transaxle, Diagnosis .....	5A-50
Tire Chain Usage .....	2E-10	Transaxle General Description, 4T40-E Automatic Transaxle .....	5A-266
Tire Diagnosis, Wheel Alignment .....	2B-2	Transaxle General Specifications, 4T40-E Automatic Transaxle .....	5A-5
Tire Label .....	2E-11	Transaxle Holding Fixture Assembly, 4T40-E Automatic Transaxle, Unit Repair .....	5A-181
Tire Lead/Pull, Radial, Wheel Alignment, Diagnosis .....	2B-3	Transaxle Identification Information, 4T40-E Automatic Transaxle .....	5A-19
Tire Mounting and Dismounting, Unit Repair .....	2E-8	Transaxle Mount, 4T40-E Automatic Transaxle, On-Vehicle Service .....	5A-167
Tire Size and Pressure Specifications .....	2E-1	Transaxle, Five-Speed Manual .....	5B-93
Tire, Spare .....	2E-11	Transmission Control Module (1 of 4), 4T40-E Automatic Transaxle, Schematic and Routing Diagrams .....	5A-15
Tires and ABS, Antilock Brake System .....	4F-212	Transmission Control Module (2 of 4), 4T40-E Automatic Transaxle, Schematic and Routing Diagrams .....	5A-16
Tires, All-Season .....	2E-10	Transmission Control Module (3 of 4), 4T40-E Automatic Transaxle, Schematic and Routing Diagrams .....	5A-17
Tires, Correcting Non-Uniform, Unit Repair .....	2E-7	Transmission Control Module (4 of 4), 4T40-E Automatic Transaxle, Schematic and Routing Diagrams .....	5A-18
Tires, Inflation of .....	2E-11	Transmission Control Module (TCM), 4T40-E Automatic Transaxle .....	5A-274
Tires, Passenger Metric Sized .....	2E-11	Transmission Electrical Connector, 4T40-E Automatic Transaxle .....	5A-273
Tires, Replacement .....	2E-10	Transmission Fluid Pressure Manual Valve Position Switch (TFP Val. Position Sw.), Automatic, 4T40-E Automatic Transaxle .....	5A-271
Toe Adjustment, Front, Wheel Alignment, Diagnosis .....	2B-8	Transmission Fluid Pressure Manual Valve Position Switch Resistance Check, Automatic, 4T40-E Automatic Transaxle, Diagnosis .....	5A-64
Toe Check, Rear, Wheel Alignment, Diagnosis .....	2B-8	Transmission Fluid Temperature (TFT) Sensor, 4T40-E Automatic Transaxle .....	5A-272
Toe, Wheel Alignment .....	2B-9	Transmission, TCM Inputs that Affect the .....	5A-274
Too Much Heat, Heating and Ventilation System .....	7A-11	Transponder, Ignition Key, Immobilizer Anti-Theft System, On-Vehicle Service .....	9T-8
Torque Converter Clutch, 4T40-E Automatic Transaxle, Diagnosis .....	5A-58	Trim Panel, Instrument Cluster, Instrumentation/Driver Information, On-Vehicle Service .....	9E-42
Torque Converter Clutch Solenoid Valve (TCC Sol. Valve), 4T40-E Automatic Transaxle .....	5A-271	Trip Odometer, Speedometer/Odometer/, Instrumentation/Driver Information, On-Vehicle Service .....	9E-33
Torque Converter Evaluation, 4T40-E Automatic Transaxle .....	5A-59	Trip Odometer, Speedometer/Odometer/, Instrumentation/Driver Information .....	9E-47
Torque Converter Installation, 4T40-E Automatic Transaxle, Unit Repair .....	5A-264		
Torque Converter Removal, 4T40-E Automatic Transaxle, Unit Repair .....	5A-181		
Torque Converter Seal Installation, 4T40-E Automatic Transaxle, Unit Repair .....	5A-197		
Torque Converter Seal Removal, 4T40-E Automatic Transaxle, Unit Repair .....	5A-194		
Torque Rod, Body Rear End, On-Vehicle Service .....	9S-8		
Torque Steer, Suspension Diagnosis .....	2A-6		
Transaxle Assembly, 4T40-E Automatic Transaxle, On-Vehicle Service .....	5A-172		
Transaxle Assembly, Five-Speed Manual Transaxle, On-Vehicle Service .....	5B-36		
Transaxle Brace, 4T40-E Automatic Transaxle, On-Vehicle Service .....	5A-178		
Transaxle Bracket, 4T40-E Automatic Transaxle, On-Vehicle Service .....	5A-169		
Transaxle Component and System Description, 4T40-E Automatic Transaxle .....	5A-266		

Tripot Seal, Inner, Automatic Transaxle Drive Axle, Unit Repair .....	3A-9
Trouble Code Diagnosis, Engine Controls .....	1F-22
Trouble Codes, Clearing, Engine Controls, Diagnosis .....	1F-22
Tube, Boot, Bushing and/or Bearing Ring, Gearshift, Five-Speed Manual Transaxle ....	5B-17
Turn and Hazard Lamps Circuit, Lighting Systems, Schematic and Routing Diagrams .....	9B-13
Turn Signal Lamps, Parking and, Lighting Systems .....	9B-52
Turn Signal Lamps, Side, Lighting Systems, Lighting Systems, On-Vehicle Service .....	9B-38
Turn Signal Switch and Lever, Steering Wheel and Column, On-Vehicle Service .....	6E-7
Turning Angle, Wheel Alignment .....	2B-9
Two-Piece Drum, Rear Drum Brakes .....	4E-5
Two-Point Lap Rear Center Seat Belt .....	8A-20
Two-Point Lap Rear Center Seat Belt, On-Vehicle Service .....	8A-18

## U

Under Covers, Engine, Frame and Underbody .....	9N-7
Under Covers, Engine, Frame and Underbody, On-Vehicle Service .....	9N-6
Underbody Dimensions (Hatchback), Frame and Underbody .....	9N-3
Underbody Dimensions (Notchback), Frame and Underbody .....	9N-1
Upper B-Pillar Trim Panel (Three-Door Hatchback), Interior Trim, On-Vehicle Service .....	9G-9
Upper B-Pillar Trim Panel, Interior Trim, On-Vehicle Service .....	9G-7
Upper Bearing, Stub Shaft Seals and, Power Steering Gear, Unit Repair .....	6C-24
Upper End, SOHC Engine Mechanical, Component Locator, .....	1C-8
Upper Garnish Molding, Hatchback Door, Interior Trim, On-Vehicle Service .....	9G-14
Usage Chart, Bulb, Lighting Systems, Specifications .....	9B-2

## V

V5 System Air Conditioning Diagnosis, Insufficient Cooling Diagnosis .....	7B-15
Vacuum Hose, Power Booster .....	4C-2
Valve (DOHC), Exhaust Gas Recirculation, Engine Controls, On-Vehicle Service .....	1F-306
Valve (SOHC), Exhaust Gas Recirculation, Engine Controls, On-Vehicle Service .....	1F-306
Valve (TCC Sol. Valve), Torque Converter Clutch Solenoid, 4T40-E Automatic Transaxle .....	5A-271

Valve (Typical), Idle Air Control, Engine Controls, On-Vehicle Service .....	1F-304
Valve Assembly and TFP Switch Install, Control, 4T40-E Automatic Transaxle, Unit Repair .....	5A-252
Valve Body-to-Spacer Plate Gasket, 4T40-E Automatic Transaxle, Component Locator .....	5A-37
Valve Body Assemble, 4T40-E Automatic Transaxle, Unit Repair .....	5A-248
Valve Body Assembly and Gasket Removal, Control, 4T40-E Automatic Transaxle, Unit Repair .....	5A-186
Valve Body Assembly, Control, 4T40-E Automatic Transaxle, Component Locator .....	5A-21
Valve Body Disassemble, Control, 4T40-E Automatic Transaxle, Unit Repair .....	5A-244
Valve Clip Removal, Manual, 4T40-E Automatic Transaxle, Unit Repair .....	5A-187
Valve Cover, SOHC Engine Mechanical, On-Vehicle Service .....	1C-12
Valve Install, Manual, 4T40-E Automatic Transaxle, Unit Repair .....	5A-242
Valve Install, Oil Level Control, 4T40-E Automatic Transaxle, Unit Repair .....	5A-263
Valve Plate, Reed Plate, and O-Ring, Rear Head, Gasket, Manual Control Heating, Ventilation and Air Conditioning System, Unit Repair .....	7B-64
Valve Position Switch (TFP Val. Position Sw.), Automatic Transmission Fluid Pressure Manual, 4T40-E Automatic Transaxle .....	5A-271
Valve Solenoid (Typical), Exhaust Gas Recirculation, Engine Controls, On-Vehicle Service .....	1F-307
Valve Train Components, Cylinder Head and, SOHC Engine Mechanical, Unit Repair .....	1C-76
Valve, (PS Sol. Valve), Pressure Control Solenoid, 4T40-E Automatic Transaxle .....	5A-270
Valve, Checking Brake Proportioning, Master Cylinder .....	4B-1
Valve, Exhaust Gas Recirculation, Engine Controls .....	1F-315
Valve, Hydraulic Modulator Bleeder, Antilock Brake System, On-Vehicle Service .....	4F-192
Valve, Idle Air Control, Engine Controls .....	1F-316
Valves, Proportioning, Master Cylinder .....	4B-11
Valves, Proportioning, Master Cylinder, On-Vehicle Service .....	4B-7
Variable Geometry Induction System Operation, Engine Controls .....	1F-314

Variable Geometry Induction System, Engine Controls, On-Vehicle Service .....	1F-305
Vehicle and Component Identification, General Description .....	0B-17
Vehicle Dimensions and Weights, Specifications .....	0B-6
Vehicle Lifting Procedures, General Description .....	0B-21
Vehicle Use, Normal, Maintenance and Lubrication .....	0B-9
Vent, Pressure Relief, Interior Trim .....	9G-30
Ventilation System Controls, Heating and .....	7A-13
Ventilation System Operation, Positive Crankcase, Engine Controls .....	1F-315
Ventilation System, Heating and .....	7A-24
Vents, Instrument Cluster Trim Panel, Instrumentation/Driver Information, On-Vehicle Service .....	9E-29
Vents, Instrument Panel, Instrumentation/Driver Information .....	9E-47
Vibration Diagnosis, Wheel Alignment .....	2B-5
Vibration Test Procedure, Flexplate/Torque Converter, 4T40-E Automatic Transaxle, Diagnosis .....	5A-60
Vibration, 4T40-E Automatic Transaxle, Symptom Diagnosis .....	5A-75
Visors, Sun, Roof .....	9Q-16
Visors, Sun, Roof, On-Vehicle Service .....	9Q-13
Voltage Load Test, Antilock Brake System ....	4F-187

## W

Warning Lamp is Inoperative, Seat Belt, Diagnosis .....	8A-3
Warning Lamp Operation, Hydraulic Brakes ....	4A-24
Warning Lamp Operation, Hydraulic Brakes, Diagnosis .....	4A-6
Washer Hoses, Windshield, On-Vehicle Service .....	9D-18
Washer Measurement and Installation, Selective, 4T40-E Automatic Transaxle, Unit Repair .....	5A-225
Washer Nozzle, Rear Window, On-Vehicle Service .....	9D-20
Washer Nozzles, Windshield, On-Vehicle Service .....	9D-17
Washer Pump(s), Windshield, On-Vehicle Service .....	9D-17
Washer Reservoir, Windshield, On-Vehicle Service .....	9D-15
Washer System (Hatchback), Rear Window, Diagnosis .....	9D-10
Washer System, Rear Window Wiper and, Schematic and Routing Diagrams .....	9D-3
Washer System, Windshield .....	9D-21
Washer System, Windshield Wipers and, Schematic and Routing Diagrams .....	9D-2
Washer System, Windshield, Diagnosis .....	9D-8

Waterleak Diagnosis .....	9I-2
Waterleak Repair, On-Vehicle Service .....	9I-5
Waterleak Repairs, Recommended Materials for, Specifications .....	9I-1
Watertest Stand Specifications, Waterleaks .....	9I-1
Weatherstrip, Body Rear End, On-Vehicle Service .....	9S-11
Weatherstrip, Door Opening, Doors, On-Vehicle Service .....	9P-38
Weatherstrip, Door, Doors, On-Vehicle Service .....	9P-36
Weatherstrip, Front Door Secondary, Doors, On-Vehicle Service .....	9P-18
Weatherstrip, Rear Door Secondary, Doors, On-Vehicle Service .....	9P-19
Weights, Vehicle Dimensions and, Specifications .....	0B-6
Wheel Alignment Specifications .....	2B-1
Wheel Balancing, Tire and .....	2E-9
Wheel Bearing Adjustment, Rear Suspension, On-Vehicle Service .....	2D-3
Wheel Bearing Diagnosis, Sealed, Suspension Diagnosis .....	2A-6
Wheel Cylinder Assembly, Rear Drum Brakes, On-Vehicle Service .....	4E-11
Wheel Cylinder, Rear Drum Brakes, Unit Repair .....	4E-14
Wheel Match- Mounting, Tire and, Unit Repair .....	2E-7
Wheel Porosity, Aluminum, Unit Repair .....	2E-4
Wheel Refinishing, Aluminum, Unit Repair .....	2E-5
Wheel Runout, Diagnosis .....	2E-2
Wheel, On-Vehicle Service .....	2E-3
Wheelhouse Trim Panel (Hatchback), Luggage Compartment, Interior Trim, On-Vehicle Service .....	9G-27
Wheelhouse Trim Panel (Notchback), Luggage Compartment, Interior Trim, On-Vehicle Service .....	9G-27
Wheels .....	2E-11
While Operating the Vehicle, Owner Inspections and Services .....	0B-13
Will Not Flash Service Engine Soon Lamp (1.3L and 1.5L SOHC IEFI-6), Engine Controls, Diagnosis .....	1F-48
Will Not Flash Service Engine Soon Lamp (1.3L SOHC and 1.6L DOHC ITMS-6F), Engine Controls, Diagnosis .....	1F-50
Window Wiper/Washer System, Rear .....	9D-21
Windnoise Diagnosis .....	9J-1
Windnoise Repair, On-Vehicle Service .....	9J-2
Window (Three-Door Hatchback), Movable Quarter, On-Vehicle Service .....	9L-16
Window Defogger Grid Line Repair, Rear, On-Vehicle Service .....	9L-11
Window Defogger Grid Line, Testing Rear, Diagnosis .....	9L-3
Window Glass, Rear, On-Vehicle Service .....	9L-9

- Window Regulator Handle, Manual, Doors,  
On-Vehicle Service ..... 9P-38
- Window Regulator, Manual Front, Doors,  
On-Vehicle Service ..... 9P-29
- Window Regulator, Manual Rear, Doors,  
On-Vehicle Service ..... 9P-30
- Window Regulator, Power, Doors,  
On-Vehicle Service ..... 9P-30
- Window Washer Nozzle, Rear,  
On-Vehicle Service ..... 9D-20
- Window Washer System (Hatchback),  
Rear, Diagnosis ..... 9D-10
- Window Wiper (Hatchback), Rear, Diagnosis .... 9D-9
- Window Wiper and Washer System, Rear,  
Schematic and Routing Diagrams ..... 9D-3
- Window Wiper Arm, Rear,  
On-Vehicle Service ..... 9D-19
- Window Wiper Motor, Rear,  
On-Vehicle Service ..... 9D-19
- Windows (Front and Rear), Power, Doors,  
Schematic and Routing Diagrams ..... 9P-6
- Windows (Front Only), Power, Doors,  
Schematic and Routing Diagrams ..... 9P-5
- Windows, Power, Doors ..... 9P-40
- Windows, Power, Doors, Diagnosis ..... 9P-7
- Windshield Washer Hoses,  
On-Vehicle Service ..... 9D-18
- Windshield Washer Nozzles,  
On-Vehicle Service ..... 9D-17
- Windshield Washer Pump(s),  
On-Vehicle Service ..... 9D-17
- Windshield Washer Reservoir,  
On-Vehicle Service ..... 9D-15
- Windshield Washer System ..... 9D-21
- Windshield Washer System, Diagnosis ..... 9D-8
- Windshield Wiper Arm, On-Vehicle Service .... 9D-11
- Windshield Wiper Blade Insert,  
On-Vehicle Service ..... 9D-14
- Windshield Wiper Blade,  
On-Vehicle Service ..... 9D-13
- Windshield Wiper Motor,  
On-Vehicle Service ..... 9D-11
- Windshield Wiper System ..... 9D-21
- Windshield Wipers and Washer System,  
Schematic and Routing Diagrams ..... 9D-2
- Windshield Wipers, Intermittent, Diagnosis ..... 9D-4
- Windshield, On-Vehicle Service ..... 9L-7
- Wiper (Hatchback), Rear Window, Diagnosis .... 9D-9
- Wiper Arm, Rear Window,  
On-Vehicle Service ..... 9D-19
- Wiper Arm, Windshield, On-Vehicle Service .... 9D-11
- Wiper Blade Insert, Windshield,  
On-Vehicle Service ..... 9D-14
- Wiper Blade, Windshield,  
On-Vehicle Service ..... 9D-13
- Wiper Motor, Rear Window,  
On-Vehicle Service ..... 9D-19
- Wiper Motor, Windshield, On-Vehicle Service .... 9D-11
- Wiper Switch and Lever, Steering  
Wheel and Column, On-Vehicle Service ..... 6E-9
- Wiper System, Windshield ..... 9D-21
- Wiper/Washer System, Rear Window ..... 9D-21
- Wire Color Chart, Body Wiring System,  
Schematic and Routing Diagrams ..... 9A-1
- Wire Harness Disconnect, 4T40-E  
Automatic Transaxle, Unit Repair ..... 5A-185
- Wire Repair, Rear Window Defogger  
Braided Lead, On-Vehicle Service ..... 9L-13
- Wiring Diagram (1.3L and 1.5L SOHC- 1 of 5)  
(IEFI-6 ECM), ECM, Schematic  
and Routing Diagrams ..... 1F-6
- Wiring Diagram (1.3L and 1.5L SOHC- 2 of 5)  
(IEFI-6 ECM), ECM, Schematic  
and Routing Diagrams ..... 1F-7
- Wiring Diagram (1.3L and 1.5L SOHC- 3 of 5)  
(IEFI-6 ECM), ECM, Schematic  
and Routing Diagrams ..... 1F-8
- Wiring Diagram (1.3L and 1.5L SOHC- 4 of 5)  
(IEFI-6 ECM), ECM, Schematic  
and Routing Diagrams ..... 1F-9
- Wiring Diagram (1.3L and 1.5L SOHC- 5 of 5)  
(IEFI-6 ECM), ECM, Schematic  
and Routing Diagrams ..... 1F-10
- Wiring Diagram (1.3L SOHC and 1.6L DOHC -  
1 of 5) (ITMS-6F ECM), ECM,  
Schematic and Routing Diagrams ..... 1F-11
- Wiring Diagram (1.3L SOHC and 1.6L DOHC -  
2 of 5) (ITMS-6F ECM), ECM,  
Schematic and Routing Diagrams ..... 1F-12
- Wiring Diagram (1.3L SOHC and 1.6L DOHC -  
3 of 5) (ITMS-6F ECM), ECM,  
Schematic and Routing Diagrams ..... 1F-13
- Wiring Diagram (1.3L SOHC and 1.6L DOHC -  
4 of 5) (ITMS-6F ECM), ECM,  
Schematic and Routing Diagrams ..... 1F-14
- Wiring Diagram (1.3L SOHC and 1.6L DOHC -  
5 of 5) (ITMS-6F ECM), ECM,  
Schematic and Routing Diagrams ..... 1F-15
- Wiring Diagram, 4T40-E Automatic  
Transaxle, Diagnosis ..... 5A-63
- Wiring Harness Assembly Connect, 4T40-E  
Automatic Transaxle, Unit Repair ..... 5A-253
- Wiring Harness Check, Internal,  
4T40-E Automatic Transaxle, Diagnosis ..... 5A-61
- Wiring Harness Installation, 4T40-E  
Automatic Transaxle, Unit Repair ..... 5A-237
- Wiring Harness Removal, 4T40-E  
Automatic Transaxle, Unit Repair ..... 5A-189
- Wiring Harness, Antilock Brake System ..... 4F-213
- Wiring Harness/Connectors, Supplemental  
Inflatable Restraints (SIR) ..... 8B-52
- Wiring System, Horn, Schematic and  
Routing Diagrams ..... 9C-2
- Wrong Gear Selection, Shift Indicator  
Indicates, 4T40-E Automatic  
Transaxle, Symptom, Diagnosis ..... 5A-74