

---

## SECTION 1C

# DOHC ENGINE MECHANICAL

**CAUTION** Do not use any tools or equipment that may damage the engine or its components. Use only the tools and equipment specified in this manual. Do not use any tools or equipment that may damage the engine or its components. Use only the tools and equipment specified in this manual.

## TABLE OF CONTENTS

|  |       |  |        |
|--|-------|--|--------|
| Specifications .....                         | 1C-2  | Camshaft Gears .....                   | 1C-55  |
| Engine Specifications .....                  | 1C-2  | Rear Timing Belt Cover .....           | 1C-57  |
| Fastener Tightening Specifications .....     | 1C-4  | Engine .....                           | 1C-59  |
| Special Tools .....                          | 1C-6  | Pistons and Rods .....                 | 1C-69  |
| Special Tools Table .....                    | 1C-6  | Unit Repair .....                      | 1C-74  |
| Component Locator .....                      | 1C-8  | Cylinder Head and Valve Train          |        |
| Upper End .....                              | 1C-8  | Components .....                       | 1C-74  |
| Lower End .....                              | 1C-10 | Crankshaft .....                       | 1C-84  |
| Maintenance and Repair .....                 | 1C-12 | Crankshaft Bearings and Connecting Rod |        |
| On-Vehicle Service .....                     | 1C-12 | Bearings - Gauging Plastic .....       | 1C-96  |
| Valve Cover .....                            | 1C-12 | General Description and System         |        |
| Cylinder Head and Gasket .....               | 1C-14 | Operation .....                        | 1C-100 |
| Camshafts .....                              | 1C-25 | Cylinder Head and Gasket .....         | 1C-100 |
| Timing Belt Check and Adjust .....           | 1C-29 | Crankshaft .....                       | 1C-100 |
| Timing Belt .....                            | 1C-33 | Timing Belt .....                      | 1C-100 |
| Engine Oil Pressure Inspection Procedure ... | 1C-39 | Oil Pump .....                         | 1C-100 |
| Oil Pump .....                               | 1C-40 | Oil Pan .....                          | 1C-100 |
| Oil Pan .....                                | 1C-44 | Exhaust Manifold .....                 | 1C-100 |
| Engine Mount .....                           | 1C-47 | Intake Manifold .....                  | 1C-100 |
| Intake Manifold .....                        | 1C-49 | Camshafts .....                        | 1C-100 |
| Exhaust Manifold .....                       | 1C-52 | Exhaust Gas Recirculation Valve .....  | 1C-100 |

## SPECIFICATIONS

### ENGINE SPECIFICATIONS

| Application                  | Description (1.6L DOHC)                        |
|------------------------------|--|
| <b>General Data:</b>         |  |
| Engine Type                  | 4 Cylinder (In-line)                           |
| Displacement                 | 1 598 cm <sup>3</sup> (97.51 in <sup>3</sup> ) |
| Bore Stroke                  | 79.0 X 81.5 mm (3.11 in. X 3.21 in.)           |
| Compression Ratio            | 9.5\$ 0.02:1                                   |
| Firing Order                 | 1-3-4-2  |
| <b>Cylinder Bore:</b>        |  |
| Diameter                     | 79.0 mm (3.11 in.)                             |
| Out of Round (Maximum)       | 0.0065 mm (0.00025 in.)                        |
| Taper (Maximum)              | 0.0065 mm (0.00025 in.)                        |
| <b>Piston:</b>               |  |
| Diameter                     | 78.970 mm (3.1090 in.)                         |
| Clearance to Bore            | 0.030 mm (0.0012 in.)                          |
| <b>Piston Rings:</b>         |  |
| Ring, End Gap:               |  |
| Top Compression              | 0.3 mm (0.019 in.)                             |
| 2nd Compression              | 0.3 mm (0.019 in.)                             |
| Groove Clearance:            |  |
| Top Impression               | 0.02 mm (0.0008 in.)                           |
| 2nd Impression               | 0.02 mm (0.0008 in.)                           |
| <b>Piston Pin:</b>           |  |
| Diameter                     | 18.00 mm (0.708 in.)                           |
| Pin Off-Set                  | 0.6X 0.8 mm (0.02X 0.03 in.)                   |
| <b>Camshaft:</b>             |  |
| Lift Intake                  | 8.75 mm (0.344 in.)                            |
| Lift Exhaust                 | 8.75 mm (0.344 in.)                            |
| End Play                     | 0.10X 0.25 mm (0.003X 0.009 in.)               |
| <b>Journal OD:</b>           |  |
| No. 1                        | 30 mm (1.18 in.)                               |
| No. 2                        | 27 mm (1.06 in.)                               |
| No. 3                        | 27 mm (1.06 in.)                               |
| No. 4                        | 27 mm (1.06 in.)                               |
| No. 5                        | 27 mm (1.06 in.)                               |
| <b>Crankshaft:</b>           |  |
| Main Journal:                |  |
| Diameter (All)               | 54.982X 54.994 mm (2.164X 2.165 in.)           |
| Taper (Maximum)              | 0.005 mm (0.0001 in.)                          |
| Out of Round (Maximum)       | 0.004 mm (0.0001 in.)                          |
| Main Bearing Clearance (All) | 0.005 mm (0.0001 in.)                          |

## ENGINE SPECIFICATIONS (Cont'd)

| Application                                  | Description (1.6L DOHC)                      |
|--|--|
| Crankshaft End Play                          | 0.01 mm (0.003 in.)                          |
| Connecting Rod Journal:<br>Diameter (All)    | 42.971X 42.987 mm (1.691X 1.692 in.)         |
| Taper (Maximum)                              | 0.005 mm (0.0001 in.)                        |
| Out of Round (Maximum)                       | 0.004 mm (0.0001 in.)                        |
| Rod Bearing Clearance (All)                  | 0.019X 0.070 mm (0.0007X 0.0027 in.)         |
| Rod Side Clearance                           | 0.070X 0.242 mm (0.0027X 0.009 in.)          |
| <b>Valve System:</b>                         |  |
| Valve Lash Compensators                      | Hydraulic                                    |
| Face Angle (All)                             | 46°  |
| Seat Angle (All)                             | 46°  |
| Seat Runout (Maximum, All)                   | 0.03 mm (0.019 in.)                          |
| Face Runout (Maximum, All)                   | 0.03 mm (0.019 in.)                          |
| Seat Width:<br>Intake                        | 1.17X 1.57 mm (0.046X 0.062 in.)             |
| Exhaust                                      | 1.07X 1.47 mm (0.042X 0.058 in.)             |
| Valve Guide Inside Diameter (All)            | 6.00X 6.02 mm (0.236X 0.237 in.)             |
| Valve Stem Diameter (All)                    | 6 mm (0.236 in.)                             |
| Valve Diameter (All):<br>Intake              | 30.3" 0.12 mm (1.19" 0.0047 in.)             |
| Exhaust                                      | 26.0" 0.14 mm (1.02" 0.0055 in.)             |
| Valve Spring Loads:<br>Valve Open            | 580" 26 N (428" 19 lbs) @ 23.0 mm (0.90 in.) |
| Valve Closed                                 | 260" 13 N (192" 9 lbs) @ 32.0 mm (1.25 in.)  |
| Valve Spring Free Length                     | -  |
| <b>Cylinder Head:</b>                        |  |
| Overall Height                               | 138.18 mm (5.440 in.)                        |
| Minimum Height after machining               | 138.13 mm (5.438 in.)                        |
| Distortion                                   | 0.1 mm (0.002 in.)                           |
| <b>Oil Pump:</b>                             |  |
| Gap Between Oil Pump Body and Out Rotor      | 0.4X 0.484 mm (0.016X 0.019 in.)             |
| Out Rotor Side Clearance                     | 0.45X 0.100 mm (0.017X 0.003 in.)            |
| Inner Rotor Side Clearance                   | 0.035X 0.085 mm (0.001X 0.003 in.)           |
| Relief Valve Spring Free Length              | 81 mm (3.188 in.)                            |
| <b>Sealants and Adhesives:</b>               |  |
| Rear Main Bearing Cap                        | GE p/n RTV 159                               |
| Camshaft Carrier to Cylinder Head            | HN 1581 (Loctite <sup>®</sup> 515)           |
| Oil Pan Bolts                                | HN 1256 (Loctite <sup>®</sup> 242)           |
| Oil Pump Bolts                               | HN 1256 (Loctite <sup>®</sup> 242)           |
| Oil Pan Pickup Tube Bolts                    | HN 1256 (Loctite <sup>®</sup> 242)           |
| Oil Gallery Plug                             | HN 1256 (Loctite <sup>®</sup> 242)           |
| Coolant Jacket Caps and Plugs (Freeze Plugs) | HN 1756 (Loctite <sup>®</sup> 176)           |
| Exhaust Manifold Studs/Nuts                  | Anti-seize Compound (HMC Spec HN1325)        |

## 1C - 4 DOHC ENGINE MECHANICAL

### FASTENER TIGHTENING SPECIFICATIONS









| Application   | NSm                              | Lb-Ft                            | Lb-In |
|---|----------------------------------|----------------------------------|-------|
| A/C Compressor Hose Assembly Retaining Bolt                                   | 33                               | 24                               | -     |
| A/C Compressor Mounting Bolts   | 27                               | 20                               | -     |
| A/C Compressor Mounting Bracket Bolts   | 50                               | 37                               | -     |
| Air Filter Housing Bolts  | 12                               | -                                | 106   |
| Alternator Adjusting Bolt   | 20                               | 15                               | -     |
| Alternator Adjusting Bracket Retaining Bolt                                   | 20                               | 15                               | -     |
| Camshaft Cap Bolts  | 16                               | 12                               | -     |
| Camshaft Gear Bolt, Intake & Exhaust  | 67.5                             | 49                               | -     |
| Connecting Rod Cap Bolts  | 25<br>+ 30_ + 15_                | 18<br>+ 30_ + 15_                | -     |
| Coolant Pump Retaining Bolts  | 10                               | -                                | 89    |
| Coolant Temperature Sensor  | 20                               | 15                               | -     |
| Crankshaft Bearing Cap Bolts  | 50<br>+ 45_ + 15_                | 37<br>+ 45_ + 15_                | -     |
| Crankshaft Pulley Bolt  | 95<br>+ 30_ + 15_                | 70<br>+ 30_ + 15_                | -     |
| Crankshaft Position Sensor Retaining Bolt                                     | 10                               | -                                | 89    |
| Cylinder Head Bolts (Camshaft Support Housing & Cylinder Head Mounting Bolts) | 25<br>+ 60_ + 60_<br>+ 60_ + 10_ | 18<br>+ 60_ + 60_<br>+ 60_ + 10_ | -     |
| DIS Ignition Coil Mounting Bracket Bolts                                      | 10                               | -                                | 89    |
| DIS Ignition Coil Mounting Bolts  | 10                               | -                                | 89    |
| Engine Mount Bracket Retaining Bolts  | 60                               | 44                               | -     |
| Engine Mount Retaining Nuts   | 40                               | 30                               | -     |
| Engine-Mount-to-Engine-Mount-Bracket Retaining Bolts                          | 60                               | 44                               | -     |
| Exhaust Flexible Pipe Bracket Bolts   | 40                               | 30                               | -     |
| Exhaust Flex Pipe-to-Catalytic Converter or Connecting Pipe Retaining Nuts    | 30                               | 22                               | -     |
| Exhaust Flex Pipe-to-Exhaust Manifold Retaining Nuts                          | 40                               | 30                               | -     |
| Exhaust Gas Recirculation Valve Adapter Bolts                                 | 25                               | 18                               | -     |
| Exhaust Manifold Heat Shield Bolts  | 15                               | 11                               | -     |
| Exhaust Manifold Retaining Nuts   | 25                               | 18                               | -     |
| Flexible Plate Bolts  | 60                               | 44                               | -     |
| Flexible Plate Inspection Cover Bolts   | 10                               | -                                | 89    |
| Flywheel Bolts  | 35<br>+ 30_ + 15_                | 25<br>+ 30_ + 15_                | -     |
| Flywheel Inspection Cover Bolts   | 12                               | -                                | 106   |
| Front Timing Belt Cover Bolts, Upper and Lower                                | 10                               | -                                | 89    |
| Fuel Rail Retaining Bolts   | 25                               | 18                               | -     |
| Intake Manifold Retaining Nuts/Bolts  | 25                               | 18                               | -     |
| Intake Manifold Support Bracket Bolts, Upper                                  | 25                               | 18                               | -     |

**FASTENER TIGHTENING SPECIFICATIONS (Cont'd)**







| <b>Application</b>                        | <b>N·m</b> | <b>Lb-Ft</b> | <b>Lb-In</b> |
|---|------------|--------------|--------------|
| Oil Pan Retaining Bolts                   | 10         | -            | 89           |
| Oil Pressure Switch                       | 40         | 30           | -            |
| Oil Pump Rear Cover Bolts                 | 6          | -            | 53           |
| Oil Pump Retaining Bolts                  | 10         | -            | 89           |
| Oil Pump Safety Relief Valve              | 30         | 22           | -            |
| Oil Pump/Pickup Tube Bolts                | 10         | -            | 89           |
| Power Steering Pump Mounting Bolts        | 25         | 18           | -            |
| Power Steering Pump Pulley Bolts          | 25         | 18           | -            |
| Rear Timing Belt Cover Bolts              | 10         | -            | 89           |
| Right Transaxle Brace Bolts               | 40         | 30           | -            |
| Spark Plug Cover Bolts                    | 3          | -            | 27           |
| Spark Plugs                               | 25         | 18           | -            |
| Support Bracket Bolt                      | 10         | -            | 89           |
| Thermostat Housing Mounting Bolts         | 20         | 15           | -            |
| Throttle Cable Bracket Bolts              | 8          | -            | 71           |
| Timing Belt Automatic Tensioner Bolts     | 25         | 18           | -            |
| Timing Belt Idler Pulley Bolt             | 40         | 30           | -            |
| Transaxle Torque Converter Bolts          | 65         | 48           | -            |
| Transmission/Transaxle Bell Housing Bolts | 75         | 55           | -            |
| Valve Cover Nuts                          | 10         | -            | 89           |

## SPECIAL TOOLS

### SPECIAL TOOLS TABLE


|   |   |  |  |
|---|---|--|--|
|  <p>A102B151</p>   | <p><b>J-42492<br/>Timing Belt Adjuster</b></p>                  |  <p>A102B154</p>   | <p><b>MKM-571-B<br/>Gauge</b></p>  |
|  <p>A102B161</p>  | <p><b>KM-470-B<br/>Angular Torque Gauge</b></p>                 |  <p>A102B156</p>  | <p><b>KM-340-0<br/>Cutter Set</b><br/>Includes: KM-340-7<br/>KM-340-13<br/>KM-340-26</p> |
|  <p>A102B152</p> | <p><b>J-28467-B<br/>Engine Assembly<br/>Support Fixture</b></p> |  <p>A102B157</p> | <p><b>KM-348<br/>Valve Spring<br/>Compressor</b></p>                                     |
|  <p>A102B153</p> | <p><b>KM-427<br/>Piston Pin Service Set</b></p>                 |  <p>A102C153</p> | <p><b>KM-653<br/>Adapter</b></p>   |

**SPECIAL TOOLS TABLE (Cont'd)**

|   |   |  |   |
|---|---|--|---|
| <br><br>A102C154   | <b>KM-805<br/>Valve Guide Reamer</b>    | <br><br>A102B160   | <b>KM-635<br/>Crankshaft Rear Oil<br/>Seal Installer</b>  |
| <br><br>A102B159  | <b>KM-412<br/>Engine Overhaul Stand</b> | <br><br>A102C155   | <b>J-36972<br/>Crankshaft Rear Oil<br/>Seal Installer</b> |
| <br><br>A202B005 | <b>KM-498-B<br/>Pressure Gauge</b>      | <br><br>B102C044 | <b>KM-135<br/>Adapter</b>                                 |

## COMPONENT LOCATOR

### UPPER END



A102C100




|                                 |                                      |
|---------------------------------|--------------------------------------|
| 1 Spark Plug Cover              | 28 Washer                            |
| 2 Oil Cap                       | 29 Cylinder Head Gasket              |
| 3 Oil Cap Seal                  | 30 Exhaust Valve                     |
| 4 Valve Cover                   | 31 Intake Valve                      |
| 5 Valve Cover Nut               | 32 Camshaft Seal                     |
| 6 Valve Cover Washer            | 33 Washer                            |
| 7 Valve Cover Gasket            | 34 Camshaft Gear Bolt                |
| 8 Seal                          | 35 Camshaft                          |
| 9 Hydraulic Valve Lash Adjuster | 36 Plug                              |
| 10 Valve Key                    | 37 Stud                              |
| 11 Valve Spring Retainer        | 38 Engine Coolant Temperature Sensor |
| 12 Valve Spring                 | 39 Coolant Temperature Sensor        |
| 13 Valve Stem Oil Seal          | 40 Bolt                              |
| 14 Valve Cover Stud             | 41 Front Camshaft Cap                |
| 15 Freeze Plug                  | 42 Plug                              |
| 16 Exhaust Manifold             | 43 Valve Guide                       |
| 17 Nut                          | 44 Intermediate Camshaft Cap         |
| 18 Exhaust Manifold Heat Shield | 45 Washer                            |
| 19 Oxygen Sensor                | 46 Head Bolt                         |
| 20 Bolt                         | 47 Exhaust Gas Recirculation Pipe    |
| 21 Bolt                         | 48 Intake Manifold                   |
| 22 Thermostat Housing           | 49 Plenum Gasket                     |
| 23 Thermostat Housing Seal      | 50 Throttle Body                     |
| 24 Thermostat                   | 51 Plenum                            |
| 25 Thermostat Adapter           | 52 Intake Manifold Gasket            |
| 26 Thermostat Adapter Seal      | 53 Exhaust Manifold Gasket           |
| 27 Nut                          | 54 Cylinder Head                     |

---


## 1C - 10 DOHC ENGINE MECHANICAL

### LOWER END



A202C006

- |                                   |  |
|-----------------------------------|--|
| 1 Piston Ring Set                 | 39 Crankshaft Position Sensor              |
| 2 Piston                          | 40 Flexible Plate (Automatic Transmission) |
| 3 Piston Pin                      | 41 Bolt (Automatic Transmission)           |
| 4 Connecting Rod                  | 42 Crankshaft Main Bearing Cap             |
| 5 Connecting Rod Bearing Set      | 43 Bolt                                    |
| 6 Connecting Rod Bolt             | 44 Bolt                                    |
| 7 Oil Level Gauge Stick           | 45 Knock Sensor                            |
| 8 Gauge Stick Tube                | 46 Oil Pan                                 |
| 9 Connecting Piece                | 47 Threaded Ring                           |
| 10 Oil Filter                     | 48 Bolt                                    |
| 11 Hose Clamp                     | 49 Bolt                                    |
| 12 Engine Ventilation Hose        | 50 Bracket                                 |
| 13 Engine Ventilation Pipe        | 51 Oil Pickup Tube                         |
| 14 Bolt                           | 52 Bolt                                    |
| 15 Oil Separator Gasket           | 53 Bolt                                    |
| 16 Crankshaft Pulley Bolt         | 54 Timing Belt                             |
| 17 Washer                         | 55 Cover Seal                              |
| 18 Crankshaft Pulley              | 56 Cover                                   |
| 19 Crankshaft Gear                | 57 Bolt                                    |
| 20 Rear Timing Belt Cover         | 58 Clamp                                   |
| 21 Bolt                           | 59 Bolt                                    |
| 22 Coolant Pump                   | 60 Washer                                  |
| 23 Oil Pump                       | 61 Cover Bracket                           |
| 24 Engine Block Seal Ring         | 62 Idler Pulley                            |
| 25 Oil Pump Body Gasket           | 63 Rear Cover Bolt                         |
| 26 Engine Block                   | 64 Bolt                                    |
| 27 Pressure Relief Valve Plunger  | 65 Auto Tensioner                          |
| 28 Spring                         | 66 Seal                                    |
| 29 Oil Pump Seal Ring             | 67 Bolt                                    |
| 30 Bolt Plug                      | 68 Seal                                    |
| 31 Crankshaft Bearing Set         | 69 Gear                                    |
| 32 Crankshaft                     | 70 Gear                                    |
| 33 Shaft Seal Ring                | 71 Cover                                   |
| 34 Flywheel (Manual Transmission) | 72 Bolt                                    |
| 35 Bolt (Manual Transmission)     | 73 Plug                                    |
| 36 Bolt                           | 74 Oil Pressure Sensor                     |
| 37 Bracket                        | 75 Intake Manifold Support Bracket         |
| 38 Bolt                           | 76 EGR Solenoid                            |
-



## **MAINTENANCE AND REPAIR**



### **ON-VEHICLE SERVICE**


#### **VALVE COVER**

**(Left-Hand Drive Shown, Right-Hand Drive Similar)**

##### **Removal Procedure**


1. Disconnect the negative battery cable.
2. Remove the spark plug cover bolts and cover.
3. Disconnect the breather tube from the valve cover.
4. Disconnect the crankcase ventilation tube from the valve cover.
5. Disconnect all of the necessary vacuum lines.
6. Disconnect the ignition wires from the spark plugs.
7. Remove the valve cover nuts.
8. Remove the valve cover washers.
9. Remove the valve cover.
10. Remove the valve cover gasket from the valve cover.





### **Installation Procedure**


1. Apply a small amount of gasket sealant to the corners of the front camshaft caps and the top of the rear valve cover to cylinder head seal.
2. Install the new valve cover gasket to the valve cover.
3. Install the valve cover.



4. Install the valve cover washers.
5. Install the valve cover nuts.

### **Tighten**

Tighten the valve cover nuts to 10 N $\cdot$ m (89 lb-in).




6. Connect the ignition wires to the spark plugs.
7. Install the spark plug cover.
8. Install the spark plug cover bolts.

### **Tighten**

Tighten the spark plug cover bolts to 3 N $\cdot$ m (27 lb-in).

9. Connect all of the necessary vacuum lines.
10. Connect the crankcase ventilation tube to the valve cover.
11. Connect the breather tube to the valve cover.
12. Connect the negative battery cable.

## 1C - 14 DOHC ENGINE MECHANICAL



### CYLINDER HEAD AND GASKET (Left-Hand Drive Shown, Right-Hand Drive Similar)



#### Tools Required


J-42472 Timing Belt Adjuster

KM-470-B Angular Torque Gauge


#### Removal Procedure

1. Remove the fuel pump fuse.
2. Start the engine. After it stalls, crank the engine after it stalls for 10 seconds to rid the fuel system of fuel pressure.
3. Disconnect the negative battery cable.
4. Disconnect the ECM ground terminal from the intake manifold.
5. Drain the engine coolant. Refer to Section 1D, Engine Cooling.
6. Disconnect the manifold air temperature sensor connector.
7. Disconnect the breather tube from the valve cover.
8. Disconnect the air intake tube from the throttle body.
9. Disconnect the DIS ignition coil connector.
10. Disconnect the oxygen sensor connector.
11. Disconnect the fuel injector harness connectors.
12. Disconnect the idle air control valve connector.
13. Disconnect the throttle position sensor connector.
14. Disconnect the engine coolant temperature sensor connector.
15. Disconnect the coolant temperature sensor connector.






16. Remove the air filter housing bolts.
17. Remove the air filter housing.
18. Remove the right front wheel. Refer to Section 2E, Tires and Wheels.
19. Remove the right front splash shield.



20. Disconnect the upper radiator hose at the thermostat housing.
  21. Remove the A/C compressor drive belt, if equipped.
  22. Remove the alternator adjusting bolt and the alternator drive belt.
  23. Remove the power steering pump pulley bolts, if equipped.
- Important:** Push the engine assembly toward the battery to remove the power steering pump pulley.
24. Remove the power steering pump pulley, if equipped.
  25. Remove the crankshaft pulley bolt.
  26. Remove the crankshaft pulley.




27. Remove the upper front timing belt cover bolts.
28. Remove the upper front timing belt cover.
29. Remove the lower front timing belt cover bolts.
30. Remove the lower front timing belt cover.
31. Remove the power steering pump, if equipped. Refer to Section 6B, Power Steering Pump.
32. Install the engine-mount-to-engine-mount-bracket retaining bolts and tighten the bolts to secure the engine if the power steering was removed.

## Tighten


Tighten the engine-mount-to-engine-mount-bracket retaining bolts to 60 N·m (44 lb-ft).

33. Align the camshaft gear timing marks.


## 1C - 16 DOHC ENGINE MECHANICAL



34. Slightly loosen the coolant pump retaining bolts.
35. Rotate the coolant pump counterclockwise using the timing belt adjuster J-42492 to relieve the timing belt tension.
36. Remove the timing belt. Refer to "Timing Belt" in this section.




37. Disconnect the crankcase ventilation tube at the valve cover.
38. Remove the spark plug cover bolts.
39. Remove the spark plug cover.
40. Disconnect the ignition wires from the spark plugs.
41. Remove the valve cover nuts.
42. Remove the valve cover washers.
43. Remove the valve cover and the valve cover gasket.



**Notice:** Take extreme care to prevent any scratches, nicks or damage to the camshafts.


44. While holding the intake camshaft firmly in place, remove the intake camshaft gear bolt.
45. Remove the intake camshaft gear.
46. While holding the exhaust camshaft firmly in place, remove the exhaust camshaft gear bolt.
47. Remove the exhaust camshaft gear.






**48. Remove the timing belt automatic tensioner bolts.**

**49. Remove the timing belt automatic tensioner.**



**50. Remove the timing belt idler pulley bolt.**


**51. Remove the timing belt idler pulley.**




**52. Remove the rear timing belt cover bolts.**

**53. Remove the rear timing belt cover.**


## 1C - 18 DOHC ENGINE MECHANICAL




- 54. Remove the exhaust flex pipe retaining nuts at the exhaust manifold studs and the bolts at the bracket.
- 55. Disconnect all of the necessary vacuum hoses.



- 56. Disconnect the fuel return line at the fuel pressure regulator.
- 57. Disconnect the fuel feed line at the fuel rail.
- 58. Remove the alternator adjusting bracket retaining bolt and the bracket.
- 59. Disconnect the heater inlet hose at the cylinder head.
- 60. Disconnect the surge tank coolant hose at the throttle body.



- 61. Remove the upper intake manifold support bracket bolts.



62. Disconnect the throttle cable at the throttle body and the intake manifold.


63. Loosen all of the cylinder head bolts gradually and in the sequence shown.

64. Remove the cylinder head bolts.

65. Remove the cylinder head with the intake manifold and the exhaust manifold attached.

**Notice:** Prevent any engine oil or coolant from entering the cylinders when removing the cylinder heads.

66. Remove the cylinder head gasket.



### Cleaning Procedure

1. Clean the gasket surfaces of the cylinder head and the engine block.

2. Make sure the gasket surfaces of the cylinder head and the engine block are free of nicks and heavy scratches.

3. Clean the cylinder head bolts.

4. Inspect the cylinder head for warpage. Refer to "Cylinder Head and Valve Train Components" in this section.

### Installation Procedure

1. Install the cylinder head gasket.


2. Install the cylinder head with the intake manifold and the exhaust manifold attached.

3. Install the cylinder head bolts.


4. Tighten the cylinder head bolts gradually and in the sequence shown.

### Tighten

Tighten the cylinder head bolts to 25 N·m (18 lb-ft). Adjust the bolts to 60 degrees + 60 degrees + 60 degrees + 10 degrees using the angular torque gauge KM-470-B.



## 1C - 20 DOHC ENGINE MECHANICAL



5. Connect the throttle cable at the throttle body and the intake manifold.


6. Install the intake manifold support bracket upper bolts to the intake manifold.

### Tighten

Tighten the intake manifold support bracket upper bolts to the intake manifold to 25 NSm (18 lb-ft).

7. Connect the surge tank coolant hose at the throttle body.

8. Connect the heater inlet hose to the cylinder head.



9. Install the alternator adjusting bracket with the bolt.


### Tighten

Tighten the alternator adjusting bracket retaining bolt to 20 NSm (15 lb-ft).

10. Connect the fuel feed line at the fuel rail.

11. Connect the fuel return line at the fuel rail.

12. Connect all of the necessary vacuum hoses.



13. Install the exhaust flex pipe retaining nuts at the exhaust manifold flange and the bolts at the bracket.

### Tighten


Tighten the exhaust flex pipe retaining nuts and bracket bolts to 40 NSm (30 lb-ft).

14. Install the rear timing belt cover.

15. Install the rear timing belt cover bolts.

### Tighten

Tighten the rear timing belt cover bolts to 10 NSm (89 lb-in).



16. Install the timing belt automatic tensioner.
17. Install the timing belt automatic tensioner bolts.


**Tighten**

Tighten the timing belt automatic tensioner bolts to 25 N $\cdot$ m (18 lb-ft).

18. Install the timing belt idler pulley.
19. Install the timing belt idler pulley bolt.

**Tighten**

Tighten the timing belt idler pulley bolt to 40 N $\cdot$ m (30 lb-ft).




**Notice:** Take extreme care to prevent any scratches, nicks or damage to the camshafts.

20. Install the intake camshaft gear.
21. While holding the intake camshaft firmly in place, install the intake camshaft gear bolt.

**Tighten**

Tighten the intake camshaft gear bolt to 67.5 N $\cdot$ m (49 lb-ft).




22. Install the exhaust camshaft gear.
23. While holding the exhaust camshaft firmly in place, install the exhaust camshaft gear bolt.

**Tighten**

Tighten the exhaust camshaft gear bolt to 67.5 N $\cdot$ m (49 lb-ft).


## 1C - 22 DOHC ENGINE MECHANICAL



24. Apply a small amount of gasket sealant to the corners of the front camshaft caps, and the top of the rear valve cover to cylinder head seal.
25. Install the valve cover and the valve cover gasket.
26. Install the valve cover washers.
27. Install the valve cover nuts.

### Tighten

Tighten the valve cover nuts to 10 N·m (89 lb-in).




28. Connect the ignition wires to the spark plugs.
29. Install the spark plug cover.
30. Install the spark plug cover bolts.


### Tighten

Tighten the spark plug cover bolts to 3 N·m (27 lb-in).

31. Connect the crankcase ventilation tube to the valve cover.
32. Align the timing marks on the camshaft gears.



33. Align the mark on the crankshaft gear to the notch at the bottom of the rear timing belt cover.




34. Install the timing belt.

35. Rotate the coolant pump clockwise using the timing belt adjuster J-42492 to apply tension to the timing belt.

### Tighten

Tighten the coolant pump retaining bolts to 10 NSm (89 lb-in).

36. Check and adjust the timing belt tension. Refer to "Timing Belt Check and Adjust" in this section.



37. Install the power steering pump, if equipped. Refer to Section 6B, Power Steering Pump.

38. Install the engine-mount-bracket-to-engine-mount retaining bolts if the power steering pump was installed.

### Tighten

Tighten the engine-mount-bracket-to-engine-mount retaining bolts to 60 NSm (44 lb-ft).

39. Install the upper and lower front timing belt cover.

40. Install the upper and lower front timing belt cover bolts.

### Tighten

Tighten the upper and lower front timing belt cover bolts to 10 NSm (89 lb-in).


41. Install the crankshaft pulley.

42. Install the crankshaft pulley bolt.

### Tighten

Tighten the crankshaft pulley bolt to 95 NSm (70 lb-ft) using a torque wrench. Using the angular torque gauge KM-470-B, tighten the crankshaft pulley bolt to 30 degrees + 15 degrees.

## 1C - 24 DOHC ENGINE MECHANICAL



- 43. Install the power steering pump pulley, if equipped.
- 44. Install the power steering pump pulley bolts, if equipped.

### Tighten


Tighten the power steering pump pulley bolts to 25 Nsm (18 lb-ft).

- 45. Install the alternator drive belt.
- 46. Install the alternator adjusting bolt.

### Tighten

Tighten the alternator adjusting bolt to 20 Nsm (15 lb-ft).

- 47. Install the A/C compressor drive belt, if equipped.
- 48. Connect the upper radiator hose to the thermostat housing.
- 49. Install the right front splash shield.
- 50. Install the right front wheel. Refer to Section 2E, Tires and Wheels.




- 51. Install the air filter housing.
- 52. Install the air filter housing bolts.

### Tighten


Tighten the air filter housing bolts to 12 Nsm (106 lb-in).

- 53. Connect the air intake tube to the throttle body.
- 54. Connect the breather tube to the valve cover.
- 55. Connect the manifold air temperature sensor connector.




- 56. Connect the coolant temperature sensor connector.
- 57. Connect the engine coolant temperature sensor connector.
- 58. Connect the idle air control valve connector.
- 59. Connect the throttle position sensor connector.





60. Connect the DIS ignition coil connector.
61. Connect the fuel injector harness connectors.
62. Connect the oxygen sensor connector.
63. Connect the ECM ground terminal at the intake manifold.
64. Install the fuel pump fuse.
65. Connect the negative battery ground cable.
66. Refill the engine cooling system. Refer to Section 1D, Engine Cooling.




## **CAMSHAFTS**


**(Left-Hand Drive Shown, Right-Hand Drive Similar)**

### **Removal Procedure**

1. Remove the timing belt. Refer to "Timing Belt" in this section.
2. Disconnect the air breather tube at the valve cover.
3. Disconnect the crankcase ventilation tube at the valve cover.
4. Remove the spark plug cover bolts.
5. Remove the spark plug cover.
6. Disconnect the ignition wires from the spark plugs.
7. Remove the valve cover nuts.
8. Remove the valve cover washers.
9. Remove the valve cover and the valve cover gasket.




## 1C - 26 DOHC ENGINE MECHANICAL




**Notice:** Take extreme care to prevent any scratches, nicks or damage to the camshafts.


10. While holding the intake camshaft firmly in place, remove the intake camshaft gear bolt.
11. Remove the intake camshaft gear.
12. While holding the exhaust camshaft firmly in place, remove the exhaust camshaft gear bolt.
13. Remove the exhaust camshaft gear.



14. Remove the camshaft cap bolts gradually and in the sequence shown for each camshaft cap.




15. Remove the intake camshaft caps. Maintain the correct positions for installation.
16. Remove the intake camshaft.
17. Remove the exhaust camshaft caps. Maintain the correct positions for installation.
18. Remove the exhaust camshaft.



### Installation Procedure

**Notice:** Take extreme care to prevent any scratches, nicks or damage to the camshafts.


1. Lubricate the camshaft journals and the camshaft caps with engine oil.
2. Install the intake camshaft.
3. Install the intake camshaft caps in their original positions.
4. Install the intake camshaft cap bolts.
5. Install the exhaust camshaft.
6. Install the exhaust camshaft caps in their original positions.
7. Install the exhaust camshaft cap bolts.



8. Tighten the camshaft cap bolts gradually and in the sequence shown for each camshaft cap.

### Tighten

Tighten the camshaft cap bolts to 16 N·m (12 lb-ft).




9. Measure the intake camshaft end play and the exhaust camshaft end play. Refer to "Engine Specifications" in this section.
10. Install the intake camshaft gear.
11. While holding the intake camshaft firmly in place, install the intake camshaft gear bolt.

### Tighten

Tighten the intake camshaft gear bolt to 67.5 N·m (49 lb-ft).

## 1C - 28 DOHC ENGINE MECHANICAL




12. Install the exhaust camshaft gear.

13. While holding the exhaust camshaft firmly in place, install the exhaust camshaft gear bolt.

### Tighten

Tighten the exhaust camshaft gear bolt to 67.5 N<sub>m</sub> (49 lb-ft).




14. Install the valve cover and the valve cover gasket.

15. Install the valve cover washers.

16. Install the valve cover nuts.

### Tighten

Tighten the valve cover nuts to 10 N<sub>m</sub> (89 lb-in).



17. Connect the ignition wires to the spark plugs.

18. Install the spark plug cover.

19. Install the spark plug cover bolts.


### Tighten

Tighten the spark plug cover bolts to 3 N<sub>m</sub> (27 lb-in).

20. Connect the air breather tube to the valve cover.

21. Connect the crankcase ventilation tube to the valve cover.

22. Install the timing belt. Refer to "Timing Belt" in this section.



## TIMING BELT CHECK AND ADJUST (Left-Hand Drive Shown, Right-Hand Drive Similar)


### Tools Required

J-42492 Timing Belt Adjuster


KM-470-B Angular Torque Gauge

### Adjustment Procedure

1. Disconnect the negative battery cable.
2. Disconnect the manifold air temperature sensor connector.
3. Remove the air intake tube from the throttle body.
4. Remove the breather tube from the valve cover.



5. Remove the air filter housing bolts.
6. Remove the air filter housing.
7. Remove the right front wheel. Refer to Section 2E, Tires and Wheels.
8. Remove the right front splash shield.




9. Remove the A/C compressor drive belt, if equipped.
10. Remove the alternator drive belt.
11. Remove the power steering pump pulley bolts, if equipped.


**Important:** Push the engine assembly toward the battery to remove the power steering pump pulley.

12. Remove the power steering pump pulley, if equipped.
13. Remove the crankshaft pulley bolt.
14. Remove the crankshaft pulley.


## 1C - 30 DOHC ENGINE MECHANICAL




15. Remove the upper front timing belt cover bolts.
16. Remove the upper front timing belt cover.
17. Remove the lower front timing belt cover bolts.
18. Remove the lower front timing belt cover.
19. Remove the power steering pump mounting bolts, if equipped.
20. Install the crankshaft pulley bolt.




21. Rotate the crankshaft at least one full turn clockwise using the crankshaft pulley bolt.
22. Align the mark on the crankshaft gear to the notch at the bottom of the rear timing belt cover.




23. Align the camshaft gear timing marks.



- 24. Slightly loosen the coolant pump retaining bolts.
- 25. Rotate the coolant pump clockwise using the timing belt adjuster J-42492.




- 26. Rotate the coolant pump clockwise until the adjust arm pointer of the timing belt automatic tensioner is aligned to the notch in the timing belt automatic tensioner bracket.




- 27. Tighten the coolant pump retaining bolts.
- 28. Rotate the crankshaft two full turns clockwise using the crankshaft pulley.
- 29. Loosen the coolant pump retaining bolts.

## 1C - 32 DOHC ENGINE MECHANICAL



30. Using the timing belt adjuster J-42492, rotate the coolant pump until the adjust arm pointer of the timing belt automatic tensioner is aligned with the pointer on the timing belt automatic tensioner bracket.



31. Tighten the coolant pump retaining bolts.

### **Tighten**

Tighten the coolant pump retaining bolts to 10 NSm (89 lb-in).

32. Remove the crankshaft pulley bolt.

33. Install the power steering pump mounting bolts, if equipped.

### **Tighten**


Tighten the power steering pump mounting bolts to 25 NSm (18 lb-ft).

34. Install the upper and lower front timing belt cover.

35. Install the upper and lower front timing belt cover bolts.

### **Tighten**

Tighten the upper and lower front timing belt cover bolts to 10 NSm (89 lb-in).



36. Install the crankshaft pulley.

37. Install the crankshaft pulley bolt.

### **Tighten**

Tighten the crankshaft pulley bolt to 95 NSm (70 lb-ft) using a torque wrench. Using the angular torque gauge KM-470-B, tighten the crankshaft pulley bolt to 30 degrees + 15 degrees.

38. Install the power steering pump pulley, if equipped.

39. Install the power steering pump pulley bolts, if equipped.


### **Tighten**

Tighten the power steering pump pulley bolts to 25 NSm (18 lb-ft).

40. Install the alternator drive belt.

41. Install the A/C compressor drive belt, if equipped.







- 42. Install the right front splash shield.
- 43. Install the right front wheel. Refer to Section 2E, Tires and Wheels.
- 44. Install the air filter housing.
- 45. Install the air filter housing bolts.

**Tighten**

Tighten the air filter housing bolts to 12 NSm (106 lb-in).



- 46. Connect the air intake tube to the throttle body.
- 47. Connect the breather tube to the valve cover.
- 48. Connect the manifold air temperature sensor connector.
- 49. Connect the negative battery cable.



**TIMING BELT**

(Left-Hand Drive Shown, Right-Hand Drive Similar)

**Tools Required**


J-42492 Timing Belt Adjuster

KM-470-B Angular Torque Gauge


**Removal Procedure**

- 1. Disconnect the negative battery cable.
- 2. Disconnect the manifold air temperature sensor connector.
- 3. Disconnect the air intake tube from the throttle body.
- 4. Disconnect the breather tube from the valve cover.


## 1C - 34 DOHC ENGINE MECHANICAL




5. Remove the air filter housing bolts.
6. Remove the air filter housing.
7. Remove the right front wheel. Refer to Section 2E, Tires and Wheels.
8. Remove the right front splash shield.




9. Remove the A/C compressor drive belt, if equipped.
10. Remove the alternator drive belt.
11. Remove the power steering pump pulley bolts, if equipped.
12. Remove the power steering pump pulley, if equipped.
13. Remove the crankshaft pulley bolt.
14. Remove the crankshaft pulley.




15. Remove the upper front timing belt cover bolts.
16. Remove the upper front timing belt cover.
17. Remove the lower front timing belt cover bolts.
18. Remove the lower front timing belt cover.
19. Remove the power steering pump mounting bolts, if equipped.
20. Install the crankshaft pulley bolt.



21. Using the crankshaft pulley bolt, rotate the crankshaft clockwise until the timing mark on the crankshaft gear is aligned with the notch at the bottom of the rear timing belt cover.




22. Slightly loosen the coolant pump retaining bolts.
23. Using the timing belt adjuster J-42492, rotate the coolant pump counterclockwise to release the tension on the timing belt.



**Important:** Remove the timing belt behind the power steering pump.


24. Remove the timing belt.

## 1C - 36 DOHC ENGINE MECHANICAL




### Installation Procedure

1. Align the timing mark on the crankshaft gear to the notch on the bottom of the rear timing belt cover.




2. Align the timing marks on the camshaft gears.




**Important:** Insert the timing belt behind the power steering pump.


3. Install the timing belt.



4. Rotate the coolant pump clockwise using the timing belt adjuster J-42492.




5. Rotate the coolant pump clockwise until the adjust arm pointer of the timing belt automatic tensioner is aligned to the notch in the timing belt automatic tensioner bracket.



6. Tighten the coolant pump retaining bolts.  
7. Rotate the crankshaft two full turns clockwise using the crankshaft pulley bolt.  
8. Loosen the coolant pump retaining bolts.  
9. Rotate the coolant pump until the adjust arm pointer of the timing belt automatic tensioner is aligned with the pointer on the timing belt automatic tensioner bracket.


## 1C - 38 DOHC ENGINE MECHANICAL



10. Tighten the coolant pump retaining bolts.

### Tighten

Tighten the coolant pump retaining bolts to 10 NSm (89 lb-in).



11. Remove the crankshaft pulley bolt.

12. Install the power steering pump mounting bolts, if equipped.

### Tighten


Tighten the power steering mounting bolts to 25 NSm (18 lb-ft).

13. Install the upper and lower front timing belt cover.

14. Install the upper and lower front timing belt cover bolts.

### Tighten

Tighten the upper and lower front timing belt cover bolts to 10 NSm (89 lb-in).




15. Install the crankshaft pulley.

16. Install the crankshaft pulley bolt.

### Tighten

Tighten the crankshaft pulley bolt to 95 NSm (70 lb-ft) using a torque wrench. Using the angular torque gauge KM-470-B, tighten the crankshaft pulley bolt to 30 degrees + 15 degrees.




17. Install the power steering pump pulley, if equipped.
18. Install the power steering pump pulley bolts, if equipped.

**Tighten**

Tighten the power steering pump pulley bolts to 25 NSm (18 lb-ft).

19. Install the alternator drive belt.
20. Install the A/C compressor drive belt, if equipped.
21. Install the right front splash shield.
22. Install the right front wheel. Refer to Section 2E, Tires and Wheels.




24. Install the air filter housing.
25. Install the air filter housing bolts.

**Tighten**

Tighten the air filter housing bolts to 12 NSm (106 lb-in).

26. Connect the air intake tube to the throttle body.
27. Connect the breather tube to the valve cover.
28. Connect the manifold air temperature sensor connector.
29. Connect the negative battery cable.



**ENGINE OIL PRESSURE INSPECTION PROCEDURE**


**Tools Required**

KM-498-B Pressure Gauge


KM-135 Adapter

1. Remove the front, right-hand wheel well splash shield.
2. Disconnect the oil pressure switch connector.

## 1C - 40 DOHC ENGINE MECHANICAL



3. Install the adapter KM-135 in place of the oil pressure switch.
4. Connect the pressure gauge KM-498-B to the adapter.
5. Start the engine and check the oil pressure at idle speed and engine temperature of 80\_C (176\_F). The minimum oil pressure should be 30 kPa (8.88 psi).
6. Turn the engine OFF and remove the oil pressure gauge and adapter.




7. Install the oil pressure switch.

### Tighten

Tighten the oil pressure switch to 40 NSm (30 lb-ft).

8. Connect the oil pressure switch connector.
9. Install the lower front, right-hand wheel well splash shield.
10. Check the oil level and fill to the full mark.




## OIL PUMP


### Removal Procedure

1. Disconnect the negative battery cable.
2. Remove the power steering pump, if equipped. Refer to Section 6B, Power Steering Pump.
3. Remove the timing belt. Refer to "Timing Belt" in this section.
4. Remove the rear timing belt cover. Refer to "Rear Timing Belt Cover" in this section.
5. Disconnect the oil pressure switch connector.






6. Remove the crankshaft position sensor bolt.
7. Remove the crankshaft position sensor.
8. Remove the oil pan. Refer to "Oil Pan" in this section.
9. Remove the oil pump pickup tube and the support bracket bolts.
10. Remove the oil pump pickup tube.




11. Remove the oil pump retaining bolts.
12. Carefully separate the oil pump and the gasket from the engine block and the oil pan.
13. Remove the oil pump.




### Inspection Procedure

1. Clean the oil pump and the engine block gasket mating surfaces.
2. Remove the safety relief valve bolt.
3. Remove the safety relief valve and the spring.
4. Remove the oil pump-to-crankshaft seal.

## 1C - 42 DOHC ENGINE MECHANICAL



5. Remove the oil pump rear cover bolts.
6. Remove the rear cover.



7. Clean the oil pump housing and all of the parts of the oil pump housing.
8. Inspect all of the parts for signs of wear. Refer to "Engine Specifications" in this section.
9. Coat all of the oil pump parts with clean engine oil and reinstall them.

**Notice:** Pack the oil pump gear cavity with petroleum jelly to ensure an oil pump prime, or engine damage could result.

10. Apply Loctite<sup>R</sup> 242 to the rear cover bolts and install the rear oil pump cover with the bolts.


### **Tighten**

Tighten the rear cover bolts to 6 NSm (53 lb-in).

11. Install the safety relief valve, the spring, the washer, and the bolt.

### **Tighten**

Tighten the safety relief valve bolt to 30 NSm (22 lb-ft).




### Installation Procedure


1. Apply Loctite<sup>®</sup> 242 to the oil pump bolts and room temperature vulcanizing (RTV) (sealer) sealant to the new oil pump gasket.
2. Install the gasket to the oil pump and install the oil pump to the engine block with the retaining bolts.

### Tighten

Tighten the oil pump retaining bolts to 10 N·m (89 lb-in).



3. Install a new oil pump-to-crankshaft seal. Coat the lip of the seal with a thin coat of grease.




4. Coat the threads of the oil pump pickup tube and support bracket bolts with Loctite<sup>®</sup> 242.
5. Install the oil pump pickup tube and bolts.

### Tighten

Tighten the oil pump pickup tube and the support bracket bolts to 10 N·m (89 lb-in).

## 1C - 44 DOHC ENGINE MECHANICAL




6. Install the oil pan. Refer to "Oil Pan" in this section.
7. Install the crankshaft position sensor and the bolt.

### Tighten

Tighten the crankshaft position sensor retaining bolt to 10 N·m (89 lb-in).


8. Connect the oil pressure switch connector.
9. Install the rear timing belt cover. Refer to "Rear Timing Belt Cover" in this section.
10. Install the power steering pump, if equipped. Refer to Section 6B, Power Steering Pump.
11. Install the timing belt. Refer to "Timing Belt" In this section.
12. Connect the negative battery cable.




## OIL PAN


### Removal Procedure

1. Disconnect the negative battery cable.
2. Remove the right front wheel. Refer to Section 2E, Tires and Wheels.
3. Remove the right front splash shield.
4. Drain the engine oil from the engine crankcase.
5. Remove the exhaust flex pipe retaining nuts from the exhaust manifold and the bolts at the bracket.
6. Remove the exhaust flex pipe retaining nuts from the catalytic converter or the connecting pipe.
7. Remove the exhaust flex pipe.
8. Remove the flywheel or flexible plate inspection cover bolts.
9. Remove the flywheel or flexible plate inspection cover.






10. Remove the oil pan retaining bolts.
11. Remove the oil pan from the engine block.
12. Remove the oil pan gasket from the oil pan.



### Cleaning Procedure

1. Clean the oil pan sealing surface.
2. Clean the engine block sealing surface.
3. Clean the oil pan retaining bolts.
4. Clean the oil pan attaching bolt holes in the engine block.



### Installation Procedure

1. Install the oil pan gasket to the oil pan.
2. Install the oil pan to the engine block.


**Important:** Install the oil pan within 5 minutes after applying the liquid gasket to the oil pan.

3. Install the oil pan retaining bolts.

### Tighten

Tighten the oil pan retaining bolts to 10 N $\cdot$ m (89 lb-in).


## 1C - 46 DOHC ENGINE MECHANICAL



4. Install the flywheel or flexible plate inspection cover.
5. Install the flywheel or flexible plate inspection cover bolts.

### Tighten

Tighten the flywheel inspection cover bolts to 12 N $\cdot$ m (106 lb-in) or the flexible plate inspection cover bolts to 10 N $\cdot$ m (89 lb-in).



6. Install the exhaust flex pipe.
7. Install the exhaust flex pipe retaining nuts to the exhaust manifold and the exhaust pipe bracket bolts.


### Tighten

Tighten the exhaust flex pipe retaining nuts to the exhaust manifold and the exhaust pipe bracket bolts to 40 N $\cdot$ m (30 lb-ft).


8. Install the exhaust flex pipe retaining nuts to the catalytic converter or the connecting pipe.

### Tighten

Tighten the exhaust flex pipe retaining nuts to the catalytic converter or the connecting pipe to 30 N $\cdot$ m (22 lb-ft).



9. Install the right front splash shield.
10. Install the right front wheel. Refer to Section 2E, Tires and Wheels.
11. Connect the negative battery cable.
12. Refill the engine crankcase with engine oil.




## ENGINE MOUNT

### Tools Required


J-28467-B Engine Assembly Lift Support

### Removal Procedure

1. Disconnect the negative battery cable.
2. Remove the upper radiator cover.
3. Remove the right front splash shield.
4. Support the engine assembly using the engine assembly lift support J-28467-B.




5. Remove the engine mount bracket retaining bolts.



6. Remove the engine mount retaining nuts.
7. Lower the engine.
8. Remove the engine mount.

## 1C - 48 DOHC ENGINE MECHANICAL




### Installation Procedure

1. Install the engine mount.
2. Raise the engine.
3. Install the engine mount retaining nuts.

### Tighten


Tighten the engine mount retaining nuts to 40 N $\cdot$ m (30 lb-ft).



4. Install the engine mount bracket retaining bolts.


### Tighten

Tighten the engine mount bracket retaining bolts to 60 N $\cdot$ m (44 lb-ft).



5. Remove engine assembly lift support J-28467-B.
6. Install the right front splash shield.
7. Install the upper radiator cover.
8. Connect the negative battery cable.








## INTAKE MANIFOLD

### Removal Procedure


1. Remove the fuel pump fuse.
2. Start the engine. Crank the engine after it stalls for 10 seconds to rid the fuel system of fuel pressure.
3. Disconnect the negative battery cable.
4. Disconnect the ECM ground terminal from the intake manifold.
5. Drain the engine coolant. Refer to Section 1D, Engine Cooling.
6. Disconnect the manifold air temperature sensor connector.
7. Disconnect the air intake tube from the throttle body.
8. Disconnect the idle air control valve connector.
9. Disconnect the throttle position sensor connector.
10. Disconnect the coolant temperature sensor connector.
11. Disconnect the engine coolant temperature sensor connector.
12. Disconnect the heater inlet hose from the cylinder head.
13. Disconnect the surge tank coolant hose at the throttle body.




## 1C - 50 DOHC ENGINE MECHANICAL




14. Disconnect all of the necessary vacuum hoses, including the vacuum hose at the fuel pressure regulator and the brake booster vacuum hose at the intake manifold.
15. Disconnect the throttle cable from the throttle body and the intake manifold.
16. Remove the throttle cable bracket bolts from the intake manifold.
17. Remove the throttle cable bracket.



18. Remove the fuel injector rail and fuel injectors as an assembly. Refer to Section 1F, Engine Controls.
19. Remove the alternator. Refer to Section 1E, Engine Electrical.
20. Remove the intake manifold support bracket bolts.
21. Remove the intake manifold support bracket.



22. Remove the intake manifold retaining bolts/nuts in the sequence shown.
23. Remove the intake manifold.
24. Remove the intake manifold gasket.
25. Clean the sealing surfaces of the intake manifold and the cylinder head.




### Installation Procedure

1. Install the intake manifold gasket.
2. Install the intake manifold.
3. Install the intake manifold retaining bolts/nuts in the sequence shown.

### Tighten

Tighten the intake manifold retaining bolts to 25 N·m (18 lb-ft).



4. Install the intake manifold support bracket.
5. Install the intake manifold support bracket upper bolts to the intake manifold.

### Tighten


Tighten the intake manifold support bracket bolts to 25 N·m (18 lb-ft).

6. Install the intake manifold support bracket lower bolt to the engine block.

### Tighten

Tighten the intake manifold support bracket lower bolt to the engine block to 40 N·m (30 lb-ft).

7. Install the alternator. Refer to Section 1E, Engine Electrical.




8. Install the fuel rail and fuel injectors as an assembly. Refer to Section 1F, Engine Controls.
9. Install the throttle cable bracket.
10. Install the throttle cable bracket bolts.

### Tighten


Tighten the throttle cable bracket bolts to 8 N·m (71 lb-in).

11. Connect the throttle cable to the intake manifold and the throttle body.
12. Connect all of the necessary vacuum lines that were previously disconnected.


## 1C - 52 DOHC ENGINE MECHANICAL



13. Connect the heater inlet hose to the cylinder head.
14. Connect the surge tank coolant hose to the throttle body.
15. Connect the coolant temperature sensor connector.
16. Connect the engine coolant temperature sensor connector.
17. Connect the idle air control valve connector.
18. Connect the throttle position sensor connector.




19. Connect the air intake tube to the throttle body.
20. Connect the manifold air temperature sensor connector.
21. Connect the ECM ground terminal to the intake manifold.
22. Install the fuel pump fuse.
23. Connect the negative battery cable.
24. Refill the engine cooling system. Refer to Section 1D, Engine Cooling.




## EXHAUST MANIFOLD

### Removal Procedure


1. Disconnect the negative battery cable.
2. Disconnect the oxygen sensor connector.
3. Remove the exhaust manifold heat shield bolts.
4. Remove the exhaust manifold heat shield.



5. Remove the exhaust flex pipe retaining nuts from the exhaust manifold studs.



6. Remove the exhaust manifold retaining nuts in the sequence shown.
7. Remove the exhaust manifold.
8. Remove the exhaust manifold gasket.
9. Clean the sealing surfaces of the exhaust manifold and the cylinder head.




### Installation Procedure

1. Install the exhaust manifold gasket.
2. Install the exhaust manifold.
3. Install the exhaust manifold retaining nuts and tighten in the sequence shown.

### Tighten

Tighten the exhaust manifold retaining nuts 25 N·m (18 lb-ft).


## 1C - 54 DOHC ENGINE MECHANICAL



4. Install the exhaust flex pipe retaining nuts to the exhaust manifold studs.

### Tighten

Tighten the exhaust flex pipe retaining nuts to 40 NSm (30 lb-ft).




5. Install the exhaust manifold heat shield.

6. Install the exhaust manifold heat shield bolts.


### Tighten

Tighten the exhaust manifold heat shield bolts to 15 NSm (11 lb-ft).



7. Connect the oxygen sensor connector.

8. Connect the negative battery cable.




## CAMSHAFT GEARS

(Left-Hand Drive Shown, Right-Hand Drive Similar)


### Removal Procedure


1. Disconnect the negative battery cable.
2. Remove the timing belt. Refer to "Timing Belt" in this section.
3. Remove the spark plug cover bolts.
4. Remove the spark plug cover.
5. Disconnect the ignition wires from the spark plugs.
6. Disconnect the crankcase ventilation tubes from the valve cover.
7. Remove the valve cover nuts.
8. Remove the valve cover washers.
9. Remove the valve cover and the valve cover gasket.



**Notice:** Take extreme care to prevent any scratches, nicks or damage to the camshafts.

10. While holding the intake camshaft firmly in place, remove the intake camshaft gear bolt.
11. Remove the intake camshaft gear.
12. While holding the exhaust camshaft firmly in place, remove the exhaust camshaft gear bolt.
13. Remove the exhaust camshaft gear.






### Installation Procedure

**Notice:** Take extreme care to prevent any scratches, nicks or damage to the camshafts.

1. Install the intake camshaft gear.
2. While holding the intake camshaft firmly in place, install the intake camshaft gear bolt.

### Tighten


Tighten the intake camshaft gear bolt to 67.5 N $\cdot$ m (49 lb-ft).



3. Install the exhaust camshaft gear.
4. While holding the exhaust camshaft firmly in place, install the exhaust camshaft gear bolt.

### Tighten

Tighten the exhaust camshaft gear bolt to 67.5 N $\cdot$ m (49 lb-ft).




5. Apply a small amount of gasket sealant to the corners of the front camshaft caps and the top of the rear valve cover to cylinder head seal.
6. Install the valve cover and the valve cover gasket.
7. Install the valve cover washers.
8. Install the valve cover nuts.

### Tighten

Tighten the valve cover nuts to 10 N $\cdot$ m (89 lb-in).






9. Connect the crankcase ventilation tubes to the valve cover.
10. Connect the ignition wires to the spark plugs.
11. Install the spark plug cover.
12. Install the spark plug cover bolts.

### **Tighten**

Tighten the spark plug cover bolts to 3 Nsm (27 lb-in).


13. Install the timing belt. Refer to "Timing Belt" in this section.
14. Connect the negative battery cable.



## **REAR TIMING BELT COVER**


### **Removal Procedure**

1. Remove the timing belt and the timing belt cover. Refer to "Timing Belt" in this section.
2. Remove the camshaft gears. Refer to "Camshaft Gears" in this section.
3. Remove the crankshaft gear.
4. Remove the timing belt automatic tensioner bolts.
5. Remove the timing belt automatic tensioner.




6. Remove the timing belt idler pulley bolt.
7. Remove the timing belt idler pulley.

## 1C - 58 DOHC ENGINE MECHANICAL



8. Remove the rear timing belt cover bolts.
9. Remove the rear timing belt cover.




### Installation Procedure

1. Install the rear timing belt cover.
2. Install the rear timing belt cover bolts.

#### Tighten


Tighten the rear timing belt cover bolts to 10 NSm (89 lb-in).



3. Install the timing belt idler pulley.
4. Install the timing belt idler pulley bolt.

#### Tighten

Tighten the timing belt idler pulley bolt to 40 NSm (30 lb-ft).




A102C018

5. Install the timing belt automatic tensioner.
6. Install the timing belt automatic tensioner bolts.

### Tighten

Tighten the timing belt automatic tensioner bolts to 25 N<sub>m</sub> (18 lb-ft).

7. Install the crankshaft gear.
8. Install the camshaft gears. Refer to "Camshaft Gears" in this section.
9. Install the timing belt and timing belt cover. Refer to "Timing Belt" in this section.



A102B012

## ENGINE


### Tools Required

KM-470-B Angular Torque Gauge

### Removal Procedure

**Important:** On vehicles equipped with manual transaxle, the manual transaxle must be removed before the engine is removed. Refer to Section 5B, Manual Transaxle.


1. Remove the fuel pump fuse.
2. Start the engine. Crank the engine after it stalls for 10 seconds to rid the fuel system of fuel pressure.
3. Remove the hood. Refer to Section 9R, Body Front End.
4. Drain the engine oil.




A102B013

5. Disconnect the negative battery cable.
6. Disconnect and separate the positive battery cable.
7. Disconnect the negative battery cable from the vehicle frame.


## 1C - 60 DOHC ENGINE MECHANICAL




8. Discharge the air conditioning system, if equipped. Refer to Section 7B, Manual Control Heating, Ventilation, and Air Conditioning System.
9. Disconnect the manifold air temperature sensor connector.
10. Remove the air intake tube from the throttle body and air filter housing.
11. Disconnect the breather tubes from the valve cover.




12. Remove the right front wheel. Refer to Section 2E, Tires and Wheels.
13. Remove the right front splash shield.
14. Remove the A/C compressor drive belt, if equipped.
15. Remove the alternator drive belt.
16. Remove the power steering pump pulley bolts.
17. Remove the power steering pump pulley.




18. Drain the engine coolant. Refer to Section 1D, Engine Cooling.
19. Remove the cooling system radiator and the engine cooling fans. Refer to Section 1D, Engine Cooling.
20. Disconnect the upper radiator hose from the thermostat housing.
21. Disconnect the power steering return hose from the power steering pump, if equipped. Refer to Section 6A, Power Steering System.
22. Disconnect the power steering pressure hose from the power steering pump, if equipped. Refer to Section 6A, Power Steering System.
23. Disconnect the electrical connector at the DIS ignition coil and the ECM ground terminal at the intake manifold and at the starter motor.



- 24. Disconnect the oxygen sensor connector.
- 25. Disconnect the fuel injector harness connectors.
- 26. Disconnect the idle air control valve connector.
- 27. Disconnect the throttle position sensor connector.
- 28. Disconnect the engine coolant temperature sensor connector.
- 29. Disconnect the coolant temperature sensor connector.
- 30. Disconnect the alternator voltage regulator connector.




- 31. Disconnect all of the necessary vacuum lines including the brake booster vacuum hose.
- 32. Disconnect the fuel return line at the fuel pressure regulator.
- 33. Disconnect the fuel feed line at the fuel rail.




- 34. Disconnect the throttle cable from the throttle body and the intake manifold bracket.
- 35. Disconnect the surge tank coolant hose at the throttle body.
- 36. Disconnect the heater outlet hose at the coolant pipe.
- 37. Disconnect the heater inlet hose from the cylinder head.
- 38. Disconnect the surge tank coolant hose from the coolant pipe.
- 39. Disconnect the lower radiator hose from the coolant pipe.


## 1C - 62 DOHC ENGINE MECHANICAL




40. Disconnect the starter solenoid "S" terminal wire.
41. Remove the A/C compressor hose assembly retaining bolt.
42. Disconnect the A/C compressor hose assembly from the compressor.
43. Disconnect the electrical connector at the A/C compressor coil.
44. Remove the A/C compressor mounting bolts.
45. Remove the A/C compressor.
46. Remove the A/C compressor mounting bracket bolts from the engine block.
47. Remove the A/C compressor mounting bracket.




48. Remove the exhaust flex pipe retaining nuts from the exhaust manifold studs and the bolts at the bracket.
49. Remove the exhaust flex pipe retaining nuts from the catalytic converter or the connecting pipe.
50. Remove the exhaust flex pipe.




51. Remove the crankshaft pulley bolt.
52. Remove the crankshaft pulley.
53. Disconnect the vacuum lines at the charcoal canister purge and exhaust gas recirculation (EGR) solenoid.
54. Disconnect the electrical connector at the charcoal canister purge and EGR solenoid.
55. Disconnect the electrical connector at the oil pressure switch.
56. Disconnect the crankshaft position sensor and the knock sensor connectors.
57. Remove the crankshaft position sensor retaining bolt.
58. Remove the crankshaft position sensor.



- 59. Remove the right transaxle brace bolts from the transmission.
- 60. Remove the flywheel or flexible plate inspection cover bolts.
- 61. Remove the flywheel or flexible plate inspection cover.




- 62. Remove the transaxle torque converter bolts, if automatic transaxle equipped.
- 63. Remove the transmission/transaxle bell housing bolts.
- 64. Support the transmission with a floor jack.
- 65. Install the engine lifting device.



- 66. Disconnect the right engine mount bracket from the engine mount by removing the retaining bolts.
- 67. Remove the right engine mount bracket from the engine block.
- 68. Separate the engine block from the transmission.
- 69. Remove the engine.

## 1C - 64 DOHC ENGINE MECHANICAL




### Installation Procedure

1. Install the engine into the engine compartment.
2. Align the engine alignment pins to the transmission.
3. Install the transmission/transaxle bell housing bolts.

#### Tighten

Tighten the transmission/transaxle bell housing bolts to 75 N $\cdot$ m (55 lb-ft).



4. Install the right engine mount bracket to the engine block.
5. Install the right engine mount bracket retaining bolts.


#### Tighten

Tighten the right engine mount bracket retaining bolts to 60 N $\cdot$ m (44 lb-ft).

6. Connect the right engine mount bracket to the engine mount by installing the two retaining bolts.

#### Tighten

Tighten the right engine mount-to-engine mount bracket retaining bolts to 60 N $\cdot$ m (44 lb-ft).




7. Remove the floor jack used for support of the transmission.
8. Remove the engine lifting device.
9. Install the transaxle torque converter bolts, if automatic transaxle equipped.

#### Tighten

Tighten the transaxle torque converter bolts to 65 N $\cdot$ m (48 lb-ft).





10. Install the flywheel or flexible plate inspection cover.
11. Install the flywheel or flexible plate inspection cover bolts.


**Tighten**

Tighten the flywheel inspection cover bolts to 12 NSm (106 lb-in) or the flexible plate inspection cover bolts to 10 NSm (89 lb-in).

12. Install the right transaxle brace bolts to the transmission.

**Tighten**


Tighten the right transaxle brace bolts to 40 NSm (30 lb-ft).



13. Connect the vacuum lines at the charcoal canister purge and EGR solenoid.
14. Connect the electrical connector charcoal canister purge and EGR solenoid.
15. Connect the oil pressure switch connector.
16. Install the crankshaft pulley.
17. Install the crankshaft pulley bolt.

**Tighten**

Tighten the crankshaft pulley bolt to 95 NSm (70 lb-ft) using a torque wrench. Using the angular torque gauge KM-470-B, tighten the crankshaft pulley bolt to 30 degrees + 15 degrees.



18. Install the crankshaft position sensor and the crankshaft position sensor retaining bolt.

**Tighten**


Tighten the crankshaft position sensor retaining bolt to 10 NSm (89 lb-in).

19. Connect the crankshaft position sensor and the knock sensor connectors.
20. Install the exhaust flex pipe.
21. Install the exhaust flex pipe retaining nuts to the exhaust manifold studs and the bolts at the bracket.

**Tighten**

Tighten the exhaust flex pipe retaining nuts and the bolts at the bracket to 40 NSm (30 lb-ft).

## 1C - 66 DOHC ENGINE MECHANICAL



22. Install the exhaust flex pipe retaining nuts to the catalytic converter.


### Tighten

Tighten the exhaust flex pipe retaining nuts to the catalytic converter on the connecting pipe or the connecting pipe to 30 N $\cdot$ m (22 lb-ft).

23. Connect the power steering pressure hose, if equipped. Refer to Section 6A, Power Steering System.
24. Connect the power steering return hose, if equipped. Refer to Section 6A, Power Steering System.
25. Install the A/C compressor mounting bracket, if equipped.
26. Install the A/C compressor mounting bracket bolts, if equipped.

### Tighten


Tighten the A/C compressor mounting brackets bolts to 50 N $\cdot$ m (37 lb-ft).



27. Install the A/C compressor, if equipped.
28. Install the A/C compressor mounting bolts, if equipped.

### Tighten


Tighten the A/C compressor mounting bolts to 27 N $\cdot$ m (20 lb-ft).



29. Connect the A/C compressor coil connector, if equipped.
30. Install the alternator drive belt.
31. Install the A/C compressor drive belt, if equipped.
32. Connect the A/C compressor hose assembly and the A/C compressor hose assembly retaining bolt, if equipped.

**Tighten**

Tighten the A/C compressor hose assembly retaining bolt to 33 N $\cdot$ m (24 lb-ft).




33. Install the power steering pump pulley, if equipped.
34. Install the power steering pump pulley bolts, if equipped.

**Tighten**


Tighten the power steering pump pulley bolts to 25 N $\cdot$ m (18 lb-ft).

35. Install the right front splash shield.
36. Install the right front wheel. Refer to Section 2E, Tires and Wheels.
37. Connect the fuel feed line to the fuel rail.
38. Connect the fuel return line to the fuel pressure regulator.




39. Connect all of the necessary vacuum lines including the brake booster vacuum hose.
40. Connect the oxygen sensor connector.
41. Connect the starter solenoid "S" terminal wire.
42. Connect the alternator voltage regulator connector.
43. Connect the coolant temperature sensor connector.
44. Connect the engine coolant temperature sensor connector.
45. Connect the throttle position sensor connector.
46. Connect the idle air control valve connector.


## 1C - 68 DOHC ENGINE MECHANICAL




- 47. Connect the fuel injector harness connectors.
- 48. Connect the electrical connector at the DIS ignition coil and the ECM ground terminal at the intake manifold and the starter motor.
- 49. Install the air intake tube between the throttle body and the air filter housing.
- 50. Connect the breather tubes to the valve cover.
- 51. Connect the manifold air temperature sensor connector.
- 52. Install the cooling system radiator and the engine cooling fans. Refer to Section 1D, Engine Cooling.



- 53. Connect the lower radiator hose to the coolant pipe.
- 54. Connect the upper radiator hose to the thermostat housing.
- 55. Connect the heater inlet hose to the cylinder head.
- 56. Connect the heater outlet hose to the coolant pipe.
- 57. Connect the coolant surge tank hose to the coolant pipe.
- 58. Connect the surge tank coolant hose to the throttle body.



- 59. Connect the throttle cable to the throttle body and the intake manifold bracket.
- 60. Install the fuel pump fuse.
- 61. Connect the negative battery cable to the vehicle frame.
- 62. Connect the negative battery cable.
- 63. Connect and assemble the positive battery cable.
- 64. Refill the engine crankcase with engine oil.
- 65. Refill the engine coolant system. Refer to Section 1D, Engine Cooling.
- 66. Bleed the power steering system, if equipped. Refer to Section 6A, Power Steering System.
- 67. Refill the A/C refrigerant system, if equipped. Refer to Section 7B, Manual Control Heating, Ventilation, and Air Conditioning System.
- 68. Install the hood. Refer to Section 9R, Body Front End.



## PISTONS AND RODS


### Tools Required

KM-427 Piston Pin Service Set

KM 470-B Angular Torque Gauge


### Removal Procedure

1. Remove the cylinder head with the intake manifold and exhaust manifold attached. Refer to "Cylinder Head and Gasket" in this section.
2. Remove the oil pan. Refer to "Oil Pan" in this section.
3. Remove the oil pump/pickup tube bolts.
4. Remove the oil pump/pickup tube.
5. Move the piston to the bottom of the piston stroke.
6. Mark the connecting rod cap for position.
7. Remove the connecting rod cap bolts.
8. Remove the connecting rod cap and lower connecting rod bearing.
9. Remove the upper piston connecting rod bearing.
10. Ridge ream the cylinder wall.




**Caution:** Use care when handling the piston. Worn piston rings are sharp and may cause injury.

11. Remove the piston.
12. Use a piston ring expander tool to expand the piston rings.
13. Remove the piston rings.




## 1C - 70 DOHC ENGINE MECHANICAL




14. Remove the piston pin from the piston and connecting rod assembly using the piston pin service set KM-427.

15. Separate the piston from the connecting rod.




### Inspection Procedure


1. Inspect the connecting rod for bending or twisting. If the connecting rod is bent or twisted, replace the connecting rod.
2. Inspect the connecting rod bearings.
3. Inspect the connecting rod lower end for wear.
4. Inspect the connecting rod upper end for scoring.
5. Inspect the crankshaft rod bearing journal for wear. Refer to "Engine Specifications" in this section.
6. Inspect the piston for scoring, cracks, and wear.
7. Inspect the piston for taper using a micrometer.



8. Inspect the piston for fit to the connecting rod.




9. Inspect the engine block deck surface for flatness using a straight edge and a feeler gauge. Refer to "Engine Specifications" in this section.
10. Inspect the bearing bore for concentricity and alignment using a bore gauge. Refer to "Engine Specifications" in this section. If the bearing bore is beyond specifications, replace the engine block.
11. Inspect the engine block cylinder bore for wear, runout, ridging and taper using a bore gauge. Refer to "Engine Specifications" in this section.
12. Inspect the engine block cylinder bore for glazing. Lightly hone the cylinder bore as necessary.




### Installation Procedure

1. Align the notch on the piston and connecting rod so that the proper sides will be facing the front of the engine.
2. Install the piston pin guide through the piston and the connecting rod.
3. Coat the piston pin with clean oil.
4. Install the piston pin into the opposite side of the piston.
5. Install the piston pin into the piston and connecting rod assembly using the piston pin service set KM-427.




6. Select a set of new piston rings.
7. Measure the piston ring gap using a feeler gauge. Refer to "Engine Specifications" in this section.
8. Increase the piston ring gap by carefully filing off excess material if the piston ring gap is below specifications.


## 1C - 72 DOHC ENGINE MECHANICAL



9. Measure the piston ring side clearance using a feeler gauge. Refer to "Engine Specifications" in this section.
10. If the piston ring is too thick, try another piston ring.
11. If no piston ring can be found that fits to specifications, the piston ring may be ground to size with emery paper placed on a sheet of glass.




12. Install a piston oil ring, the expander, then the second piston oil ring to the bottom ring groove of the piston.
13. Install the second compression ring to the middle ring groove of the piston.
14. Install the top compression ring to the top ring groove of the piston.




15. Use a piston ring expander to install the piston rings. Do not expand the piston rings beyond the expansion necessary for installation.
16. Stagger the piston oil rings, the oil ring rail gaps, the second compression ring, and the top compression ring in relation to the notch on the top of the piston.






17. Lubricate the cylinder wall and the piston rings with clean engine oil.
18. Install the piston using a ring compressor and a wood handle. Guide the lower connecting rod end to prevent damaging the crankshaft journal.
19. Install the connecting rod cap and bearings. Refer to "Crankshaft Bearings and Connecting Rod Bearings - Gauging Plastic" in this section.



20. Install the connecting rod cap bolts.

### **Tighten**

Tighten the connecting rod cap bolts to 25 NSm (18 lb-ft). Using the angular torque gauge KM 470-B, tighten the bolts one turn of 30 degrees plus one turn of 15 degrees.




21. Install the oil pump/pickup tube.
22. Install the oil pump/pickup tube bolts.

### **Tighten**

Tighten the oil pickup tube bolts to 10 NSm (89 lb-in).

23. Install the oil pan. Refer to "Oil Pan" in this section.
24. Install the cylinder head with the intake manifold and exhaust manifold attached. Refer to "Cylinder Head and Gasket" in this section.



## UNIT REPAIR

### CYLINDER HEAD AND VALVE TRAIN COMPONENTS

#### Tools Required

MKM-571-B Gauge

KM-340-0 Cutter Set

KM-340-7 Guide Drift

KM-340-13 Cutters

KM-340-26 Cutters


KM-348 Valve Spring Compressor


KM-653 Adapter

KM-805 Reamer


#### Disassembly Procedure

1. Remove the cylinder head with the intake manifold and the exhaust manifold attached. Refer to "Cylinder Head and Gasket" in this section.
2. Remove the coolant temperature sensor.
3. Remove the exhaust manifold heat shield bolts.
4. Remove the exhaust manifold heat shield.
5. Remove the exhaust manifold retaining nuts in the sequence shown.
6. Remove the exhaust manifold.
7. Remove the exhaust manifold gasket.
8. Remove the exhaust manifold studs.
9. Remove the thermostat housing mounting bolts.
10. Remove the thermostat housing assembly.
11. Remove the fuel rail retaining bolts and the fuel rail assembly.






12. Remove the intake manifold retaining nuts and retaining bolts in the sequence shown.
13. Remove the intake manifold.
14. Remove the intake manifold gasket.
15. Remove the intake manifold studs.




16. Remove the DIS ignition coil mounting bolts.
17. Remove the DIS ignition coil with the ignition wires attached.
18. Remove the DIS ignition coil mounting bracket bolts.
19. Remove the DIS ignition coil mounting bracket.
20. Remove the exhaust gas recirculation valve adapter bolts.
21. Remove the exhaust gas recirculation valve adapter.
22. Remove the exhaust gas recirculation valve adapter gasket.
23. Remove the spark plugs.




24. Remove the camshaft cap bolts gradually and in the sequence shown for each camshaft cap.


## 1C - 76 DOHC ENGINE MECHANICAL




25. Remove the intake camshaft caps. Maintain the correct positions for installation.
26. Remove the intake camshaft.
27. Remove the intake valve lash adjusters.
28. Remove the exhaust camshaft caps. Maintain the correct positions for installation.
29. Remove the exhaust camshaft.
30. Remove the exhaust valve lash adjusters.



31. Compress the valve springs with the valve spring compressor KM-348 and the adapter KM-653.
32. Remove the valve retainers.
33. Remove the valve spring compressor KM-348 and the adapter KM-653.
34. Remove the valve spring caps.
35. Remove the valve springs. Maintain the original position of the valves springs for installation.




36. Remove the valves. Maintain the original position of the valves for installation.
37. Remove the valve stem seals.




### Cylinder Head Inspection

1. Clean the sealing surfaces.
2. Inspect the cylinder head gasket and mating surfaces for leaks, corrosion and blow-by.
3. Inspect the cylinder head for cracks.
4. Inspect the length and width of the cylinder head using a feeler gauge and a straight edge.
5. Check the sealing surfaces for deformation and warp-age. The cylinder head sealing surfaces must be flat within 0.050 mm (0.002 inch) maximum.




6. Measure the height of the cylinder head from sealing surface to sealing surface. The cylinder head height should be 138.13 to 138.18 mm (5.438 to 5.440 inches). If the cylinder head height is less than 138.13 mm (5.438 inches), replace the cylinder head.
7. Inspect all threaded holes for damage.
8. Valve seats for excessive wear and burned spots.




### Valve Inspection

1. Inspect the valve stem tip for wear.
2. Inspect the valve retainer grooves and the oil seal grooves for chips and wear.
3. Inspect the valves for burns or cracks.
4. Inspect the valve stem for burrs and scratches.
5. Inspect the valve stem. The valve stem must be straight.
6. Inspect the valve face for grooving. If the groove is so deep that refacing the valve would result in a sharp edge, replace the valve.

## 1C - 78 DOHC ENGINE MECHANICAL




7. Inspect the valve spring. If the valve spring ends are not parallel, replace the valve spring.
8. Measure the valve spring height. Refer to "Engine Specifications" in this section. If the valve spring height does not match the specifications, replace the valve spring.
9. Inspect the valve spring seating surface of the valve rotators for wear or gouges. Replace as required.



### Cleaning Procedure


1. Clean the cylinder head.
2. Clean the valve guides.
3. Clean all of the threaded holes.
4. Clean the valves of carbon, oil and varnish.




### Cylinder Head Overhaul

#### Valve Grind-in

1. Lubricate the valve stem using a fine-grained paste.
2. Lift the valve rhythmically from the seat with a commercially-available valve grinding tool in order to distribute the paste.




3. Check the contact pattern on the valve head and in the cylinder head.
4. Clean the valves, the valve guides, and the cylinder head.



### Valve Grind


1. Ensure that there are no crater line burns on the valve cone.
2. The valve may be reground only two times. Do not grind the valve stem end.
3. The angle at the valve face is 45 degrees.
4. Inspect the assembly height of the intake valves and the exhaust valves.



### Valve Guide - Ream

1. Measure the diameter of the valve guide using gauge MKM-571-B and a commercially-available inside micrometer.

## 1C - 80 DOHC ENGINE MECHANICAL




**Important:** Valve oversizes may already have been fitted in production.

2. An oversize service code is on the valve guide and the valve stem end. The following table gives the correct size, reamer, and production code for each service.

| Size   | Reamer | Production Code | Service Code |
|--------|--------|-----------------|--------------|
| Normal | —      | —               | K            |
| 0.075  | KM-805 | 1               | K1           |
| 0.150  |        | 2               | K2           |


3. Ream the valve guide from the upper side of the cylinder head to the next oversize.
4. After reaming, cross out the code and emboss the valve guide with the new code.



### Valve Seat - Cut


1. Place the cylinder head on wooden blocks.
2. Cut the intake and the exhaust valve seats using the guide drift KM-340-7 as follows:
  - D Valve seat: \* 45 degrees side using the cutter KM-340-13.
  - D Upper correction angle: \* 30 degrees side using the cutter KM-340-13.
  - D Lower Correction Angle: \* 60 degrees using cutter KM-340-26.
3. Clean the chippings from the cylinder head.
4. Inspect the dimension for the valve seat width.
  - D Intake: 1.17 to 1.57 mm (0.046 to 0.062 inch).
  - D Exhaust: 1.07 to 1.47 mm (0.042 to 0.058 inch).
5. Inspect the assembly height of the intake valves and the exhaust valves.
6. If the dimension is exceeded, install new valves. Inspect the assembly height of the intake valves and the exhaust valves again.
7. If the valve assembly height is still too large despite replacing the valves, replace the cylinder head.






**Assembly Procedure**

1. Install the valve stem seals.
2. Lubricate the valve stems with engine oil.
3. Carefully install the valves in their original positions.  
Do not damage the valve stem seals.
4. Install the valve springs in their original positions.
5. Install the valve spring caps.




6. Compress the valve springs with the valve spring compressor KM-348 and adapter KM-653.
7. Install the valve retainers.
8. Remove the valve spring compressor KM-348 and adapter KM-653.



9. Lubricate the valve lash adjusters with engine oil.
10. Install the valve lash adjusters.


## 1C - 82 DOHC ENGINE MECHANICAL



11. Install the intake camshaft.
12. Install the intake camshaft caps in their original positions.
13. Install the exhaust camshaft.
14. Install the exhaust camshaft caps in their original positions.
15. Install the camshaft cap bolts.
16. Tighten the camshaft cap bolts gradually and in the sequence shown for each camshaft cap.

### Tighten

Tighten the camshaft cap bolts to 16 NSm (12 lb-ft).



17. Install the spark plugs.

### Tighten

Tighten the spark plugs to 25 NSm (18 lb-ft).

18. Install the exhaust gas recirculation valve adapter gasket.
19. Install the exhaust gas recirculation valve adapter.
20. Install the exhaust gas recirculation valve adapter bolts.

### Tighten

Tighten the exhaust gas recirculation valve adapter bolts to 25 NSm (18 lb-ft).

21. Install the DIS ignition coil mounting bracket.
22. Install the DIS ignition coil mounting bracket bolts.


### Tighten

Tighten the DIS ignition coil mounting bracket bolts to 10 NSm (89 lb-in).

23. Install the DIS ignition coil with the ignition wires attached.
24. Install the DIS ignition coil mounting bolts.

### Tighten


Tighten the DIS ignition coil mounting bolts to 10 NSm (89 lb-in).



25. Install the intake manifold studs.
26. Install the intake manifold gasket.
27. Install the intake manifold.
28. Install the intake manifold retaining nuts and retaining bolts in the sequence shown.

#### Tighten

Tighten the intake manifold retaining nuts and retaining bolts to 25 NSm (18 lb-ft).



29. Install the fuel rail assembly with the bolts.


#### Tighten

Tighten the fuel rail retaining bolts to 25 NSm (18 lb-ft).

30. Install the thermostat housing assembly.
31. Install the thermostat housing mounting bolts.

#### Tighten

Tighten the thermostat housing mounting bolts to 20 NSm (15 lb-ft).



32. Install the exhaust manifold studs.
33. Install the exhaust manifold gasket.
34. Install the exhaust manifold.
35. Install the exhaust manifold retaining nuts in the sequence shown.

#### Tighten


Tighten the exhaust manifold retaining nuts to 25 NSm (18 lb-ft).

36. Install the exhaust manifold heat shield.
37. Install the exhaust manifold heat shield bolts.

#### Tighten

Tighten the exhaust manifold heat shield bolts to 15 NSm (11 lb-ft).

## 1C - 84 DOHC ENGINE MECHANICAL




38. Install the coolant temperature sensor.

### Tighten

Tighten the coolant temperature sensor to 20 N·m (15 lb-ft).

39. Install the cylinder head with the intake manifold and the exhaust manifold attached. Refer to "Cylinder Head and Gasket" in this section.



## CRANKSHAFT

### Tools Required

KM-412 Engine Overhaul Stand

J-42492 Timing Belt Adjuster


KM-470-B Angular Torque Gauge

J-36792 Crankshaft Rear Oil Seal Installer (or KM-635)

**Notice:** Take extreme care to prevent any scratches, nicks, or damage to the camshafts.


### Disassembly Procedure

1. Remove the engine. Refer to "Engine" in this section.
2. Remove the flywheel or flexible plate bolts.
3. Remove the flywheel or the flexible plate.




4. Remove the crankshaft rear oil seal.


5. Mount the engine assembly on the engine overhaul stand KM-412.



6. Remove the upper and lower front timing belt cover bolts.
7. Remove the upper and lower front timing belt cover.




8. Remove the power steering pump mounting bolts, if equipped.
9. Remove the power steering pump, if equipped.




10. Slightly loosen the coolant pump retaining bolts.

## 1C - 86 DOHC ENGINE MECHANICAL



11. Rotate the coolant pump using the timing belt adjuster J-42942 to remove the tension from the timing belt.

12. Remove the timing belt.



13. Disconnect the crankcase ventilation tubes from the valve cover.

14. Remove the spark plug cover bolts.


15. Remove the spark plug cover.

16. Disconnect the ignition wires from the spark plugs.

17. Remove the valve cover nuts.

18. Remove the valve cover washers.

19. Remove the valve cover and the valve cover gasket.




**Notice:** Take extreme care to prevent any scratches, nicks or damage to the camshafts.

20. While holding the intake camshaft firmly in place, remove the intake camshaft bolt.


21. Remove the intake camshaft gear.

22. While holding the exhaust camshaft firmly in place, remove the exhaust camshaft bolt.


23. Remove the exhaust camshaft gear.



- 24. Remove the timing belt automatic tensioner bolts.
- 25. Remove the timing belt automatic tensioner.
- 26. Remove the timing belt idler pulley bolt.
- 27. Remove the timing belt idler pulley.




- 28. Remove the crankshaft timing belt gear.
- 29. Remove the rear timing belt cover bolts.
- 30. Remove the rear timing belt cover.




- 31. Rotate the engine on the engine overhaul stand KM-412.


## 1C - 88 DOHC ENGINE MECHANICAL



- 32. Remove the oil pan retaining bolts.
- 33. Remove the oil pan.
- 34. Remove the oil pickup tube bolts.
- 35. Remove the oil pickup tube.




- 36. Remove the oil pump retaining bolts.
- 37. Remove the oil pump.




- 38. Mark the order of the connecting rod bearing caps.
- 39. Remove the connecting rod bearing cap bolts for all of the pistons.
- 40. Remove the connecting rod bearing caps and the lower connecting rod bearings.
- 41. Remove the upper connecting rod bearings.






42. Mark the order of the crankshaft bearing caps.
43. Remove the crankshaft bearing cap bolts.
44. Remove the crankshaft bearing caps and the lower crankshaft bearings.
45. Remove the crankshaft.
46. Remove the upper crankshaft bearings.
47. Clean any necessary parts.




### **Assembly Procedure**

1. Coat the crankshaft bearings with engine oil.
2. Install the upper crankshaft bearings in the engine block.




3. Install the crankshaft.
4. Install the lower crankshaft bearings in the bearing caps.
5. Inspect the crankshaft end play with the crankshaft bearings installed.
6. Check for permissible crankshaft end play. Refer to "Engine Specifications" in this section.

## 1C - 90 DOHC ENGINE MECHANICAL



A102B071

7. With the crankshaft mounted on the front and rear crankshaft bearings, check the middle crankshaft journal for permissible out-of-round (runout). Refer to "Engine Specifications" in this section.




A102B072

**Important:** Grease the crankshaft journals and lubricate the crankshaft bearings slightly so that the plastic gauging thread does not tear when the crankshaft bearing caps are removed.

8. Inspect all of the crankshaft bearing clearances using a commercially available plastic gauging (ductile plastic threads).
9. Cut the plastic gauging threads to the length of the bearing width. Lay them axially between the crankshaft journals and the crankshaft bearings.
10. Install the crankshaft bearing caps and the bolts.


### Tighten

Tighten the crankshaft bearing cap bolts to 50 NSm (37 lb-ft) 45 degrees + 15 degrees.



A102B073


11. Remove the crankshaft bearing cap bolts and the caps.
12. Measure the width of the flattened plastic thread of the plastic gauging using a ruler. (Plastic gauging is available for different tolerance ranges.)
13. Inspect the bearing clearance for permissible tolerance ranges. Refer to "Engine Specifications" in this section.



14. Apply a bead of adhesive sealing compound to the grooves of the crankshaft bearing caps.
15. Install the crankshaft bearing caps to the engine block.
16. Tighten the crankshaft bearing caps using new bolts.

### Tighten

Tighten the crankshaft bearing cap bolts to 50 Nsm (37 lb-ft) using a torque wrench. Use the angular torque gauge KM-470-B to tighten the crankshaft bearings 45 degrees + 15 degrees.




**Important:** Grease the connecting rod journals and lubricate the connecting rod bearings slightly so that the plastic gauging thread does not tear when the connecting rod bearing caps are removed.

17. Inspect all of the connecting rod bearing clearances using a commercially available plastic gauging (ductile plastic threads).
18. Cut the plastic gauging threads to the length of the connecting rod bearing width. Lay them axially between the connecting rod journals and the connecting rod bearings.
19. Install the connecting rod bearing caps.


### Tighten

Tighten the connecting rod bearing cap bolts to 25 Nsm (18 lb-ft) using a torque wrench. Use the angular torque gauge KM-470-B to tighten the connecting rod bearing cap bolts to 30 degrees + 15 degrees.



20. Remove the connecting rod bearing caps.
21. Measure the width of the flattened plastic thread of the plastic gauging using a ruler. (Plastic gauging is available for different tolerance ranges.)
22. Inspect the bearing clearance for permissible tolerance ranges. Refer to "Engine Specifications" in this section.

## 1C - 92 DOHC ENGINE MECHANICAL




23. Install the connecting rod bearing caps to the connecting rods.

24. Tighten the connecting rod bearing caps using new bolts.

### Tighten

Tighten the connecting rod bearing cap bolts to 25 NSm (18 lb-ft) using a torque wrench. Use the angular torque gauge KM-470-B to tighten the connecting rod cap bolts to 30 degrees + 15 degrees.




25. Install the oil pump.

26. Install the oil pump retaining bolts.

### Tighten

Tighten the oil pump retaining bolts to 10 NSm (89 lb-in).




27. Install the oil pump/pickup tube.

28. Install the oil pump/pickup tube bolts.

### Tighten

Tighten the oil pump/pickup tube bolts to 10 NSm (89 lb-in).



29. Install the oil pan gasket to the oil pan.


30. Install the oil pan.

**Important:** Install the oil pan within 5 minutes after applying the liquid gasket to the oil pan.


31. Install the oil pan retaining bolts.

**Tighten**

Tighten the oil pan retaining bolts to 10 NSm (89 lb-in).



32. Rotate the engine on the engine assembly stand KM-412.




33. Install the rear timing belt cover.

34. Install the rear timing belt cover bolts.

**Tighten**

Tighten the rear timing belt cover bolts to 10 NSm (89 lb-in).

## 1C - 94 DOHC ENGINE MECHANICAL



- 35. Install the crankshaft timing belt gear.
- 36. Install the timing belt automatic tensioner.
- 37. Install the timing belt automatic tensioner bolts.


### Tighten

Tighten the timing belt automatic tensioner bolts to 25 N·m (18 lb-ft).

- 38. Install the timing belt idler pulley.
- 39. Install the timing belt idler pulley bolt.

### Tighten

Tighten the timing belt idler pulley bolt to 40 N·m (30 lb-ft).



**Notice:** Take extreme care to prevent any scratches, nicks or damage to the camshafts.

- 40. Install the intake camshaft gear.
- 41. Install the intake camshaft gear bolt while holding the intake camshaft firmly in place.


### Tighten

Tighten the intake camshaft gear bolt to 67.5 N·m (49 lb-ft).

- 42. Install the exhaust camshaft gear.
- 43. Install the exhaust camshaft gear bolt while holding the exhaust camshaft firmly in place.

### Tighten


Tighten the exhaust camshaft bolt to 67.5 N·m (49 lb-ft).



- 44. Install the timing belt. Refer to "Timing Belt" in this section.
- 45. Adjust the timing belt tension. Refer to "Timing Belt Check and Adjust" in this section.
- 46. Apply a small amount of gasket sealant to the corners of the front camshaft caps and the top of the rear valve cover to cylinder head seal.
- 47. Install the valve cover and the valve cover gasket.
- 48. Install the valve cover washers.
- 49. Install the valve cover nuts.

### Tighten

Tighten the valve cover nuts to 10 N·m (89 lb-in).



50. Connect the ignition wires to the spark plugs.

51. Install the spark plug cover.

52. Install the spark plug cover bolts.

### **Tighten**

Tighten the spark plug cover bolts to 3 NSm (27 lb-in).

53. Connect the crankcase ventilation tube to the valve cover.

54. Install the upper and lower front timing belt cover.

55. Install the upper and lower front timing belt cover bolts.

### **Tighten**


Tighten the upper and lower front timing belt cover bolts to 10 NSm (89 lb-in).

56. Install the power steering pump, if equipped.

57. Install the power steering pump mounting bolts.

### **Tighten**


Tighten the power steering pump mounting bolts to 25 NSm (18 lb-ft).




58. Install the engine lifting device.

59. Remove the engine from the engine assembly stand KM-412.

## 1C - 96 DOHC ENGINE MECHANICAL



60. Install a new crankshaft rear oil seal using installer J-36972 (or KM-635).




61. Install the flywheel or flexible plate.

62. Install the flywheel or the flexible plate bolts.

### Tighten

Tighten the flywheel bolts to 35 Nsm (25 lb-ft). Use the angular torque gauge KM-470-B to tighten the flywheel bolts to 30 degrees + 15 degrees. For the manual transmission, tighten the flexible plate bolts to 60 Nsm (44 lb-ft).

63. Install the engine. Refer to "Engine" in this section.



## CRANKSHAFT BEARINGS AND CONNECTING ROD BEARINGS — GAUGING PLASTIC


### Tools Required

KM-470-B Angular Torque Gauge


### Inspection Procedure - Crankshaft

1. Coat the crankshaft bearings with engine oil.
2. Install the upper crankshaft bearings into the engine block crankshaft journals.
3. Install the lower crankshaft bearings into the crankshaft bearing caps.
4. Install the crankshaft.
5. Inspect the crankshaft end play with the crankshaft bearings installed.
6. Check for permissible crankshaft end play. Refer to "Engine Specifications" in this section.






7. With the crankshaft mounted on the front and rear crankshaft bearings, check the middle crankshaft journal for permissible out-of-round (runout). Refer to "Engine Specifications" in this section.



**Notice:** Grease the crankshaft journals and lubricate the crankshaft bearings slightly so that the plastic gauging thread does not tear when the crankshaft bearing caps are removed.

8. Inspect all of the crankshaft bearing clearances using a commercially available plastic gauging (ductile plastic threads).
9. Cut the plastic gauging threads to the length of the bearing width. Lay them axially between the crankshaft journals and the crankshaft bearings.




10. Install the crankshaft bearing caps.


11. Install the crankshaft bearing cap bolts.

### Tighten

Tighten the crankshaft bearing cap bolts to 50 N·m (37 lb-ft). Using the angular torque gauge KM-470-B, tighten the crankshaft bearing cap bolts to 45 degrees +15 degrees.



12. Remove the crankshaft bearing caps.
13. Measure the width of the flattened plastic thread of the plastic gauging using a ruler. (Plastic gauging is available for different tolerance ranges.)
14. Inspect the bearing clearances for permissible tolerance ranges. Refer to "Engine Specifications" in this section.




### Inspection Procedure - Connecting Rods

1. Coat the connecting rod bearings with engine oil.
2. Install the upper connecting rod bearings into the connecting rod journals.
3. Install the lower connecting rod bearings into the connecting rod bearing caps.

**Notice:** Grease the connecting rod journals and lubricate the connecting rod bearings slightly so that the plastic gauging thread does not tear when the connecting rod bearing caps are removed.


4. Inspect all of the connecting rod bearing clearances using a commercially available plastic gauging (ductile plastic threads).



5. Cut the plastic gauging threads to the length of the bearing width. Lay them axially between the connecting rod journals and the connecting rod bearings.
6. Install the connecting rod bearing caps.
7. Install the connecting rod bearing cap bolts.

### Tighten

Tighten the connecting rod cap bolts to 25 N·m (18 lb-ft). Using the angular torque gauge KM-470-B, tighten the connecting rod cap bolts to 30 degrees +15 degrees.



8. Remove the connecting rod bearing caps.
9. Measure the width of the flattened plastic thread of the plastic gauging using a ruler. (Plastic gauging is available for different tolerance ranges.)
10. Inspect the bearing clearance for permissible tolerance ranges. Refer to "Engine Specifications" in this section.

# GENERAL DESCRIPTION AND SYSTEM OPERATION

## CYLINDER HEAD AND GASKET

The cylinder head is made of an aluminum alloy. The cylinder head uses crossflow intake and exhaust ports. A spark plug is located in the center of each combustion chamber. The cylinder head houses the dual camshafts.

## CRANKSHAFT

The crankshaft has eight integral weights which are cast with it for balancing. Oil holes run through the center of the crankshaft to supply oil to the connecting rods, the bearings, the pistons, and the other components. The end thrust load is taken by the thrust washers installed at the center journal.

## TIMING BELT

The timing belt coordinates the crankshaft and the dual overhead camshafts and keeps them synchronized. The timing belt also turns the coolant pump. The timing belt and the pulleys are toothed so that there is no slippage between them. There are two idler pulleys. An automatic tensioner pulley maintains the timing belt's correct tension. The timing belt is made of a tough reinforced rubber similar to that used on the serpentine drive belt. The timing belt requires no lubrication.

## OIL PUMP

The oil pump draws engine oil from the oil pan and feeds it under pressure to the various parts of the engine. An oil strainer is mounted before the inlet of the oil pump to remove impurities which could clog or damage the oil pump or other engine components. When the drive gear rotates, the driven gear rotates. This causes the space between the gears to constantly open and narrow, pulling oil in from the oil pan when the space opens and pumping the oil out to the engine as it narrows.

At high engine speeds, the oil pump supplies a much higher amount of oil than required for lubrication of the engine. The oil pressure regulator prevents too much oil from entering the engine lubrication passages. During normal oil supply, a coil spring and valve keeps the bypass closed, directing all of the oil pumped to the engine. When the amount of oil being pumped increases, the pressure becomes high enough to overcome the force of the spring. This opens the valve of the oil pressure regulator, allowing the excess oil to flow through the valve and drain back to the oil pan.

## OIL PAN

The engine oil pan is mounted to the bottom of the cylinder block. The engine oil pan houses the crankcase and is made of pressed sheet metal.

Engine oil is pumped from the oil pan by the oil pump. After it passes through the oil filter, it is fed through two paths to lubricate the cylinder block and cylinder head.

In one path, the oil is pumped through oil passages in the crankshaft to the connecting rods, then to the pistons and cylinders. It then drains back to the oil pan. In the second path, the oil is pumped through passages to the camshaft. The oil passes through the internal passageways in the camshafts to lubricate the valve assemblies before draining back to the oil pan.

## EXHAUST MANIFOLD

A single four-port, rear-takedown manifold is used with this engine. The manifold is designed to direct escaping exhaust gases out of the combustion chambers with a minimum of backpressure. The oxygen sensor is mounted to the exhaust manifold.

## INTAKE MANIFOLD

The intake manifold has four independent long ports and utilizes an inertial supercharging effect to improve engine torque at low and moderate speeds. The plenum is attached to the intake manifold.

## CAMSHAFTS

This engine is a dual over head camshaft (DOHC) type, which means there are two camshafts. One camshaft operates the intake valves, and the other camshaft operates the exhaust valves. The camshafts sit in journals on the top of the engine (in the cylinder head) and are held in place by camshaft caps. The camshaft journals of the cylinder head are drilled for oil passages. Engine oil travels to the camshafts under pressure where it lubricates each camshaft journal. The oil returns to the oil pan through drain holes in the cylinder head. The camshaft lobes are machined into the solid camshaft to precisely open and close the intake and the exhaust valves the correct amount at the correct time. The camshaft lobes are oiled by splash action from pressurized oil escaping the camshaft journals.

## EXHAUST GAS RECIRCULATION VALVE

The exhaust gas recirculation (EGR) system is used to lower oxides of nitrogen (NOX) emission levels caused by high combustion temperatures. The main element of the system is the EGR valve which is operated by vacuum.

The EGR valve feeds small amounts of exhaust gas into the intake manifold to decrease the combustion temperature. The amount of exhaust gas recirculated is controlled by variations in vacuum and exhaust back pressure. If too much exhaust gas enters, combustion will not take place. For this reason, very little exhaust gas is allowed to pass through the valve, especially at idle.

The EGR valve is usually open under the following conditions:

- D Warm engine operation.
- D Above idle speed.